

TECHNICAL DATA

2WAY VRF SYSTEM



Model No. Outdoor Unit

	Class	8HP	10HP	12HP	14HP	16HP	18HP	20HP
ME1	Model Name	U-8ME1E81	U-10ME1E81	U-12ME1E81	U-14ME1E81	U-16ME1E81	U-18ME1E81	U-20ME1E81

Indoor Unit

	Class	22	28	36	45	56	60	73	90	106	140	160
U1	4-Way Cassette	S-22MU1E51 S-22MU1E5	S-28MU1E51 S-28MU1E5	S-36MU1E51 S-36MU1E5	S-45MU1E51 S-45MU1E5	S-56MU1E51 S-56MU1E5	S-60MU1E51	S-73MU1E51 S-73MU1E5	S-90MU1E51	S-106MU1E51 S-106MU1E5	S-140MU1E51 S-140MU1E5	S-160MU1E51 S-160MU1E5
Y1	4-Way Cassette 60×60	S-22MY1E5	S-28MY1E5	S-36MY1E5	S-45MY1E5	S-56MY1E5						
L1	2-Way Cassette	S-22ML1E5	S-28ML1E5	S-36ML1E5	S-45ML1E5	S-56ML1E5		S-73ML1E5				
D1	1-Way Cassette	S-22MD1E5	S-28MD1E5	S-36MD1E5	S-45MD1E5	S-56MD1E5		S-73MD1E5				
F1	Low Silhouette Ducted	S-22MF1E5	S-28MF1E5	S-36MF1E5	S-45MF1E5	S-56MF1E5		S-73MF1E5	S-90MF1E5	S-106MF1E5	S-140MF1E5	S-160MF1E5
F2	Low Silhouette Ducted	S-22MF2E5	S-28MF2E5	S-36MF2E5	S-45MF2E5	S-56MF2E5	S-60MF2E5	S-73MF2E5	S-90MF2E5	S-106MF2E5	S-140MF2E5	S-160MF2E5
M1	Slim Low Static Ducted	S-22MM1E5	S-28MM1E5	S-36MM1E5	S-45MM1E5	S-56MM1E5						
T1	Ceiling			S-36MT1E5	S-45MT1E5	S-56MT1E5		S-73MT1E5		S-106MT1E5	S-140MT1E5	
K1	Wall Mounted	S-22MK1E5	S-28MK1E5	S-36MK1E5	S-45MK1E5	S-56MK1E5		S-73MK1E5		S-106MK1E5		
R1	Concealed Floor Standing	S-22MR1E5	S-28MR1E5	S-36MR1E5	S-45MR1E5	S-56MR1E5		S-73MR1E5				
P1	Floor Standing	S-22MP1E5	S-28MP1E5	S-36MP1E5	S-45MP1E5	S-56MP1E5		S-73MP1E5				

	Class	73	106	140	224	280
E1	High Static Pressure Ducted	S-73ME1E5	S-106ME1E5	S-140ME1E5	S-224ME1E5	S-280ME1E5

IMPORTANT! Please Read Before Starting

This air conditioning system meets strict safety and operating standards. As the installer or service person, it is an important part of your job to install or service the system so it operates safely and efficiently.

For safe installation and trouble-free operation, you must:

- Carefully read this instruction booklet before beginning.
- Follow each installation or repair step exactly as shown.
- Observe all local, state, and national electrical codes.
- This product is intended for professional use.
Permission from the power supplier is required when installing the U-8ME1E81 outdoor unit that is connected to a 16 A distribution network.
- This equipment complies with EN/IEC 61000-3-12 provided that the short-circuit power S_{sc} is greater than or equals to the values corresponding to each model as shown in the table below at the interface point between the user's supply and the public system.
It is the responsibility of the installer or user of the equipment to ensure; by consultation with the distribution network operator if necessary that the equipment is connected only to supply with a short-circuit power S_{sc} greater than or equals to the values corresponding to each model as shown in the table below.

	U-10ME1E81	U-12ME1E81	U-14ME1E81	U-16ME1E81	U-18ME1E81	U-20ME1E81
S_{sc}	1,150 kVA	1,550 kVA	1,550 kVA	1,550 kVA	1,550 kVA	1,550 kVA

- This equipment complies with EN/IEC 61000-3-11 provided that the system impedance Z_{max} is less than or equal to the values corresponding to each model as shown in the table below at the interface point between the user's supply and the public system. Consult with the supply authority for the system impedance Z_{max} .

	U-10ME1E81	U-12ME1E81	U-14ME1E81	U-16ME1E81	U-18ME1E81	U-20ME1E81
Z_{max}	—	0.290 Ω	0.290 Ω	0.290 Ω	0.290 Ω	0.290 Ω

- Pay close attention to all warning and caution notices given in this manual.



WARNING

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



CAUTION

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

If Necessary, Get Help

These instructions are all you need for most installation sites and maintenance conditions. If you require help for a special problem, contact our sales/service outlet or your certified dealer for additional instructions.

In Case of Improper Installation

The manufacturer shall in no way be responsible for improper installation or maintenance service, including failure to follow the instructions in this document.

SPECIAL PRECAUTIONS

WARNING When Wiring



ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH. ONLY A QUALIFIED, EXPERIENCED ELECTRICIAN SHOULD ATTEMPT TO WIRE THIS SYSTEM.

- Do not supply power to the unit until all wiring and tubing are completed or reconnected and checked.
- Highly dangerous electrical voltages are used in this system. Carefully refer to the wiring diagram and these instructions when wiring. Improper connections and inadequate grounding can cause **accidental injury or death**.
- Connect all wiring tightly. Loose wiring may cause overheating at connection points and a possible fire hazard.
- Provide a power outlet to be used exclusively for each unit.
- ELCB must be incorporated in the fixed wiring. Circuit breaker must be incorporated in the fixed wiring in accordance with the wiring regulations.

	U-8ME1E81	U-10ME1E81	U-12ME1E81	U-14ME1E81
Circuit breaker	25 A	25 A	35 A	35 A

	U-16ME1E81	U-18ME1E81	U-20ME1E81
Circuit breaker	45 A	50 A	50 A

- Provide a power outlet exclusively for each unit, and full disconnection means having a contact separation in all poles must be incorporated in the fixed wiring in accordance with the wiring rules.
- To prevent possible hazards from insulation failure, the unit must be grounded.



When Transporting

Be careful when picking up and moving the indoor and outdoor units. Get a partner to help, and bend your knees when lifting to reduce strain on your back. Sharp edges or thin aluminum fins on the air conditioner can cut your fingers.

When Installing...

Select an installation location which is rigid and strong enough to support or hold the unit, and select a location for easy maintenance.

...In a Room

Properly insulate any tubing run inside a room to prevent "sweating" that can cause dripping and water damage to walls and floors.



CAUTION

Keep the fire alarm and the air outlet at least 1.5 m away from the unit.

...In Moist or Uneven Locations

Use a raised concrete pad or concrete blocks to provide a solid, level foundation for the outdoor unit. This prevents water damage and abnormal vibration.

...In an Area with High Winds

Securely anchor the outdoor unit down with bolts and a metal frame. Provide a suitable air baffle.

...In a Snowy Area (for Heat Pump-type Systems)

Install the outdoor unit on a raised platform that is higher than drifting snow. Provide snow vents.

When Connecting Refrigerant Tubing




WARNING

- When performing piping work do not mix air except for specified refrigerant (R410A) in refrigeration cycle. It causes capacity down, and risk of explosion and injury due to high tension inside the refrigerant cycle.
- Refrigerant gas leakage may cause fire.
- Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury, etc.
- Ventilate the room well, in the event that is refrigerant gas leaks during the installation. Be careful not to allow contact of the refrigerant gas with a flame as this will cause the generation of poisonous gas.
- Keep all tubing runs as short as possible.
- Use the flare method for connecting tubing.
- Apply refrigerant lubricant to the matching surfaces of the flare and union tubes before connecting them, then tighten the nut with a torque wrench for a leak-free connection.
- Check carefully for leaks before starting the test run.
- Do not leak refrigerant while piping work for an installation or re-installation, and while repairing refrigeration parts.
Handle liquid refrigerant carefully as it may cause frostbite.

When Servicing




WARNING

- Turn the power OFF at the main power box (mains), wait at least 10 minutes until it is discharged, then open the unit to check or repair electrical parts and wiring. 
- Keep your fingers and clothing away from any moving parts.
- Clean up the site after you finish, remembering to check that no metal scraps or bits of wiring have been left inside the unit being serviced.
- This product must not be modified or disassembled under any circumstances. Modified or disassembled unit may cause fire, electric shock or injury.
- Do not clean inside the indoor and outdoor units by users. Engage authorized dealer or specialist for cleaning.
- In case of malfunction of this appliance, do not repair by yourself. Contact to the sales dealer or service dealer for a repair.







CAUTION

- Do not touch the air inlet or the sharp aluminum fins of the outdoor unit. You may get injured. 
- Ventilate any enclosed areas when installing or testing the refrigeration system. Escaped refrigerant gas, on contact with fire or heat, can produce dangerously toxic gas.
- Confirm after installation that no refrigerant gas is leaking. If the gas comes in contact with a burning stove, gas water heater, electric room heater or other heat source, it can cause the generation of poisonous gas.

Others



CAUTION

- Do not touch the air inlet or the sharp aluminum fins of the outdoor unit. You may get injured. 
- Do not sit or step on the unit, you may fall down accidentally. 
- Do not stick any object into the FAN CASE. You may be injured and the unit may be damaged. 


Check of Density Limit

The room in which the air conditioner is to be installed requires a design that in the event of refrigerant gas leaking out, its density will not exceed a set limit.

The refrigerant (R410A), which is used in the air conditioner, is safe, without the toxicity or combustibility of ammonia, and is not restricted by laws imposed to protect the ozone layer. However, since it contains more than air, it poses the risk of suffocation if its density should rise excessively. Suffocation from leakage of refrigerant is almost non-existent. With the recent increase in the number of high density buildings, however, the installation of multi air conditioner systems is on the increase because of the need for effective use of floor space, individual control, energy conservation by curtailing heat and carrying power, etc.

Most importantly, the multi air conditioner system is able to replenish a large amount of refrigerant compared to conventional individual air conditioners. If a single unit of the multi air conditioner system is to be installed in a small room, select a suitable model and installation procedure so that if the refrigerant accidentally leaks out, its density does not reach the limit (and in the event of an emergency, measures can be made before injury can occur).

In a room where the density may exceed the limit, create an opening with adjacent rooms, or install mechanical ventilation combined with a gas leak detection device. The density is as given below.

Total amount of refrigerant (kg)


$$\text{Min. volume of the indoor unit installed room (m}^3\text{)} \leq \text{Density limit (kg/m}^3\text{)}$$

The density limit of refrigerant which is used in multi air conditioners is 0.3 kg/m^3 (ISO 5149).

NOTE

1. If there are 2 or more refrigerating systems in a single refrigerating device, the amount of refrigerant should be as charged in each independent device.

For the amount of charge in this example:




The possible amount of leaked refrigerant gas in rooms A, B and C is 10 kg.


The possible amount of leaked refrigerant gas in rooms D, E and F is 15 kg.

2. The standards for minimum room volume are as follows.


- (1) No partition (shaded portion)




- (2) When there is an effective opening with the adjacent room for ventilation of leaking refrigerant gas (opening without a door, or an opening 0.15% or larger than the respective floor spaces at the top or bottom of the door).



- (3) If an indoor unit is installed in each partitioned room and the refrigerant tubing is interconnected, the smallest room of course becomes the object. But when mechanical ventilation is installed interlocked with a gas leakage detector in the smallest room where the density limit is exceeded, the volume of the next smallest room becomes the object.



3. The minimum indoor floor space compared with the amount of refrigerant is roughly as follows: (When the ceiling is 2.7 m high)



Precautions for Installation Using New Refrigerant

1. Care regarding tubing

1-1. Process tubing

- Material: Use C1220 phosphorous deoxidized copper specified in JIS H3300 "Copper and Copper Alloy Seamless Pipes and Tubes." For tubes of $\phi 22.22$ or larger, use C1220 T-1/2H material or H material, and do not bend the tubes.
- **Tubing size: Be sure to use the sizes indicated in the table below.**
- Use a tube cutter when cutting the tubing, and be sure to remove any flash. This also applies to distribution joints (optional).
- When bending tubing, use a bending radius that is 4 times the outer diameter of the tubing or larger.



CAUTION

Use sufficient care in handling the tubing. Seal the tubing ends with caps or tape to prevent dirt, moisture, or other foreign substances from entering. These substances can result in system malfunction.

Unit: mm

Material		O				
Copper tube	Outer diameter	6.35	9.52	12.7	15.88	19.05
	Wall thickness	0.8	0.8	0.8	1.0	1.2

Unit: mm

Material		1/2 H, H					
Copper tube	Outer diameter	22.22	25.4	28.58	31.75	38.1	41.28
	Wall thickness	1.0	1.0	1.0	1.1	over 1.35	over 1.45

1-2. Prevent impurities including water, dust and oxide from entering the tubing. Impurities can cause R410A refrigerant deterioration and compressor defects. Due to the features of the refrigerant and refrigerating machine oil, the prevention of water and other impurities becomes more important than ever.

2. Be sure to recharge the refrigerant only in liquid form.

2-1. Since R410A is a non-azeotrope, recharging the refrigerant in gas form can lower performance and cause defects in the unit.

2-2. Since refrigerant composition changes and performance decreases when gas leaks, collect the remaining refrigerant and recharge the required total amount of new refrigerant after fixing the leak.


3. Different tools required

3-1. Tool specifications have been changed due to the characteristics of R410A.


Some tools for R22- and R407C-type refrigerant systems cannot be used.

Item	New tool?	R407C tools compatible with R410A?	Remarks
Manifold gauge	Yes	No	Types of refrigerant, refrigerating machine oil, and pressure gauge are different.
Charge hose	Yes	No	To resist higher pressure, material must be changed.
Vacuum pump	Yes	Yes	Use a conventional vacuum pump if it is equipped with a check valve. If it has no check valve, purchase and attach a vacuum pump adapter.
Leak detector	Yes	No	Leak detectors for CFC and HCFC that react to chlorine do not function because R410A contains no chlorine. Leak detectors for HFC134a can be used for R410A.
Flaring oil	Yes	No	For systems that use R22, apply mineral oil (Suniso oil) to the flare nuts on the tubing to prevent refrigerant leakage. For machines that use R407C or R410A, apply synthetic oil (ether oil) to the flare nuts.

Manifold gauge



Vacuum pump




* Using tools for R22 and R407C and new tools for R410A together can cause defects.

3-2. Use R410A exclusive cylinder only.

Single-outlet valve

(with siphon tube)
Liquid refrigerant should be recharged with the cylinder standing on end as shown.



— Contents —

Section 1: OUTLINE OF 2WAY SYSTEM	1-1
1. Line-up	1-2
2. Features of 2WAY SYSTEM	1-6
3. MARKINGS FOR DIRECTIVE 97/23/EC (PED)	1-10
Section 2: DESIGN OF 2WAY SYSTEM	2-1
1. Model Selecting and Capacity Calculator	2-2
2. System Design	2-20
3. Electrical Wiring	2-26
4. Installation Instructions	2-34
5. HOW TO PROCESS TUBING	2-128
6. AIR PURGING	2-132
7. Optional Parts	2-135
8. How to select of AHU system	2-153
Section 3: Control of 2WAY SYSTEM.....	3-1
1. Main Operating Functions.....	3-4
2. Wireless Remote Controller	3-6
3. Timer Remote Controller.....	3-35
4. Simplified Remote Controller	3-54
5. System Controller	3-67
6. Schedule Timer.....	3-89
7. ON/OFF Controller (CZ-ANC2).....	3-114
8. Intelligent Controller (CZ-256ESMC2)	3-135
9. Communication Adaptor (CZ-CFUNC2)	3-196
10. Remote Sensor.....	3-204
11. LonWorks Interface (CZ-CLNC2).....	3-207
12. Seri-Para I/O unit for outdoor unit (CZ-CAPDC2)	3-222
13. MINI Seri-para I/O Unit (CZ-CAPBC2).....	3-237
14. Local Adaptor for ON/OFF Controller (CZ-CAPC2)	3-245
15. Web Interface (CZ-CWEBBC2)	3-252
16. Intelligent Management System.....	3-308
Section 4: 2WAY SYSTEM UNIT SPECIFICATIONS.....	4-1
1. Outdoor Unit.....	4-3
2. 4-Way Cassette Type (U1 Type).....	4-42
3. Low Silhouette Ducted Type (F2 Type).....	4-54
4. 4-Way Cassette Type (U1 Type).....	4-65
5. 4-Way Cassette 60×60 Type (Y1 Type).....	4-91
6. 2-Way Cassette Type (L1 Type)	4-105
7. Wall Mounted Type (K1 Type).....	4-121
8. Ceiling Type (T1 Type).....	4-142
9. Low Silhouette Ducted Type (F1 Type).....	4-159
10. High Static Pressure Ducted Type (E1 Type)	4-186
11. Floor Standing Type (P1 Type)	4-203
12. Concealed Floor Standing Type (R1 Type).....	4-218
13. 1-Way Cassette Type (D1 Type).....	4-234
14. Slim Low Static Ducted Type (M1 Type).....	4-247
15. Intaking Fresh Air of 4-Way Casstte Type and Slim Low Static Ducted Type	4-260

Section 5: TEST RUN	5-1
1. Preparing for Test Run	5-2
2. Test Run Procedure	5-3
3. Main Outdoor Unit PCB Setting	5-4
4. Auto Address Setting	5-7
5. Remote Controller Test Run Settings.....	5-13
6. Caution for Pump Down.....	5-14
7. Meaning of Alarm Messages	5-15
Section 6: ELECTRICAL DATA.....	6-1
1. Outdoor Unit.....	6-2
2. Indoor Unit	6-8
Section 7: PCB AND FUNCTIONS	7-1
1. Outdoor Unit Control PCB.....	7-2
2. Indoor Unit Control PCB Switches and Functions	7-8
Section 8: CAPACITY TABLE	8-1
1. Capacity Ratio of Outdoor Unit (Standard-COP)	8-2
2. Cooling Capacity of Indoor Unit	8-44

– MEMO –

Contents

1. OUTLINE OF 2WAY SYSTEM

1. Line-up..... 1-2















































































2. Features of 2WAY SYSTEM..... 1-6






 2-1. Outline of 2WAY SYSTEM 1-6

3. MARKINGS FOR DIRECTIVE 97/23/EC (PED)..... 1-10

1. Line-up

Indoor units



Type	22	28	36	45	56	60	73	90	106	140	160
Capacity: kW (BTU/h) Cooling Heating	2.2 (7,500) / 2.5 (8,500)	2.8 (9,600) / 3.2 (11,000)	3.6 (12,000) / 4.2 (14,000)	4.5 (15,000) / 5.0 (17,000)	5.6 (19,000) / 6.3 (21,000)	6.0 (20,500) / 7.1 (24,200)	7.3 (25,000) / 8.0 (27,000)	9.0 (30,000) / 10.0 (34,000)	10.6 (36,000) / 11.4 (39,000)	14.0 (47,800) / 16.0 (54,600)	16.0 (54,600) / 18.0 (61,500)
4-Way Cassette Type (U1 Type)	 S-22MU1E51 S-22MU1E5	 S-28MU1E51 S-28MU1E5	 S-36MU1E51 S-36MU1E5	 S-45MU1E51 S-45MU1E5	 S-56MU1E51 S-56MU1E5	 S-60MU1E51	 S-73MU1E51 S-73MU1E5	 S-90MU1E51	 S-106MU1E51 S-106MU1E5	 S-140MU1E51 S-140MU1E5	 S-160MU1E51 S-160MU1E5
4-Way Cassette 60×60 Type (Y1 Type)	 S-22MY1E5	 S-28MY1E5	 S-36MY1E5	 S-45MY1E5	 S-56MY1E5						
2-Way Cassette Type (L1 Type)	 S-22ML1E5	 S-28ML1E5	 S-36ML1E5	 S-45ML1E5	 S-56ML1E5		 S-73ML1E5				
Wall Mounted Type (K1 Type)	 S-22MK1E5	 S-28MK1E5	 S-36MK1E5	 S-45MK1E5	 S-56MK1E5		 S-73MK1E5		 S-106MK1E5		
Ceiling Type (T1 Type)			 S-36MT1E5	 S-45MT1E5	 S-56MT1E5		 S-73MT1E5		 S-106MT1E5	 S-140MT1E5	
1-Way Cassette Type (D1 Type)		 S-28MD1E5	 S-36MD1E5	 S-45MD1E5	 S-56MD1E5		 S-73MD1E5				
Low Silhouette Ducted Type (F1 Type)	 S-22MF1E5	 S-28MF1E5	 S-36MF1E5	 S-45MF1E5	 S-56MF1E5		 S-73MF1E5	 S-90MF1E5	 S-106MF1E5	 S-140MF1E5	 S-160MF1E5
Low Silhouette Ducted Type (F2 Type)	 S-22MF2E5	 S-28MF2E5	 S-36MF2E5	 S-45MF2E5	 S-56MF2E5	 S-60MF2E5	 S-73MF2E5	 S-90MF2E5	 S-106MF2E5	 S-140MF2E5	 S-160MF2E5
Slim Low Static Ducted Type (M1 Type)	 S-22MM1E5	 S-28MM1E5	 S-36MM1E5	 S-45MM1E5	 S-56MM1E5						
Floor Standing Type (P1 Type)	 S-22MP1E5	 S-28MP1E5	 S-36MP1E5	 S-45MP1E5	 S-56MP1E5		 S-71MP1E5				
Concealed Floor Standing Type (R1 Type)	 S-22MR1E5	 S-28MR1E5	 S-36MR1E5	 S-45MR1E5	 S-56MR1E5		 S-71MR1E5				

Type	73	106	140	224	280
High Static Pressure Ducted Type (E1 Type)	 S-73ME1E5	 S-106ME1E5	 S-140ME1E5	 S-224ME1E5	 S-280ME1E5

1. Line-up

Outdoor units

Model	U-18ME1E81	U-20ME1E81
Capacity: kW (BTU/h) Cooling / Heating	50.0 (170,600) / 56.0 (191,100)	56.0 (191,100) / 63.0 (215,000)




◆ Installation fixing bracket
Installation side

- According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from "A", "B" or "C".
A : 894 (Installation hole pitch) * The tubing is routed out from the front.
B : 730 (Installation hole pitch) * The tubing is routed out from the bottom.
C : 730 (Installation hole pitch)

2. Features of 2WAY SYSTEM

2-1. Outline of 2WAY SYSTEM

■ System example



■ System limitations

Maximum number of combined outdoor units	3 *2
Maximum horsepower of combined outdoor units	168kW (60 HP)
Maximum number of connectable indoor units	64 *1
Indoor/outdoor unit capacity ratio	50~200% *3
Maximum actual piping length	180 m
Maximum level difference (when outdoor unit is lower)	50 (40) m
Maximum total piping length	1000 m

*1: In the case of 22 hp (type 61.5 kW) or smaller units, the number is limited by the total capacity of the connected indoor units.

*2: Up to 3 units can be connected if the system has been extended.

*3: It is strongly recommended that you choose the unit so the load can become between 50 and 130%.

* If the additional installment of outdoor and indoor units are expected, the size of refrigerant piping should be decided according to the total capacity after the addition.

2. Features of 2WAY SYSTEM

■ Combination of outdoor units (Standard-COP mode)

Total horse power Type (hp)	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46	48	50	52	54	56	58	60
8	1							1																			
10		1							1																		
12			1							1	1							1	1								
14				1				1	1	1		1						1		1							
16					1						1	1	2	1	1			1	2	2	3	2	2	1			
18						1								1		1						1		1	2	1	
20							1								1	1	2						1	1	1	2	3

■ Combination of outdoor units (High-COP mode)

- Setting the Dip switch (SW8) on the outdoor unit PCB to "ON" activates as the high-COP mode.
- When operating in the high-COP mode, the outdoor unit capacity decreases against the standard COP mode.
See the following table and select the most suitable unit for the air conditioning load.

Total system horsepower (kW)	Combined outdoor units		
8HP (22.4)	—	—	—
10HP (28.0)	U-14ME1E81	—	—
12HP (33.5)	U-16ME1E81	—	—
14HP (40.0)	U-18ME1E81	—	—
16HP (45.0)	U-20ME1E81	—	—
18HP (50.0)	U-14ME1E81	U-8ME1E81	—
20HP (56.0)	U-16ME1E81	U-8ME1E81	—
22HP (61.5)	U-18ME1E81	U-8ME1E81	—
24HP (68.0)	U-16ME1E81	U-16ME1E81	—
26HP (73.0)	U-18ME1E81	U-16ME1E81	—
28HP (78.5)	U-20ME1E81	U-16ME1E81	—
30HP (85.0)	U-20ME1E81	U-18ME1E81	—
32HP (90.0)	U-20ME1E81	U-20ME1E81	—
34HP (96.0)	U-18ME1E81	U-16ME1E81	U-8ME1E81
36HP (101.0)	U-16ME1E81	U-16ME1E81	U-16ME1E81
38HP (107.0)	U-18ME1E81	U-16ME1E81	U-16ME1E81
40HP (113.0)	U-20ME1E81	U-16ME1E81	U-16ME1E81
42HP (118.0)	U-20ME1E81	U-18ME1E81	U-16ME1E81
44HP (124.0)	U-20ME1E81	U-18ME1E81	U-18ME1E81
46HP (130.0)	U-20ME1E81	U-20ME1E81	U-18ME1E81
48HP (135.0)	U-20ME1E81	U-20ME1E81	U-20ME1E81

* Be sure that the total load of indoor unit (load when operating the maximum number of units) should not exceed 130% of the outdoor unit capacity.

2. Features of 2WAY SYSTEM

■ Setting procedure for using High-COP mode


- (1) Turn off all outdoor units.
- (2) Set the DIP switch (SW8) to "ON" on all main outdoor units PCB for setting the high-COP mode.
If multiple outdoor units are connected to a system, perform the same step on each of the outdoor units. In the case of combination with the 8HP (U-8ME1E81), do set in a similar manner noted above.
If one of the outdoor units is not set in the "ON" position, the alarm message indicates "L17".

- (3) Switch on the outdoor unit.


Now the setting is over.

Paste the label of "HIGH COP MODE" on the outdoor unit set in the high-COP mode.

The purpose of this notice is to inform that the unit is in the high-COP mode before maintenance is performed.



Unit: mm



NOTE

- It may sometimes happen that the power consumption increases to that in the standard COP mode temporarily due to the maintenance drive of the outdoor unit although the high-COP mode has been set. The electrical capacitance (electrical wire length, diameter, breaker capacity and electrical capacitance for the building) should be in the same manner of the standard COP mode.
- Be sure that the total load of indoor units (load when operating the maximum number of units) should not exceed 130% of outdoor unit capacity. The limitation of the indoor-outdoor capacity ratio is 200% against the outdoor capacity in the high-COP mode.
- Select the tube length and size equivalent to the content described on pages 9 and 10 in the installation instructions. Be sure to read the total capacity of outdoor units as that in the high-COP mode.
- Select the optional distribution joints suited to the capacity.
However, when you used the tube diameter for the standard COP mode between the outdoor unit and the first distribution joint in a system to which more than two outdoor units are connected, select joint suited to the capacity in the standard COP mode.
- The additional refrigerant charge should be calculated according to the liquid tubing size.
- The installation space is equivalent to that of the standard COP mode.
- The shield for horizontal exhaust and wind ducting are equivalent to that of the standard COP mode.

2. Features of 2WAY SYSTEM

Capacity control

The compressor combination (DC inverter compressor + constant-speed compressor) allows smooth capacity control from 0.8 HP to 60 HP.

Realization of smooth capacity control from 0.8HP to 60HP



Capacity control is possible smoothly with a DC inverter compressor.

The graph shown in the below is the image of the operating combination of compressors in case of 60HP system.

In actual operation, the combination will be changed by operating condition, operating time amount, priority of compressor and so on.

Comp. HP	Unit 1 (main)	Unit 2 (sub 1)	Unit 3 (sub 2)
INV comp.	10	10	10
AC1 comp.	6	6	6
AC2 comp.	6	6	6

* 60HP = U-20ME1E81 x 3





Contents

2. DESIGN OF 2WAY SYSTEM

1. Model Selecting and Capacity Calculator	2-2
1-1. Operating Range	2-2
1-2. Procedure for Selecting Models and Calculating Capacity	2-3
1-3. Tubing Length	2-4
1-4. Tubing Size	2-7
1-5. Straight Equivalent Length of Joints	2-11
1-6. Check of Limit Density	2-12
1-7. Calculation of Actual Capacity of Indoor Unit	2-13
1-8. Capacity Correction Graph According to Tubing Length and Elevation Difference	2-18
2. System Design	2-20
2-1. System Example	2-20
2-2. Example of Tubing Size Selection for Extension and Additional Charge Amount	2-22
3. Electrical Wiring	2-26
3-1. General Precautions on Wiring	2-26
3-2. Recommended Wire Length and Wire Diameter for Power Supply System	2-26
3-3. Wiring System Diagrams	2-27
4. Installation Instructions	2-34
■ Outdoor Unit	2-34
4-1. Selecting the Installation Site for Outdoor Unit	2-34
4-2. Shield for Horizontal Exhaust Discharge	2-36
4-3. Installing the Outdoor Unit in Heavy Snow Areas	2-36
4-4. Precautions When Installing in Heavy Snow Areas	2-36
4-5. Dimensions of Wind Ducting	2-37
4-6. Dimensions of Snow Ducting	2-44
4-7. Transporting the Outdoor Unit	2-51
4-8. Installing the Outdoor Unit	2-52
4-9. Routing the Tubing	2-55
4-10. Prepare the Tubing	2-56
4-11. Connect the Tubing	2-57
■ Indoor Unit	2-61
4-12. Selecting the Installation Site for Indoor Unit	2-61
4-13. How to install the indoor unit	2-62
5. HOW TO PROCESS TUBING	2-128
5-1. Connecting the Refrigerant Tubing	2-128
5-2. Connecting Tubing Between Indoor and Outdoor Units	2-129
5-3. Insulating the Refrigerant Tubing	2-129
5-4. Taping the Tubes	2-131
5-5. Finishing the Installation	2-131
6. AIR PURGING	2-132
■ Air Purging with a Vacuum Pump (for Test Run) Preparation	2-132
7. Optional Parts	2-135
7-1. Distribution Joint Kits (CZ-P160BK2, P680BK2, P1350BK2, P680PJ2, P1350PJ2, P4HPC2, P4HP2C2, P4HP1C2)	2-135
7-2. RAP Valve Kit (CZ-P160RVK2)	2-141
7-3. External Electronic Expansion Valve Kit for Indoor Unit (CZ-P56SVK2, P160SVK2)	2-144
7-4. Filter Chamber for Indoor Unit (CZ-FDU2)	2-147
7-5. Air Intake Kit for Chamber (CZ-ATU2)	2-148
7-6. Air Intake Kit for Unit (CZ-BCU2)	2-149
7-7. Air Cut Insulation (CZ-CFU2)	2-150
8. How to select of AHU system	2-153

1. Model Selecting and Capacity Calculator

1-1. Operating Range




1. Model Selecting and Capacity Calculator

1-2. Procedure for Selecting Models and Calculating Capacity

■ Model Selection Procedure

Select the model and calculate the capacity for each refrigerant system according to the procedure shown below.




1. Model Selecting and Capacity Calculator

1-3. Tubing Length

Select the installation location so that the length and size of refrigerant tubing are within the allowable range shown in the figure below.

1. — Main tubing length $LM = LA + LB \dots$
2. — Main distribution tubes $LC - LH$ are selected according to the capacity after the distribution joint.
3. The outdoor connection main tubing (LO portion) is determined by the total capacity of the outdoor units that are connected to the tube ends.
4. — Sizes of indoor unit connection tubing $\ell 1 - \ell 64$ are determined by the connection tubing sizes on the indoor units.



Note: Do not use commercially available T-joints for the liquid tubing and parts.

* Be sure to use special R410A distribution joints (purchased separately) for outdoor unit connections and tubing branches.

Table 2-1 Ranges that Apply to Refrigerant Tubing Lengths and to Differences in Installation Heights

Item	Mark	Contents	Length (m)
Allowable tubing length	L1	Max. tubing length	Actual length ≤ 180
			Equivalent length ≤ 200
	$\Delta L (L2 - L4)$	Difference between max. length and min. length from the No.1 distribution joint	$\leq 50^{*5}$
	LM	Max. length of main tubing (at max. diameter)	*3
	$\ell 1, \ell 2 \dots \ell 64$	Max. length of each distribution tube	≤ 30
	$L1 + \ell 1 + \ell 2 \dots \ell 63 + \ell A + \ell B + \ell F + \ell G + \ell H$	Total max. tubing length including length of each distribution tube (only liquid tubing)	≤ 1000
Allowable elevation difference	H1	When outdoor unit is installed higher than indoor unit	≤ 50
		When outdoor unit is installed lower than indoor unit	≤ 40
	H2	Max. difference between indoor units	$\leq 15^{*6}$
	H3	Max. difference between outdoor units	≤ 4
Allowable length of joint tubing	L3	T-joint tubing (field-supply); Max. tubing length between the first T-joint and solidly welded-shut end point	≤ 2

L = Length, H = Height

NOTE

- 1: The outdoor connection main tubing (LO portion) is determined by the total capacity of the outdoor units that are connected to the tube ends.
- 2: If the longest tubing length (L1) exceeds 90 m (equivalent length), increase the sizes of the main tubes (LM) by 1 rank for gas tubes and liquid tubes. (Use a field supply reducer.) (Select the tube size from the table of main tube sizes (Table 2-5) on the following page (LA table), and from the table of refrigerant tubing sizes (Table 2-7) on the second following page.)
- 3: If the longest main tube length (LM) exceeds 50 m, increase the main tube size at the portion before 50 m by 1 rank for the gas tubes. (Use a field supply reducer.) Determine the length less than the limitation of allowable maximum tubing length. (For the portion that exceeds 50 m, set based on the main tube sizes (LA) listed in the table on the following page.)

4: If the size of the existing tubing is already larger than the standard tubing size, it is not necessary to further increase the size.

* If the existing tubing is used and the amount of on-site refrigerant charge exceeds the value listed below, change the size of the tubing to reduce the amount of refrigerant.

- 5: 1) Calculate the ΔL ($L2(L2', L2'' \dots) - L4$) of each combined indoor unit from the first distribution joint.
The $L2(L2', L2'' \dots)$ indicates the pipe length connected to the farthest indoor unit among each combined indoor unit from the first distribution joint. The $L4$ indicates the pipe length connected to the nearest indoor unit among all connected indoor units to the system. It is necessary to calculate the ΔL of each combined indoor unit.
- 2) If the calculated ΔL exceeds 40m, increase by one size of both the liquid and gas tubes.
The length of pipe needed to increase by one size becomes different according to the total cooling capacity of combined indoor unit which the ΔL exceeds 40m.
Calculate the total cooling capacity of combined indoor units which the ΔL exceeds 40m.
Then apply to a certain pipe length from the first distribution listed below.
Be sure to use the reducer (field supply) at joint portion between the original pipe and the pipe increased by one size.
If there is the necessity to increase by one size, do not increase the pipe (LB or LF) any more when the pipe LB or pipe LF part is overlapped. There can be only one time effective to increase by one size from original pipe size.
The total cooling capacity after distribution for each combined indoor unit is less than 22.4kW: 12m
The total cooling capacity after distribution for each combined indoor unit is over 22.4kW and less than 52.4kW: 20m
The total cooling capacity after distribution for each combined indoor unit is over 52.4kW: 28m

The 2nd distribution joint to 5m, liquid tube $\phi 12.7$, gas tube $\phi 25.4$. Then, the remainder is 2m, liquid tube $\phi 9.52$, gas tube $\phi 22.22$.

2-5

1. Model Selecting and Capacity Calculator

Additional Refrigerant Charge

Additional refrigerant charge amount is calculated below.

Required amount of additional refrigerant charge

$$= [(\text{Amount of additional refrigerant charge per meter of each size of liquid tube} \times \text{its tube length}) + (\dots) + (\dots)]$$

$$+ [(\text{Necessary amount of additional refrigerant charge per outdoor unit} + (\dots) + (\dots))]$$

* Always charge accurately using a scale for weighing.

* If the existing tubing is used and the amount of on-site additional refrigerant charge exceeds the value listed below, change the size of the tubing to reduce the amount of refrigerant.

	with 1 outdoor unit	with 2 outdoor unit	with 3 outdoor unit
Total amount of refrigerant for the system	50 kg	80 kg	100 kg

Table 2-2-1 Amount of Additional Refrigerant Charge Per Meter, According to Liquid Tubing Size

Liquid tubing size	6.35	9.52	12.7	15.88	19.05	22.22	25.4
Amount of additional refrigerant charge/m (g/m)	26	56	128	185	259	366	490

Table 2-2-2 Necessary Amount of Additional Refrigerant Charge Per Outdoor Unit

U-8ME1E81	U-10ME1E81	U-12ME1E81	U-14ME1E81	U-16ME1E81	U-18ME1E81	U-20ME1E81
5.9 kg	6.6 kg	6.6 kg	7.8 kg	7.8 kg	8.5 kg	8.5 kg

Table 2-3 Refrigerant Charge Amount at Shipment (for Outdoor Unit)

U-8ME1E81	U-10ME1E81	U-12ME1E81	U-14ME1E81	U-16ME1E81	U-18ME1E81	U-20ME1E81
6.5 kg	6.8 kg	6.8 kg	8.5 kg	8.5 kg	9.0 kg	9.0 kg

Table 2-4 System Limitations

Max. No. allowable connected outdoor units	3 * 2
Max. capacity allowable connected outdoor units	168 kW (60 hp)
Max. connectable indoor units	64 * 1
Max. allowable indoor/outdoor capacity ratio	50 – 200 % * 3

*1: In the case of 22 hp (type 61.5 kW) or smaller units, the number is limited by the total capacity of the connected indoor units.

*2: Up to 3 units can be connected if the system has been extended.

*3: It is strongly recommended that you choose the unit so the maximum operation load can become between 50 and 130%.

1. Model Selecting and Capacity Calculator

1-4. Tubing Size

Table 2-5-1 Main Tubing Size (LA) (Standard-COP mode)

Total system horsepower (kW)	Combined outdoor units			Liquid tubing (mm)	Gas tubing (mm)
8 hp (22.4)	U-8ME1E81	—	—	ø9.52	ø19.05
10 hp (28.0)	U-10ME1E81	—	—	ø9.52	ø22.22
12 hp (33.5)	U-12ME1E81	—	—	ø12.7	ø25.4
14 hp (40.0)	U-14ME1E81	—	—	ø12.7	ø25.4
16 hp (45.0)	U-16ME1E81	—	—	ø12.7	ø28.58
18 hp (50.0)	U-18ME1E81	—	—	ø15.88	ø28.58
20 hp (56.0)	U-20ME1E81	—	—	ø15.88	ø28.58
22 hp (61.5)	U-14ME1E81	U-8ME1E81	—	ø15.88	ø28.58
24 hp (68.0)	U-14ME1E81	U-10ME1E81	—	ø15.88	ø28.58
26 hp (73.0)	U-14ME1E81	U-12ME1E81	—	ø19.05	ø31.75
28 hp (78.5)	U-16ME1E81	U-12ME1E81	—	ø19.05	ø31.75
30 hp (85.0)	U-16ME1E81	U-14ME1E81	—	ø19.05	ø31.75
32 hp (90.0)	U-16ME1E81	U-16ME1E81	—	ø19.05	ø31.75
34 hp (96.0)	U-18ME1E81	U-16ME1E81	—	ø19.05	ø31.75
36 hp (101.0)	U-20ME1E81	U-16ME1E81	—	ø19.05	ø38.1
38 hp (107.0)	U-20ME1E81	U-18ME1E81	—	ø19.05	ø38.1
40 hp (113.0)	U-20ME1E81	U-20ME1E81	—	ø19.05	ø38.1
42 hp (118.0)	U-16ME1E81	U-14ME1E81	U-12ME1E81	ø19.05	ø38.1
44 hp (124.0)	U-16ME1E81	U-16ME1E81	U-12ME1E81	ø19.05	ø38.1
46 hp (130.0)	U-16ME1E81	U-16ME1E81	U-14ME1E81	ø19.05	ø38.1
48 hp (135.0)	U-16ME1E81	U-16ME1E81	U-16ME1E81	ø19.05	ø38.1
50 hp (140.0)	U-18ME1E81	U-16ME1E81	U-16ME1E81	ø19.05	ø38.1
52 hp (145.0)	U-20ME1E81	U-16ME1E81	U-16ME1E81	ø19.05	ø38.1
54 hp (151.0)	U-20ME1E81	U-18ME1E81	U-16ME1E81	ø19.05	ø38.1
56 hp (156.0)	U-20ME1E81	U-18ME1E81	U-18ME1E81	ø19.05	ø38.1
58 hp (162.0)	U-20ME1E81	U-20ME1E81	U-18ME1E81	ø19.05	ø38.1
60 hp (168.0)	U-20ME1E81	U-20ME1E81	U-20ME1E81	ø19.05	ø38.1

*1: If future extension is planned, select the tubing diameter based on the total horsepower after extension.

However extension is not possible if the resulting tubing size is two ranks higher.

*2: The balance tube (outdoor unit tube) diameter is ø6.35.

*3: The refrigerant tubing should be used with R410A refrigerant.

*4: If the length of the longest tube (L1) exceeds 90 m (equivalent length), increase the main tube (LM) size by 1 rank for the gas and liquid tubes. (Use field-supply reducers.) (Select from Table 2-5-1 and Table 2-9.)

*5: If the longest main tube length (LM) exceeds 50 m, increase the main tube size at the portion before 50 m by 1 rank for the gas tubes.

(For the portion that exceeds 50 m, set based on the main tube sizes (LA) listed in the table above.)

1. Model Selecting and Capacity Calculator

1-4. Tubing Size (continued)

High-COP mode

Setting the DIP switch (S011) on the outdoor unit PCB to "ON" activates the high-COP mode.

* Hereafter, the DIP switch (S011) "ON" is defined as the high-COP mode and "OFF" is defined as the standard COP mode.

Outdoor unit capacity and tubing diameter during high-COP mode

When operating in the high-COP mode, the outdoor unit capacity decreases against the standard COP mode.

Referring to the following table, select the most suitable unit and main pipe diameter for the air conditioning load.

Table 2-5-2 Main Tubing Size (LA) (High-COP mode)

Total system horsepower (kW)	Combined outdoor units			Liquid tubing (mm)	Gas tubing (mm)
8 hp (22.4)		—	—	—	—
10 hp (28.0)	U-14ME1E81	—	—	ø9.52	ø22.22
12 hp (33.5)	U-16ME1E81	—	—	ø12.7	ø25.4
14 hp (40.0)	U-18ME1E81	—	—	ø12.7	ø25.4
16 hp (45.0)	U-20ME1E81	—	—	ø12.7	ø28.58
18 hp (50.0)	U-14ME1E81	U-8ME1E81	—	ø15.88	ø28.58
20 hp (56.0)	U-16ME1E81	U-8ME1E81	—	ø15.88	ø28.58
22 hp (61.5)	U-18ME1E81	U-8ME1E81	—	ø15.88	ø28.58
24 hp (68.0)	U-16ME1E81	U-16ME1E81	—	ø15.88	ø28.58
26 hp (73.0)	U-18ME1E81	U-16ME1E81	—	ø19.05	ø31.75
28 hp (78.5)	U-20ME1E81	U-16ME1E81	—	ø19.05	ø31.75
30 hp (85.0)	U-20ME1E81	U-18ME1E81	—	ø19.05	ø31.75
32 hp (90.0)	U-20ME1E81	U-20ME1E81	—	ø19.05	ø31.75
34 hp (96.0)	U-18ME1E81	U-16ME1E81	U-8ME1E81	ø19.05	ø31.75
36 hp (101.0)	U-16ME1E81	U-16ME1E81	U-16ME1E81	ø19.05	ø38.1
38 hp (107.0)	U-18ME1E81	U-16ME1E81	U-16ME1E81	ø19.05	ø38.1
40 hp (113.0)	U-20ME1E81	U-16ME1E81	U-16ME1E81	ø19.05	ø38.1
42 hp (118.0)	U-20ME1E81	U-18ME1E81	U-16ME1E81	ø19.05	ø38.1
44 hp (124.0)	U-20ME1E81	U-18ME1E81	U-18ME1E81	ø19.05	ø38.1
46 hp (130.0)	U-20ME1E81	U-20ME1E81	U-18ME1E81	ø19.05	ø38.1
48 hp (135.0)	U-20ME1E81	U-20ME1E81	U-20ME1E81	ø19.05	ø38.1

* Be sure that the total load of indoor units (load when operating the maximum number of units) should not exceed 130% of the outdoor unit capacity.

Tube diameter of each outdoor unit

When connecting the tube to the outdoor unit in the high-COP mode, you may need to use smaller diameter tubes.

So, it is necessary to provide the reducer for the connection. Supply the reducer in the field.


For the system to which more than two outdoor units are connected, you can use the tube diameter of the standard COP mode between the outdoor unit and the first distribution joint (inside the dotted lines of Fig. 2-1).

* Beyond the first distribution joint (outside the dotted lines of Fig. 2-1), be sure to select the tube diameter according to the outdoor unit capacity in the high-COP mode.

* The balance tube diameter is 6.35 mm in every unit.

1. Model Selecting and Capacity Calculator

Tube diameter of each outdoor unit (Continued)



Select the diameter of these tubes according to the outdoor unit capacity in the high-COP mode.

Fig. 2-1

Table 2-5-3

Unit : mm

Standard COP mode	Capacity	14 hp	16 hp	18 hp	20 hp
	Gas tubing	ø25.4	ø28.58	ø28.58	ø28.58
	Liquid tubing	ø12.7	ø12.7	ø15.88	ø15.88

Table 2-5-4


High-COP mode	Capacity	10 hp	12 hp	14 hp	16 hp
	Gas tubing	ø22.22	ø25.4	ø25.4	ø28.58
	Liquid tubing	ø9.52	ø12.7	ø12.7	ø12.7

Gas valve diameter of outdoor unit	ø25.4	ø25.4	ø28.58	ø28.58
Liquid valve diameter of outdoor unit	ø12.7	ø12.7	ø15.88	ø15.88

* Only for the system to which more than two outdoor units are connected, you can use the tube diameter for the standard COP mode up to the first distribution joint.

Example : When the capacity is 10 hp in the high-COP mode

- You need to use reducers (field supplied) to connect the 22.22 mm diameter tube (Table 2-5-4) to the 25.4 mm diameter gas valve (Table 2-5-3). However, only for the system to which more than two outdoor units are connected, you can use 25.4 mm diameter tubes without using any reducers.
- You need to use reducers (field supplied) to connect the 9.52 mm diameter tube (Table 2-5-4) to the 12.7 mm diameter liquid valve (Table 2-5-3). However, only for the system to which more than two outdoor units are connected, you can use 12.7 mm diameter tubes without using any reducers.



1. Model Selecting and Capacity Calculator

■ Size of tubing (LO) between outdoor units

Select the size of tubing between outdoor units based on the main tubing size (LA) as given in the tables under the section of 2-5-1 Main Tubing Size (LA)(Standard-COP mode) and 2-5-2 Main Tubing Size (LA)(High-COP mode).

Table 2-6 Main Tubing Size After Distribution (LB, LC...)

Unit: mm
hp = horsepower

Total capacity after distribution	Below kW	7.1 (2.5 hp)	16.0 (6 hp)	22.5 (8.1 hp)	30.0 (11 hp)	42.0 (15 hp)	52.4 (19 hp)	70.0 (25 hp)	98.0 (35 hp)	—
	Over kW	—	7.1 (2.5 hp)	16.0 (6 hp)	22.5 (8.1 hp)	30.0 (11 hp)	42.0 (15 hp)	52.4 (19 hp)	70.0 (25 hp)	98.0 (35 hp)
Tubing size	Gas tubing (mm)	ø12.7	ø15.88	ø19.05	ø22.22	ø25.4	ø28.58	ø28.58	ø31.75	ø38.1
	Liquid tubing (mm)	ø9.52	ø9.52	ø9.52	ø9.52	ø12.7	ø12.7	ø15.88	ø19.05	ø19.05

NOTE In case the total capacity of connected indoor units exceeds the total capacity of the outdoor units, select the main tubing size for the total capacity of the outdoor units. (Especially the main tubing segments of LA, LB and LF.)

Table 2-7 Outdoor Unit Tubing Connection Size(øA – øC)

Unit: mm

							Unit: mm
kW	22.4	28.0	33.5	40.0	45.0	50.0	56.0
Gas tubing	ø19.05	ø22.22	ø25.4		ø28.58		
	Braze connection						
Liquid tubing	ø9.52		ø12.7			ø15.88	
	Flare connection						
Balance tubing	ø6.35						
	Flare connection						




Table 2-8 Indoor Unit Tubing Connection Size

Indoor unit type	22	28	36	45	56	73	90	106	140	160	224	280
Gas tubing (mm)	ø12.7					ø15.88					ø19.05	ø22.22
Liquid tubing (mm)	ø6.35					ø9.52						

Note: Use C1220T-1/2H or -H material for tubing over ø22.22.

Table 2-9 Refrigerant tubing (Existing tubing can be used.)

Tubing size (mm)			
Material O		Material 1/2H-H	
ø6.35	t 0.8	ø22.22	t 1.0
ø9.52	t 0.8	ø25.40	t 1.0
ø12.7	t 0.8	ø28.58	t 1.0
ø15.88	t 1.0	ø31.75	t 1.1
ø19.05	t 1.2	ø38.10	over t 1.35
		ø41.28	over t 1.45

* When bending the tubes, use a bending radius that is at least 4 times the outer diameter of the tubes. In addition, take sufficient care to avoid crushing or damaging the tubes when bending them.






1. Model Selecting and Capacity Calculator

■ Straight equivalent length of joints

1-5. Straight Equivalent Length of Joints


Design the tubing system by referring to the following table for the straight equivalent length of joints.

Straight Equivalent Length of Joints

Wide tubing size (mm)		12.7	15.88	19.05	22.22	25.4	28.58	31.75	38.1
90° elbow		0.3	0.35	0.42	0.48	0.52	0.57	0.7	0.79
45° elbow		0.23	0.26	0.32	0.36	0.39	0.43	0.53	0.59
U-shape tube bent (R60 - 100 mm)		0.9	1.05	1.26	1.44	1.56	1.71	2.1	2.37
Trap bend		2.3	2.8	3.2	3.8	4.3	4.7	5.0	5.8
Y-branch distribution joint		Equivalent length conversion not needed.							
Ball valve for service		Equivalent length conversion not needed.							

● Capacity loss caused by differences in tubing diameters

- * Capacity loss will occur if a tubing system that matches the horsepower is not selected (for example, if a tubing system was determined and installed with no plan for extension and extension occurs later). The loss rate can be found from the graph below.



(Reading the graph)

<Example 1>

Currently a 20 HP system and ϕ 28.58 Gas tubings are used. Subsequently the system is expanded, with 8 HP added to the same tubing system.

- Horsepower after extension: $20 + 8 = 28$ HP
- From the graph above: Cooling: Capacity ratio is 96.7%. Actual capacity = $28 \times 0.967 = 27.1$ HP
Heating: Capacity ratio is 98.6%. Actual capacity = $28 \times 0.986 = 27.6$ HP

1. Model Selecting and Capacity Calculator

■ Additional refrigerant charge amount

Additional refrigerant charge amount is calculated below.

Required amount of additional refrigerant charge
 = [(Amount of additional refrigerant charge per meter of each size of liquid tube x its tube length) + (...) + (...)]
 + [(Necessary amount of additional refrigerant charge per outdoor unit + (...) + (...)]

* Always charge accurately using a scale for weighing.

* If the existing tubing is used and the amount of on-site refrigerant charge exceeds the value listed below, change the size of the tubing to reduce the amount of refrigerant.

Total amount of refrigerant for the system with 1 outdoor unit : 50 kg

Total amount of refrigerant for the system with 2 outdoor units : 80 kg

Total amount of refrigerant for the system with 3 outdoor units : 100 kg

Amount of Additional Refrigerant Charge Per Meter, According to Liquid Tubing Size

Liquid tubing size	6.35	9.52	12.7	15.88	19.05	22.22	25.4
Amount of additional refrigerant charge/m (g/m)	26	56	128	185	259	366	490

2

■ Check of limit density



WARNING

Always check the gas density limit for the room in which the unit is installed.

1-6. Check of Limit Density

When installing an air conditioner in a room, it is necessary to ensure that if the refrigerant gas accidentally leaks out, its density does not exceed the limit level for that room. If the density could exceed the limit level, it is necessary to provide an opening between the unit and the adjacent room, or to install mechanical ventilation which is interlocked with the leak detector.

Overall refrigerant charge amount for the air conditioner : kg


(Minimum room volume for indoor unit: m³)

≤ **Limit density 0.3 (kg/m³)**

The limit density of refrigerant which is used in this unit is 0.3 kg/m³ (ISO 5149).

The shipped outdoor unit comes charged with the amount of refrigerant fixed for each type, so add it to the amount that is charged in the field. (For the refrigerant charge amount at shipment, refer to the unit's nameplate.)

Minimum indoor volume and floor area as against the amount of refrigerant is roughly as given in the following table.



CAUTION

Pay special attention to any location, such as a basement, etc., where leaking refrigerant can accumulate, since refrigerant gas is heavier than air.

1. Model Selecting and Capacity Calculator

1-7. Calculation of Actual Capacity of Indoor Unit

■ Calculating the actual capacity of each indoor unit

Because the capacity of a multi air-conditioner changes according to the temperature conditions, tubing length, elevation difference and other factors, select the correct model after taking into account the various correction values.

When selecting the model, calculate the corrected capacities of the outdoor unit and each indoor unit.

Use the corrected outdoor unit capacity and the total corrected capacity of all the indoor units to calculate the actual final capacity of each indoor unit.

1. Outdoor unit capacity correction

$$\text{Outdoor unit capacity correction (kW)} = \text{Rated capacity} \times (A) \times (B) \times (C) \times (D)$$

(A) Capacity correction for the outdoor unit temperature conditions (%)

Read the capacity correction for outdoor unit temperature, indoor unit temperature and indoor/ outdoor ratio as shown in the section "8. CAPACITY TABLE".

* Indoor unit temperature is indoor unit rated capacity - weighted average temperature.

Example

Cooling operation

No.	(a) Rated capacity	(b) Intake temperature	(a) × (b)
1	2.8 kW	19 WB	53.2
2	3.6 kW	18 WB	64.8
3	4.5 kW	17 WB	76.5
4	5.6 kW	16 WB	89.6

$$\text{Rated capacity-weighted average temperature} = \frac{\sum((a) \times (b))}{\sum(a)} = 17.2\text{WB}$$

* The indoor/ outdoor ratio should be selected according to the real rated capacity.

Example

There are 4 indoor units for class 28, 36, 45, 56 and the outdoor unit HP is 8 (22.4kW in the cooling-mode, 25.0kW in the heating-mode).

No.	Rated cooling capacity	Rated heating capacity
1	2.8 kW	3.2 kW
2	3.6 kW	4.2 kW
3	4.5 kW	5.0 kW
4	5.6 kW	6.3 kW
Total	16.5 kW	18.7 kW
I/O ratio	73.7%	74.8 %

(B) Capacity correction coefficient for outdoor unit tubing length (%)

From the graph of capacity change characteristics resulting from tubing length and elevation difference on page "2-16", read the capacity correction coefficient.

* Use the lowest capacity changing ratio. Usually, the furthest and highest or the lowest indoor unit is used.

(C) Surplus capacity correction coefficient for outdoor unit temperature conditions (%)

From the graph of surplus capacity characteristics resulting from outdoor temperature on page "2-15", read the capacity correction coefficient.

(D) Capacity correction coefficient for outdoor unit frosting and defrosting during heating operation (%)

From the outdoor unit heating capacity correction coefficient during frosting / defrosting on page "2-15", read the capacity correction coefficient.

1. Model Selecting and Capacity Calculator

2. Indoor unit capacity correction coefficient

$$\text{Indoor unit capacity correction (kW)} = (G) \times (H) \times (C) \times (D)$$

$$* \text{ Indoor unit capacity correction} \leq (G)$$

(E) Capacity correction for the indoor unit temperature conditions (kW)

From the graph of indoor capacity characteristics on page “ 2-16 ”, read the capacity correction coefficient for indoor unit temperature conditions.

$$(E) = \text{Capacity correction coefficient for indoor unit temperature conditions} \times \text{Rated capacity}$$

(F) Calculate the Capacity distribution ratio (%)

$$(F) = \frac{(E)}{\sum(E)}$$

(G) Distribute the outdoor unit capacity among each indoor unit (kW)


$$(G) = (A) \times (F)$$

(H) Capacity correction coefficient for tubing length and elevation difference (%)

From the graph of capacity change characteristics resulting from tubing length and elevation difference on page “ 2-16 ”, read the capacity correction coefficient.

1. Model Selecting and Capacity Calculator

Surplus capacity correction coefficient (%)



5. Graph of capacity correction coefficients

■ Outdoor unit heating capacity correction coefficient during frosting/defrosting (1 – (4))

Outdoor intake air temp. (°CWB, RH85%)	-25	-24	-23	-22	-21	-20	-15	-10	-8	-6	-5	-4	-2	-1
Correction coefficient	0.97	0.97	0.97	0.97	0.97	0.97	0.97	0.97	0.96	0.94	0.91	0.89	0.87	0.87


Outdoor intake air temp. (°CWB, RH85%)	0	1	2	3	4	5	6
Correction coefficient	0.87	0.88	0.89	0.91	0.92	0.95	1.0

* To calculate the heating capacity with consideration for frosting/defrosting operation, multiply the heating capacity found from the capacity graph by the correction coefficient from the table above.


1. Model Selecting and Capacity Calculator

■ Graph of indoor unit capacity characteristics (2 – (2))

Indoor unit cooling capacity characteristics




Indoor unit heating capacity characteristics




■ Graph of capacity change characteristics resulting from tubing length and elevation difference (1 / 2 – (3))

(Performance correction coefficients by elevation difference of refrigerant tube length [performance change rate ÷ 100] is calculated by the following line map.)

<Cooling>



<Heating>



1. Model Selecting and Capacity Calculator

The positive side for the elevation difference indicates that the outdoor unit is installed at a higher position than the indoor units. The negative side indicates the opposite.

- The capacity loss that is caused by the tubing length can be reduced by increasing the sizes of the gas tubes.
Refer to Table 2-10-1 and make the appropriate changes. However be sure that the total length does not exceed the maximum.
 - * The only sizes which can be increased are the LM (main tube with the largest diameter) gas tubes, and the changes are limited to those shown in Table 2-10-1.
- In addition, note that the additional refrigerant charge is determined only by the liquid tube size.

Table 2-10-1 Equivalent Length Correction Coefficient when the Size of the Gas Tubes (LM) is Increased

Standard tubing diameter (gas tube, mm)	ø12.7	ø15.88	ø19.05	ø22.22	ø25.4	ø28.58	ø31.75	ø38.1
Tubing diameter after change (gas tube, mm)	ø15.88	ø19.05	ø22.22	ø25.4	ø28.58	ø31.75	ø38.1	ø41.28
Equivalent length correction coefficient	0.4		0.5			0.6		0.7

- * If the size of the gas tubes (LM) have been increased, apply the correction coefficient from Table 2-10-1 and calculate the equivalent length of the LM section.

Equivalent length of tubing after size increase
 = Standard tubing equivalent length × Equivalent length correction coefficient

1. Model Selecting and Capacity Calculator

1-8. Capacity Correction Graph According to Tubing Length and Elevation Difference

● Sample calculations

Indoor/Outdoor Capacity Ratio : (cooling) 125%
: (heating) 127%

Total Indoor Unit Rated Capacity Cooling : 70.0 kW Heating : 80.0 kW	
Total Outdoor Unit Estimation Capacity Cooling : 56.54 kW Heating : 57.81 kW	Total Indoor Unit Estimation Capacity Cooling : 58.19 kW Heating : 65.75 kW

Model name		Rated Capacity	Capacity Estimation by Temp. condition and Indoor/Outdoor Capacity Ratio				Capacity Estimation by the Equiverant Length			Capacity Estimation coefficient by Frost /Defrost
			Temperature Conditions		Estimation coefficient	Capacity	Elevation Difference	Equiverant Length	Estimation coefficient	
		(kW)	°C	%	%	kW	m	m	%	%
U-20ME1E81	Cooling	56.0	40.0	27.0	107.94	60.44	5.0	42.0	93.54	89.0
	Heating	63.0	7.0	38.0	105.52	66.48			97.71	
Indoor Unit class 140	Cooling	14.0	27.0	21.0	57.57	8.06	5.0	8.4	99.42	
	Heating	16.0	15.0	53.0	98.49	15.76			99.86	
Indoor Unit class 140	Cooling	14.0	27.0	36.0	74.84	10.48	5.0	18.0	97.74	
	Heating	16.0	18.0	34.0	89.26	14.28			99.25	
Indoor Unit class 140	Cooling	14.0	27.0	47.0	86.35	12.09	5.0	26.4	96.27	
	Heating	16.0	20.0	25.0	83.10	13.30			98.71	
Indoor Unit class 140	Cooling	14.0	27.0	59.0	97.86	13.70	5.0	42.0	93.54	
	Heating	16.0	22.0	17.0	76.94	12.31			97.71	
Indoor Unit class 140	Cooling	14.0	27.0	78.0	115.13	16.12	5.0	27.6	96.06	
	Heating	16.0	25.0	31.0	67.71	10.83			98.63	

1. Model Selecting and Capacity Calculator

- If the maximum tubing length (L1) exceeds 90 m (equivalent length), increase the tubing size of the main liquid, gas tubes (LM) by one rank.
However, the upper limit for the gas tube size is ø41.28.
- Increasing the tubing size of the gas tubes can reduce the loss of capacity caused by longer tubing lengths.
Refer to Table 2-10-2 to increase the tubing size. However, the maximum allowable tubing length must not be exceeded.
- * The amount of additional refrigerant charge is determined from the liquid tube size only.

Table 2-10-2 Equivalent Length Correction Coefficient when the Size of the Gas Tubes (LM) is Increased

Standard tubing diameter (gas tube, mm)	ø12.7	ø15.88	ø19.05	ø22.22	ø25.4	ø28.58	ø31.75	ø38.1
Tubing diameter after change (gas tube, mm)	ø15.88	ø19.05	ø22.22	ø25.4	ø28.58	ø31.75	ø38.1	ø41.28
Equivalent length correction coefficient	0.4		0.5			0.6		0.7


- * If the size of the gas tubes (LM) have been increased, apply the correction coefficient from Table 2-10-2 and calculate the equivalent length of the LM section.

Equivalent length of tubing after size increase
 = Standard tubing equivalent length × Equivalent length correction coefficient

2. System Design

2-1. System Example

Below are the tables created using the "PAC System Diagram Software".



Selection conditions

Assume that installation is in a 50 Hz region.

		Outdoor unit	Room1 (indoor unit 1)	Room2 (indoor unit 2)	Room3 (indoor unit 3)	Room4 (indoor unit 4)
Cooling	Air condition (DB / WB)	33.0 / 22.5	26.0 / 18.0	26.0 / 18.0	26.0 / 18.0	26.0 / 18.0
	Max. load (kW)	-	14.0	12.0	12.0	7.0
Heating	Air condition (DB / WB)	3.0 / 2.0	21.0 / 16.0	21.0 / 16.0	21.0 / 16.0	21.0 / 16.0
	Max. load (kW)	-	16.0	14.5	14.5	7.2
Actual tubing length		60 m	30 m	40 m	45 m	60 m
Equivalent length (with consideration for curves, etc.)		72 m	36 m	48 m	54 m	72 m

Preliminary selection

	Outdoor unit	Room1 (indoor unit 1)	Room2 (indoor unit 2)	Room3 (indoor unit 3)	Room4 (indoor unit 4)
Selected model	U-18ME1E81	Type 160	Type 140	Type 140	Type 73
Load (cooling / heating) (kW)	-	14.0	12.0	12.0	7.0
Rated capacity (cooling / heating) (kW)	50.0 / 56.0	16.0 / 18.0	14.0 / 16.0	14.0 / 16.0	7.3 / 8.0
Corrected capacity (cooling / heating) (kW)	43.3 / 48.0	14.5 / 17.2	12.4 / 15.1	12.2 / 15.1	6.2 / 7.5
Actual capacity (cooling / heating) (kW)	-	14.5 / 17.2	12.4 / 15.1	12.2 / 15.1	6.2 / 7.5

Indoor unit changes

Increase by one rank because the capacity of the indoor unit 4 is lower than the maximum load.

	Outdoor unit	Room1 (indoor unit 1)	Room2 (indoor unit 2)	Room3 (indoor unit 3)	Room4 (indoor unit 4)
Selected model	U-18ME1E81	Type 160	Type 140	Type 140	Type 106
Load (cooling / heating) (kW)	-	14.0	12.0	12.0	7.0
Rated capacity (cooling / heating) (kW)	50.0 / 56.0	16.0 / 18.0	14.0 / 16.0	14.0 / 16.0	10.6 / 11.4
Corrected capacity (cooling / heating) (kW)	42.9 / 47.1	13.5 / 15.9	11.5 / 14.0	11.4 / 14.0	8.3 / 9.8
Actual capacity (cooling / heating) (kW)	-	13.5 / 15.9	11.5 / 14.0	11.4 / 14.0	8.3 / 9.8

2. System Design

Outdoor unit changes

The capacity of the indoor units 1, 2 and 3 is lower than the maximum load.

Increase the capacity of the outdoor unit by one rank because of inability to increase the indoor unit 1 by one rank.

	Outdoor unit	Room1 (indoor unit 1)	Room2 (indoor unit 2)	Room3 (indoor unit 3)	Room4 (indoor unit 4)
Selected model	U-20ME1E81	Type 160	Type 140	Type 140	Type 106
Load (cooling / heating) (kW)	-	14.0	12.0	12.0	7.0
Rated capacity (cooling / heating) (kW)	56.0 / 63.0	16.0 / 18.0	14.0 / 16.0	14.0 / 16.0	10.6 / 11.4
Corrected capacity (cooling / heating) (kW)	45.8 / 50.4	14.4 / 17.0	12.3 / 15.0	12.2 / 14.9	8.9 / 10.5
Actual capacity (cooling / heating) (kW)	-	14.4 / 17.0	12.3 / 15.0	12.2 / 14.9	8.9 / 10.5

2. System Design

(3) Increasing the size of the refrigerant tubing

- Increasing the tubing size of the gas tubes can reduce the loss of capacity caused by longer tubing lengths.

Refer to Table 2-10-3 to increase the tubing size. However, the maximum allowable tubing length must not be exceeded.

* The amount of additional refrigerant charge is determined from the liquid tube size only.

Table 2-10-3 Equivalent Length Correction Coefficient when the Size of the Gas Tubes (LM) is Increased


Standard tubing diameter (gas tube, mm)	ø12.7	ø15.88	ø19.05	ø22.22	ø25.4	ø28.58	ø31.75	ø38.1
Tubing diameter after change (gas tube, mm)	ø15.88	ø19.05	ø22.22	ø25.4	ø28.58	ø31.75	ø38.1	ø41.28
Equivalent length correction coefficient	0.4		0.5			0.6		0.7

- * If the size of the gas tubes (LM) have been increased, apply the correction coefficient from Table 2-10-3 and calculate the equivalent length of the LM section.

Equivalent length of tubing after size increase
 = Standard tubing equivalent length × Equivalent length correction coefficient

2-2. Example of Tubing Size Selection for Extension and Additional Charge Amount

- Sample calculation for the system below



2. System Design

Additional refrigerant charge before extension

	Liquid tube diameter	Tubing length (m) (A)	Additional refrigerant charge per 1 m (kg/m) (B)	(A) × (B) kg	
La	ø12.7	2	0.128	0.256	
Lb	ø12.7	1	0.128	0.128	
Lc	ø9.52	1	0.056	0.056	
LP	ø15.88	20	0.185	3.700	
LA	ø19.05	5	0.259	1.295	
LB	ø15.88	6	0.185	1.110	
LC	ø12.7	6	0.128	0.768	
LD	ø12.7	0.4	0.128	0.051	
LE1	ø9.52	5	0.056	0.280	
LN	ø15.88	3	0.185	0.555	
LG	ø12.7	3	0.128	0.384	
LH	ø9.52	4	0.056	0.224	
LI	ø9.52	5	0.056	0.280	
LJ	ø9.52	5	0.056	0.280	
LK	ø12.7	2	0.128	0.256	
LL	ø9.52	3	0.056	0.168	
LM	ø9.52	4	0.056	0.224	
L1	ø9.52	3	0.056	0.168	
L2	ø6.35	3	0.026	0.078	
L3	ø6.35	3	0.026	0.078	
L7	ø9.52	3	0.056	0.168	
L8	ø9.52	3	0.056	0.168	
L9	ø9.52	4	0.056	0.224	
L10	ø6.35	4	0.026	0.104	
L11	ø6.35	6	0.026	0.156	
L12	ø9.52	4	0.056	0.224	
L13	ø9.52	4	0.056	0.224	
L14	ø9.52	4	0.056	0.224	
L15	ø6.35	6	0.026	0.156	
Total (kg)				11.987	→ 11.99 kg

Additional refrigerant charge after extension

	Liquid tube diameter	Tubing length (m) (A)	Additional refrigerant charge per 1 m (kg/m) (B)	(A) × (B) kg	
LE2	ø9.52	4	0.056	0.224	
LF	ø9.52	5	0.056	0.280	
L4	ø9.52	4	0.056	0.224	
L5	ø9.52	6	0.056	0.336	
L6	ø9.52	7	0.056	0.392	
Total (kg)				1.4560	→ 1.46 kg

Calculation of additional refrigerant charge for the entire 2-WAY system

(Additional refrigerant charge for entire 2-WAY system)

= (Refrigerant charge at outdoor unit)

+ (Necessary amount of additional refrigerant charge per outdoor unit)

+ [Additional total refrigerant charge (before extension + after extension)]

= [(9.9 + 9.9 + 9.9 =29.7) refrigerant charge at outdoor unit]

+ [(6.4 + 6.4 + 3.5 =16.3) necessary amount of additional refrigerant charge per outdoor unit]

+ [(11.99+1.46 =13.36) additional total refrigerant charge]

= 59.36 (after extension)

[Before extension : (9.9 + 9.9 =19.8) + (6.4 + 6.4 =12.8) + 11.99 = 44.59 kg]

2. System Design

■ Checking of limit density

The limit density judgment is made based on the room with the indoor unit having the smallest capacity in the system after extension.

The volume of the room where a type 09 indoor unit is used (connected to tubing L11) is calculated as follows :

floor area 15m² x ceiling height 2.7m = room volume 40.5m³.

Due to the room volume,

Maximum overall refrigerant charge amount

= (room volume) × (limit density)

= 40.5(m³) × 0.3(kg/m³)

= 12.15kg

From the graph at right, the minimum room volume for 59.36 kg of refrigerant is 197.9 m³ (floor area 73.3 m²).

Required minimum room volume

= (overall refrigerant charge amount) ÷ (limit density)

= 59.36(kg) ÷ 0.3(kg/m³)

= 197.9(m³)

Required minimum floor area

= (minimum room volume) ÷ (ceiling height)

= 197.9 (m³) ÷ 2.7(m)

= 73.3(m²)

Therefore an opening for ventilation is required.


< Formula for computation >

Overall refrigerant charge amount for the air conditioner : kg

(Minimum room volume for indoor unit: m³)

$$= \frac{59.36 \text{ (kg)}}{40.5 \text{ (m}^3\text{)}} = 1.47 \text{ (kg/m}^3\text{)} > 0.30 \text{ (kg/m}^3\text{)}$$

Accordingly, it is necessary to install a ventilation fan for this room.



WARNING

Always check the gas density limit for the room in which the unit is installed.

■ Check of Limit Density

When installing an air conditioner in a room, it is necessary to ensure that even if the refrigerant gas accidentally leaks out, its density does not exceed the limit level for that room.

If the density could exceed the limit level, it is necessary to provide an opening between the unit and the adjacent room, or to install mechanical ventilation which is interlocked with the leak detector.

Overall refrigerant charge amount for the air conditioner : kg

(Minimum room volume for indoor unit: m³)

≤ Limit density 0.3 (kg/m³)

The limit density of refrigerant which is used in this unit is 0.3 kg/m³ (ISO 5149).

The shipped outdoor unit comes charged with the amount of refrigerant fixed for each type, so add it to the amount that is charged in the field. (For the refrigerant charge amount at shipment, refer to the unit's nameplate.)



CAUTION

Pay special attention to any location, such as a basement, etc., where leaking refrigerant can accumulate, since refrigerant gas is heavier than air.

2. System Design


■ Installing distribution joint

- (1) Refer to "HOW TO ATTACH DISTRIBUTION JOINT" enclosed with the optional distribution joint kit (CZ-P680PJ2, P1350PJ2, P160BK2, P680BK2, P1350BK2).
- (2) When creating a branch using a commercially available T-joint (header joint system), orient the main tubing so that it is either horizontal (level) or vertical. In order to prevent accumulation of refrigerant oil in stopped units, if the main tubing is horizontal then each branch tubing length should be at an angle that is greater than horizontal. If the main tubing is vertical, provide a raised starting portion for each branch.

[Header joint system]


- Be sure to solidly weld shut the T-joint end (marked by "X" in the figure). In addition, pay attention to the insertion depth of each connected tube so that the flow of refrigerant within the T-joint is not impeded.
 - When using the header joint system, do not make further branches in the tubing.
 - Do not use the header joint system on the outdoor unit side.
- (3) If there are height differences between indoor units or if branch tubing that follows a distribution joint is connected to only 1 unit, a trap or ball valve must be added to that distribution joint. (When adding the ball valve, locate it within 40 cm of the distribution joint.)
If a trap or ball valve is not added, do not operate the system before repairs to a malfunctioning unit are completed. (The refrigerant oil sent through the tubing to the malfunctioning unit will accumulate and may damage the compressor.)

Tube branching methods (horizontal use)




Types of vertical trap specifications

(When using ball valve)



(When not using ball valve)



3. Electrical Wiring

3-1. General Precautions on Wiring

- (1) Before wiring, confirm the rated voltage of the unit as shown on its nameplate, then carry out the wiring closely following the wiring diagram.
- (2) Provide a power outlet to be used exclusively for each unit, and a power supply disconnect, circuit breaker and earth leakage breaker for overcurrent protection should be provided in the exclusive line.
- (3) To prevent possible hazards from insulation failure, the unit must be grounded.
- (4) Each wiring connection must be done in accordance with the wiring system diagram. Wrong wiring may cause the unit to misoperate or become damaged.
- (5) Do not allow wiring to touch the refrigerant tubing, compressor, or any moving parts of the fan.
- (6) Unauthorized changes in the internal wiring can be very dangerous. The manufacturer will accept no responsibility for any damage or misoperation that occurs as a result of such unauthorized changes.
- (7) Regulations on wire diameters differ from locality to locality. For field wiring rules, please refer to your LOCAL ELECTRICAL CODES before beginning. You must ensure that installation complies with all relevant rules and regulations.
- (8) To prevent malfunction of the air conditioner caused by electrical noise, care must be taken when wiring as follows:
 - The remote control wiring and the inter-unit control wiring should be wired apart from the inter-unit power wiring.
 - Use shielded wires for inter-unit control wiring between units and ground the shield on both sides.
- (9) If the power supply cord of this appliance is damaged, it must be replaced by a repair shop appointed by the manufacturer, because special purpose tools are required.

3-2. Recommended Wire Length and Wire Diameter for Power Supply System

Outdoor unit

	(A) Power supply		Time delay fuse or circuit capacity
	Wire size	Max. length	
U-8ME1E81	4 mm ²	56 m	25 A
U-10ME1E81	4 mm ²	46 m	25 A
U-12ME1E81	6 mm ²	65 m	35 A
U-14ME1E81	10 mm ²	91 m	35 A
U-16ME1E81	10 mm ²	75 m	45 A
U-18ME1E81	10 mm ²	70 m	50 A
U-20ME1E81	10 mm ²	58 m	50 A

or

	(A) Power supply		Time delay fuse or circuit capacity
	Wire size	Max. length	
	6 mm ²	84 m	35 A
	6 mm ²	69 m	35 A
	6 mm ²	65 m	35 A
	10 mm ²	91 m	50 A
	10 mm ²	75 m	50 A
	10 mm ²	70 m	50 A
	10 mm ²	58 m	50 A

Indoor unit

Type	(B) Power supply	Time delay fuse or circuit capacity
	2.5 mm ²	
K1	Max. 150 m	10 – 16 A
D1, L1, U1, Y1, T1, F1, M1, P1, R1	Max. 130 m	10 – 16 A
E1 (73, 106, 140)	Max. 60 m	10 – 16 A
E1 (224, 280)	Max. 50/30 m	10 – 16 A

Control wiring


(C) Inter-unit (between outdoor and indoor units) control wiring			(D) Remote control wiring	
0.75 mm ² (AWG #18) Use shielded wiring*	or	2.0 mm ² (AWG #14) Use shielded wiring*	0.75 mm ² (AWG #18)	
Max. 1,000 m		Max. 2,000 m	Max. 500 m	

NOTE * With ring-type wire terminal.






(E) Control wiring for group control	(F) Inter-outdoor unit control wiring
0.75 mm ² (AWG #18)	0.75 mm ² (AWG #18) Use shielded wiring
Max. 200 m (Total)	Max. 300 m

3. Electrical Wiring


3-3. Wiring System Diagrams




- (1) Refer to Section 3-2. "Recommended Wire Length and Wire Diameter for Power Supply System" for the explanation of "A", "B", "C", "D", "E" and "F" in the above diagram.
- (2) The basic connection diagram of the indoor unit shows the 7P terminal board, so the terminal boards in your equipment may differ from the diagram.
- (3) Refrigerant Circuit (R.C.) address should be set before turning the power on.
- (4) Regarding the R.C. address setting, refer to Section 5. Address setting can be executed by remote controller automatically. Refer to Section 5.
- (5) Regarding S-280ME1E5, the power supply is 220-240V, 50Hz.




ME1 Type



T1, F1, E1, D1, L1 Types



U1, Y1, M1, P1, R1 Types



K1 Type

3. Electrical Wiring



CAUTION

- (1) When linking outdoor units in a network, disconnect the terminal extended from the short plug (CN072, 2P Black, location: right bottom on the outdoor main control PCB) from all outdoor units except any one of the outdoor units.
(When shipping: In shorted condition.)
For a system without link (no connection wiring between outdoor units), do not remove the short plug.
- (2) Do not install the inter-unit control wiring in a way that forms a loop. (Fig. 2-2)




Fig. 2-2

- (3) Do not install inter-unit control wiring such as star branch wiring. Star branch wiring causes misaddress setting.




Fig. 2-3

- (4) If branching the inter-unit control wiring, the number of branch points should be 16 or fewer. (Branches less than 1 m are not included in the total branch number.) (Fig. 2-4)




Fig. 2-4

3. Electrical Wiring

- (5) Use shielded wires for inter-unit control wiring (c) and ground the shield on both sides, otherwise misoperation from noise may occur. (Fig. 2-5)
Connect wiring as shown in Section “3-3. Wiring System Diagram.”
- (6) Use the standard power supply cables for Europe (such as H05RN-F or H07RN-F which conforms to CENELEC (HAR) rating specifications) or use the cables based on IEC standard. (245 IEC57, 245 IEC66)




Fig. 2-5



WARNING

Loose wiring may cause the terminal to overheat or result in unit malfunction.
A fire hazard may also exist.
Therefore, ensure that all wiring is tightly connected.

When connecting each power wire to the terminal, follow the instructions on “How to connect wiring to the terminal” and fasten the wire securely with the fixing screw of the terminal plate.

How to connect wiring to the terminal

■ For stranded wiring

- (1) Cut the wire end with cutting pliers, then strip the insulation to expose the stranded wiring about 10 mm and tightly twist the wire ends. (Fig. 2-6)
- (2) Using a Phillips head screwdriver, remove the terminal screw(s) on the terminal plate.
- (3) Using a ring connector fastener or pliers, securely clamp each stripped wire end with a ring pressure terminal.
- (4) Place the ring pressure terminal, and replace and tighten the removed terminal screw using a screwdriver. (Fig. 2-7)




Fig. 2-6




Fig. 2-7

■ Examples of shield wires

- (1) Remove cable coat not to scratch braided shield. (Fig. 2-8)
- (2) Ravel braided shield carefully and put tightly braided shield together.
Coat with insulation tube or wrap insulation tape after putting tightly. (Fig. 2-9)
- (3) Remove coat of signal wire. (Fig. 2-10)
- (4) Connect signal wire removed coat and shield wire with pressure terminal. (Fig. 2-11)



Fig. 2-8




Fig. 2-9




Fig. 2-10





Fig. 2-11

3. Electrical Wiring

■ Wiring sample


Outdoor Unit : ME1 Type



* First remove the attached resin fixture. Then lead the clamber (field supply) through the screw hole and fix the power supply wire.

** First remove the attached resin fixture. Then lead the clamber (field supply) through the screw hole and square hole from top to bottom or vice versa. Finally fix each inter- outdoor unit control wire and the inter-unit control wire separately with the clamber (field supply).

U1 type




*1 Fasten tightly.


3. Electrical Wiring

■ Wiring sample


Indoor Unit : E1 Type (73, 106, 140)




Indoor Unit : Y1 Type



Indoor Unit : E1 Type (224, 280)



Indoor Unit : M1 Type



* Route the power supply cord through the ring of the supplied wire saddle and clamp the cord.


3. Electrical Wiring

■ Wiring sample

Indoor Unit : F1 Type

Protective ground screw (External Solenoid Valve Kit for 3WAY)

Functional ground screw (External Electronic Expansion Valve Kit and Schedule Timer)



Power Supply

Remote Control Wiring


Inter-unit Control Wiring

Use this screw when connecting to ground the shield for the Inter-unit control wiring.

Indoor Unit : F2 type

Functional ground screw (External Electronic Expansion Valve Kit and Schedule Timer)

Use this screw when connecting the shield for the Inter-unit control wiring to ground.



Protective ground screw (External Solenoid Valve Kit for 3WAY)

Power Supply


Remote Control Wiring

Inter-unit Control Wiring

Indoor Unit : D1 Type

Protective ground screw (External Solenoid Valve Kit for 3WAY)

Remote Control Wiring



Power Supply

Inter-unit Control Wiring

Use this screw when connecting to ground the shield for the Inter-unit control wiring.


Functional ground screw (External Electronic Expansion Valve Kit and Schedule Timer)

Indoor Unit : P1 and R1 Types

Protective ground screw (External Solenoid Valve Kit for 3WAY)

Functional ground screw (External Electronic Expansion Valve Kit and Schedule Timer)

Use this screw when connecting to ground the shield for the Inter-unit control wiring.



Power Supply

Remote Control Wiring

Inter-unit Control Wiring


3. Electrical Wiring

■ Wiring sample

Indoor Unit : K1 Type (22, 28, 36)

Use this screw when connecting to ground the shield for the Inter-unit control wiring.

Protective ground screw (External Solenoid Valve Kit for 3WAY)




Indoor Unit : K1 Type (45, 56, 73, 106)

Functional ground screw (External Electronic Expansion Valve Kit and Schedule Timer) *

Protective ground screw (External Solenoid Valve Kit for 3WAY) *

Fixture screw for resin cover

Resin cover




* As to functional ground screw and protective ground screw, remove the fixture screw and resin cover. Then, carry out earth ground work.

Indoor Unit : L1 Type

Protective ground screw (External Solenoid Valve Kit for 3WAY)

Functional ground screw (External Electronic Expansion Valve Kit and Schedule Timer)


Use this screw when connecting to ground the shield for the Inter-unit control wiring.



Indoor Unit : T1 type

Protective ground screw (External Solenoid Valve Kit for 3WAY)

Remote Control Wiring



4. Installation Instructions

4-1. Selecting the Installation Site for Outdoor Unit

AVOID:

- heat sources, exhaust fans, etc.
- damp, humid or uneven locations
- indoors (no-ventilation location)

DO:

- choose a place as cool as possible.
- choose a place that is well ventilated.
- allow enough room around the unit for air intake/exhaust and possible maintenance.





Fig. 2-12

Installation Space

Install the outdoor unit where there is enough space for ventilation. Otherwise the unit may not operate properly. Fig. 2-13 shows the minimum space requirement around the outdoor units when 3 sides are open and only 1 side is shuttered, with open space above the unit. The mounting base should be concrete or a similar material that allows for adequate drainage. Make provisions for anchor bolts, platform height, and other site-specific installation requirements.

Example of installation of 2 units
(when 3 sides are open and only 1 side is shuttered)



- * Make a walk-in space behind the unit to erase maintenance and servicing.
- ** When setting the anchor bolt to position "B" or "C" (See Fig. 2-14), make the space between the unit and the wall more than 250 mm for installation operation.
- *** When setting the anchor bolt to position "B" or "C" (See Fig. 2-14), make the space between the outdoor units more than 180 mm for installation operation.

Fig. 2-13

CAUTION

- Leave space open above the unit.
- Construct louvers or other openings in the wall, if necessary, to ensure adequate ventilation.

NOTE

- Do not do any wiring or tubing within 30 cm of the front panel, because this space is needed as a servicing space for the compressor.
 - Ensure a base height of 100 mm or more to ensure that drainage water does not accumulate and freeze around the bottom of the unit.
 - If installing a drain pan, install the drain pan prior to installing the outdoor unit.
 - * Make sure there is at least 150 mm between the outdoor unit and the ground.
- Also, the direction of the tubing and electrical wiring should be from the front of the outdoor unit.

4. Installation Instructions




Fig. 2-14

4. Installation Instructions

4-2. Shield for Horizontal Exhaust Discharge

It is necessary to install an air-discharge chamber (field supply) to direct exhaust from the fan horizontally if it is difficult to provide a minimum space of 2 m between the air-discharge outlet and a nearby obstacle. (Fig. 2-15)



CAUTION

In regions with heavy snowfall, the outdoor unit should be provided with a solid, raised platform and snow-proof vents. (Fig. 2-16)




Fig. 2-15

4-3. Installing the Outdoor Unit in Heavy Snow Areas

In locations where wind-blown snow can be a problem, snow-proof vents should be fitted to the unit and direct exposure to the wind should be avoided as much as possible. (Fig. 2-17)

The following problems may occur if proper countermeasures are not taken:

- The fan in the outdoor unit may stop running, causing the unit to be damaged.
- There may be no air flow.
- The tubing may freeze and burst.
- The condenser pressure may drop because of strong wind, and the indoor unit may freeze.

4-4. Precautions When Installing in Heavy Snow Areas

- a) The platform should be higher than the maximum snow depth. (Fig. 2-17)
- b) The 2 anchoring feet of the outdoor unit should be used for the platform, and the platform should be installed beneath the air-intake side of the outdoor unit.
- c) The platform foundation must be solid and the unit must be secured with anchor bolts.
- d) When installing on a roof subject to strong wind, countermeasures must be taken to prevent the unit from being overturned.




Fig. 2-16




Fig. 2-17


4. Installation Instructions

4-5. Dimensions of Wind Ducting


Reference diagram for air-discharge chamber (field supply)

Can be installed so that the air direction is to the front, right, left or rear direction.
According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from “A”, “B” or “C”.

Model : U-8ME1E81, 10ME1E81, 12ME1E81



Model : U-14ME1E81, 16ME1E81





4. Installation Instructions

Reference diagram for air-discharge chamber (field supply)

Can be installed so that the air direction is to the front, right, left or rear direction.
According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from “A”, “B” or “C”.

Model : U-18ME1E81, 20ME1E81

unit: mm



4. Installation Instructions

Reference diagram for air-discharge chamber (field supply) (continued)


Unit combinations for Standard-COP mode

Can be installed so that the air direction is to the front, right, left or rear direction.
According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from “A”, “B” or “C”.

Diagram for 22hp ~ 28hp

unit: mm

Air direction: Front direction




	For 22hp ~ 28hp	
	*a	*b
A : 894 (Installation hole pitch) * The tubing is routed out from the front.	60	1830
B : 730 (Installation hole pitch) * The tubing is routed out from the bottom.	180	1950
C : 730 (Installation hole pitch)	180	1950

Diagram for 30hp & 32hp

unit: mm

Air direction: Front direction



	For 22hp ~ 28hp	
	*a	*b
A : 894 (Installation hole pitch) * The tubing is routed out from the front.	60	1830
B : 730 (Installation hole pitch) * The tubing is routed out from the bottom.	180	1950
C : 730 (Installation hole pitch)	180	1950

4. Installation Instructions

Reference diagram for air-discharge chamber (field supply) (continued)

Unit combinations for Standard-COP mode

Can be installed so that the air direction is to the front, right, left or rear direction.
According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from “A”, “B” or “C”.

Diagram for 34hp & 36hp





Diagram for 38hp & 40hp




4. Installation Instructions

Reference diagram for air-discharge chamber (field supply) (continued)

Unit combinations for Standard-COP mode

Can be installed so that the air direction is to the front, right, left or rear direction.
According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from “A”, “B” or “C”.

Diagram for 42hp & 44hp




unit: mm

Air direction: Front direction

	For 42hp & 44hp	
	*a	*b
A : 894 (Installation hole pitch) * The tubing is routed out from the front.	60	2890
B : 730 (Installation hole pitch) * The tubing is routed out from the bottom.	180	3130
C : 730 (Installation hole pitch)	180	3130

Diagram for 46hp & 48hp



unit: mm

Air direction: Front direction

	For 42hp & 44hp	
	*a	*b
A : 894 (Installation hole pitch) * The tubing is routed out from the front.	60	2890
B : 730 (Installation hole pitch) * The tubing is routed out from the bottom.	180	3130
C : 730 (Installation hole pitch)	180	3130

4. Installation Instructions

Reference diagram for air-discharge chamber (field supply) (continued)

Unit combinations for Standard-COP mode

Can be installed so that the air direction is to the front, right, left or rear direction.
According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from “A”, “B” or “C”.

Diagram for 50hp & 52hp





Diagram for 54hp




4. Installation Instructions

Reference diagram for air-discharge chamber (field supply) (continued)

Unit combinations for Standard-COP mode

Can be installed so that the air direction is to the front, right, left or rear direction.
According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from “A”, “B” or “C”.

Diagram for 56hp ~ 60hp



4. Installation Instructions



4-6. Dimensions of Snow Ducting

Reference diagram for snow-proof vents (field supply)



Can be installed so that the air direction is to the front, right or rear direction.

According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from "A", "B" or "C".

Model : U-8ME1E81, 10ME1E81, 12ME1E81



Model : U-14ME1E81, 16ME1E81



4. Installation Instructions



Reference diagram for snow-proof vents (field supply)

Can be installed so that the air direction is to the front, right, left or rear direction.

According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from "A", "B" or "C".

Model : U-18ME1E81, 20ME1E81

unit: mm



4. Installation Instructions

Reference diagram for snow-proof vents (field supply) (continued)


Unit combinations for Standard-COP mode

Can be installed so that the air direction is to the front, right, left or rear direction.

According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from "A", "B" or "C".

Diagram for 22hp ~ 28hp


unit: mm



- A: 894 (Installation hole pitch) * The tubing is routed out from the front.
 B: 730 (Installation hole pitch) * The tubing is routed out from the bottom.
 C: 730 (Installation hole pitch)

Diagram for 30hp & 32hp

unit: mm



- A: 894 (Installation hole pitch) * The tubing is routed out from the front.
 B: 730 (Installation hole pitch) * The tubing is routed out from the bottom.
 C: 730 (Installation hole pitch)

4. Installation Instructions

Reference diagram for snow-proof vents (field supply) (continued)

Unit combinations for Standard-COP mode

Can be installed so that the air direction is to the front, right, left or rear direction.

According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from "A", "B" or "C".

Diagram for 34hp & 36hp





Diagram for 38hp & 40hp



4. Installation Instructions


Reference diagram for snow-proof vents (field supply) (continued)

Unit combinations for Standard-COP mode

Can be installed so that the air direction is to the front, right, left or rear direction.

According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from "A", "B" or "C".

Diagram for 42hp & 44hp




unit: mm

Air direction: Front direction

- A: 894 (Installation hole pitch) * The tubing is routed out from the front.
 B: 730 (Installation hole pitch) * The tubing is routed out from the bottom.
 C: 730 (Installation hole pitch)

Top view




Right side view

Diagram for 46hp & 48hp


unit: mm

Air direction: Front direction

- A: 894 (Installation hole pitch) * The tubing is routed out from the front.
 B: 730 (Installation hole pitch) * The tubing is routed out from the bottom.
 C: 730 (Installation hole pitch)



Top view



Right side view

4. Installation Instructions


Reference diagram for snow-proof vents (field supply) (continued)

Unit combinations for Standard-COP mode

Can be installed so that the air direction is to the front, right, left or rear direction.

According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from "A", "B" or "C".

Diagram for 56hp ~ 60hp



4. Installation Instructions

4-7. Transporting the Outdoor Unit

When transporting the unit, have it delivered as close to the installation site as possible without unpacking.

Use a hook for suspending the unit. (Fig. 2-23)



CAUTION


- When hoisting the outdoor unit, pass ropes through the left and right holes of the bottom plate as shown in the Figs. 2-18-1 to 2-18-3.

The angle between the rope and top panel must be 70° or more so that the rope does not come into contact with the fan guard.

Use two lengths of rope 7.5 meters long or longer.

- Hang the rope at an oblique angle of the four corners of the bottom plate.
If it is hung at other areas, the rope becomes loose and the outdoor unit will be damaged or you may be injured.
- Use protective panels or padding at all locations where the rope contacts the outer casing or other parts to prevent scratching. In particular, use protective material (such as cloth or cardboard) to prevent the edges of the top panel from being scratched.

Model : 14 hp, 16 hp




Detailed drawing B

This is not a lifting lug.
<Do not attempt to lift the unit by one of the legs at each corner of the unit or with hooks or shackles attached for installing the legs.>

Fig. 2-18-2

Model : 8 hp, 10 hp, 12 hp




Detailed drawing A

This is not a lifting lug.
<Do not attempt to lift the unit by one of the legs at each corner of the unit or with hooks or shackles attached for installing the legs.>

Fig. 2-18-1

Model : 18 hp, 20 hp



Detailed drawing C

This is not a lifting lug.
<Do not attempt to lift the unit by one of the legs at each corner of the unit or with hooks or shackles attached for installing the legs.>

Fig. 2-18-3

4. Installation Instructions

4-8. Installing the Outdoor Unit

- (1) Use four (4) anchor bolts (M12 or similar) to securely anchor the unit.

Regarding the positioning anchor bolts of the depth direction, select one of three types according to the installation site.

(See Fig. 2-19 a, b, c.)

Normally, select the position "A". When removing the connection tube in a downward direction, select the position "B".

- (2) When only using a single outdoor unit, see the Figure 2-19.

When making a combination of more than 2 units, refer to pages from 1-8 to 1- 17 regarding the confirmation of the unit installation holes and unit size.

* When positioning the anchor bolt at "B" or "C", make a sufficient space between the units or from the wall for installation.

(Make a space between the units wider than 180mm and left and right space wider than 250mm from the wall.)

- (3) The vibration insulator or the like should be kept secure to satisfy the width and depth of 100mm for the plate legs.

(See the dimensions marked by the asterisk at Fig. 2-21d - 2-21g.) Use a washer from the upper direction larger than the hole size for fixing the installation. The models 18 and 20 have four (4) anchor bolts respectively as same as others.

Two models, however, additionally need the vibration insulator under the plate leg at the central location for the installation site. Screw or wire the vibration insulator at the center of the unit to the rack or the basement.

Be sure to use the same thickness of all vibration insulators and make adjustment so that they will become the same height each other. (Fig. 2-20 and Fig. 2-21)




Fig. 2-19a




Fig. 2-19b




Fig. 2-19c

(Detailed view of anchor hole)




Fig. 2-20

- According to the installation site, you may choose the setting position in the depth direction of the anchor bolt from "A", "B" or "C".

A :894 (Installation hole pitch) * The tubing is routed out from the front.


B :730 (Installation hole pitch) * The tubing is routed out from the bottom.

C :730 (Installation hole pitch)


4. Installation Instructions

- Below shows vibration insulator position when setting anchor bolt at position A (Fig.2-19).

Model : 8 hp, 10 hp, 12 hp, 14 hp, 16 hp



Model : 18 hp, 20 hp




- * Need the vibration insulator under the plate leg at the central location for the installation site.


Fig. 2-21a

- Below shows vibration insulator position when setting anchor bolt at position B (Fig.2-19).

Model : 8 hp, 10 hp, 12 hp, 14 hp, 16 hp



Model : 18 hp, 20 hp




- * Need the vibration insulator under the plate leg at the central location for the installation site.


Fig. 2-21b

- Below shows vibration insulator position when setting anchor bolt at position C (Fig.2-19).

Model : 8 hp, 10 hp, 12 hp, 14 hp, 16 hp



Model : 18 hp, 20 hp



- * Need the vibration insulator under the plate leg at the central location for the installation site.

Fig. 2-21c

4. Installation Instructions




Fig. 2-21d






Fig. 2-21e



** Anchor bolt & washer are not required at the central plate leg (G).

Fig. 2-21f





** Anchor bolt & washer are not required at the central plate leg (F).


Fig. 2-21g

4. Installation Instructions


4-9. Routing the Tubing

- The tubing can be routed out either from the front or from the bottom. (Fig. 2-22a)
 - The connecting valve is contained inside the unit. Therefore, remove the front panel. (Fig. 2-22b)
- (1) If the tubing is routed out from the front, punch out the slit part (). (Fig. 2-23a)
- Be careful not to damage the tubing cover.
- (2) If the tubing is routed out from the bottom, use cutting pliers or a similar tool to cut out the tubing outlet slit (part indicated by ) from the tubing cover. (Figs. 2-22c and 2-23b)
- Be careful not to damage the tubing cover.

Model : 8hp, 10hp, 12hp



Model : 14hp, 16hp



Model : 18hp, 20hp






Fig. 2-22a

Model : 8hp, 10hp, 12hp



Model : 14hp, 16hp



Model : 18hp, 20hp




Fig. 2-22b





Fig. 2-22c


If the tubing is routed out from the front, punch out in the direction of the arrow.

Fig. 2-23a



If the tubing is routed out from the bottom, use cutting pliers or a similar tool to cut out the tubing outlet slit from the tubing cover.

Fig. 2-23b



4. Installation Instructions

4-10. Prepare the Tubing

- Material: Use C1220 phosphorous deoxidized copper as described in JIS H3300, "Copper and Copper Alloy Seamless Pipes and Tubes." (For tubes that are $\varnothing 22.22$ or larger, use 1/2H material or H material. For all others use O material.)
- Tubing size
Use the tubing size indicated in the table below.
- When cutting the tubing, use a tube cutter, and be sure to remove any burrs.
(The same applies to distribution tubing (optional).)
- When bending the tubes, bend each tube using a radius that is at least 4 times the outer diameter of the tube.
When bending, use sufficient care to avoid crushing or damaging the tube.
- For flaring, use a flare tool, and be sure that flaring is performed correctly.



CAUTION

Use sufficient caution during preparation of the tubing.

Seal the tube ends by means of caps or taping to prevent dust, moisture, or other foreign substances from entering the tubes.

Refrigerant tubing

Tubing size (mm)			
Outer dia.	Thickness	Outer dia.	Thickness
$\varnothing 6.35$	t0.8	$\varnothing 22.22$	t1.0
$\varnothing 9.52$	t0.8	$\varnothing 25.4$	t1.0
$\varnothing 12.7$	t0.8	$\varnothing 28.58$	t1.0
$\varnothing 15.88$	t1.0	$\varnothing 31.75$	t1.1
$\varnothing 19.05$	t1.2	$\varnothing 38.1$	over t1.35
		$\varnothing 41.28$	over t1.45


4. Installation Instructions

4-11. Connect the Tubing


- When operating the refrigerant tube installation in the field, do not apply the flame of welding to the surrounding sheet-metal parts. If necessary, use a wet rag to prevent overheating of the heat exchanger.
- Except for the 16HP model, do not use the supplied connector tubing. (See figure below.)

Model : 8 hp, 10 hp, 12 hp, 14 hp,
18 hp, 20 hp (Except 16 hp)

Model : 16 hp





	Refrigerant tubing	Connection method	Supplied parts used?
1	Gas tubing	Brazing	No
2	Liquid tubing	Flare connection	No
3	Balance tube	Flare connection	No




	Refrigerant tubing	Connection method	Supplied parts used?
1	Gas tubing	Brazing	yes ø25.4 → ø28.58
2	Liquid tubing	Flare connection	No
3	Balance tube	Flare connection	No

Refrigerant tube port

- Use caulking, putty, or a similar material to fill any gaps at the refrigerant tube port () in order to prevent rainwater, dust or foreign substances from entering the unit.
- * Perform this work even if the tubing is routed out in a downward direction.



Tubing routed out through the front side



Tubing routed out through the bottom

4. Installation Instructions


- Tighten each cap as specified below.

Tightening torque for each cap


Cap tightening torque

Service port cap (width 15 mm, 17 mm)		8 – 10 N · m (80 – 100 kgf · cm)
Valve cap	width 22 mm	19 – 21 N · m (190 – 210 kgf · cm)
	width 24 mm	24 – 26 N · m (240 – 260 kgf · cm)
	width 27 mm	28 – 32 N · m (280 – 320 kgf · cm)


(Model : 8 hp)




(Model : 10 hp)




(Model : 12 hp, 14 hp, 16 hp)



(Model : 18 hp, 20 hp)



4. Installation Instructions



Use two adjustable wrenches when removing or installing the balance tube flare nut.

In particular, do not apply an adjustable wrench to the hexagonal part at the top of the valve.


(If force is applied to this part, gas leakage will occur.)

Apply an adjustable wrench to settle the fixing tool as shown in the figure. If not used, the valve fixing tool will get distorted.

Use two adjustable wrenches, as shown in the figure, when removing the liquid tube valve flare nut.

1. Do not apply a wrench to the valve cap when removing or installing the flare nuts. Doing so may damage the valve.
2. If the valve cap is left off for a long period of time, refrigerant leakage will occur. Therefore, do not leave the valve cap off.
3. Applying refrigerant oil to the flare surface can be effective in preventing gas leakage, however be sure to use a refrigerant oil which is suitable for the refrigerant that is used in the system.

(This unit utilizes R410A refrigerant, and the refrigerant oil is ether oil (synthetic oil). However, hub oil (synthetic oil) can also be used.)




● Precautions for brazing

Be sure to replace the air inside the tube with nitrogen to prevent oxide film from forming during the brazing process.

Be sure to use a damp cloth or other means to cool the valve unit during brazing.

Work method



CAUTION

1. Be sure to use nitrogen
(Oxygen, CO₂, and CFC must not be used.)
2. Use a pressure-reducing valve on the nitrogen tank.
3. Do not use agents intended to prevent the formation of oxide film.
They will adversely affect the refrigeration oil, and may cause equipment failure.
4. The balance tube is not used if only 1 outdoor unit is installed.
Use the unit in the same conditions as when it was shipped from the factory.

4. Installation Instructions

● Charging procedure

Be sure to charge with R410A refrigerant **in liquid form**.

1. After performing a vacuum, charge with refrigerant from the liquid tubing side. At this time, all valves must be in the “fully closed” position.
2. If it was not possible to charge the designated amount, operate the system in Cooling mode while charging with refrigerant from the gas tubing side. (This is performed at the time of the test run. For this, all valves must be in the “fully open” position. However if only one outdoor unit is installed, a balance tube is not used.

Therefore, leave the valves fully closed.) Charge with R410A refrigerant in liquid form.


With R410A refrigerant, charge while adjusting the amount being fed a little at a time in order to prevent liquid refrigerant from backing up.

- After charging is completed, turn all valves to the “fully open” position.
- Replace the tubing covers as they were before.



CAUTION

1. R410A additional charging absolutely must be done through liquid charging.
2. The R410A refrigerant cylinder has a gray base color, and the top part is pink.
3. The R410A refrigerant cylinder includes a siphon tube. Check that the siphon tube is present. (This is indicated on the label at the top of the cylinder.)
4. Due to differences in the refrigerant, pressure, and refrigerant oil involved in installation, it is not possible in some cases to use the same tools for R22 and for R410A.



4. Installation Instructions

4-12. Selecting the Installation Site for Indoor Unit

AVOID:

- Areas where leakage of flammable gas may be expected.
- Places where large amounts of oil mist exist.
- Direct sunlight.
- Locations near heat sources which may affect the performance of the unit.
- Locations where external air may enter the room directly. This may cause "sweating" on the air discharge ports, causing them to spray or drip.
- Locations where the remote controller will be splashed with water or affected by dampness or humidity.
- Installing the remote controller behind curtains or furniture.
- Locations where high-frequency emissions are generated.
- Places where blocks air passages.
- Places where the false ceiling is not noticeably on an incline.

DO:

- Select an appropriate position from which every corner of the room can be uniformly cooled.
- Select a location where the ceiling is strong enough to support the weight of the unit.
- Select a location where tubing and drain pipe have the shortest run to the outdoor unit.
- Allow room for operation and maintenance as well as unrestricted air flow around the unit.
- Install the unit within the maximum elevation difference above or below the outdoor unit and within a total tubing length (L) from the outdoor unit as detailed in Table 2-1.
- Allow room for mounting the remote controller about 1 m off the floor, in an area that is not in direct sunlight nor in the flow of cool air from the indoor unit. Air delivery will be degraded if the distance from the floor to the ceiling is greater than 3 m (for D1 type, greater than 3.5 m).
- Places where optimum air distribution can be ensured.
- Places where sufficient clearance for maintenance and service can be ensured. (Refer to the diagram.)
- If the indoor unit is installed on the ceiling where the temperature or humidity inside is high (over 30°C/RH: 80%), add insulating material to the surface of the unit to avoid dew condensation. (Only for U1 type.)
- If the indoor unit is installed on the ceiling where the temperature or humidity inside is high (over 30°C/RH: 70%), add insulating material to the surface of the unit to avoid dew condensation. (Only for F2 type.)

NOTE

Air delivery will be degraded if the distance from the floor to the ceiling is greater than 3 m (for D1 type, greater than 3.5 m).

Floor Standing, Concealed Floor Standing Type





Fig. 2-27

Ceiling Type



NOTE

The rear of the indoor unit can be installed flush against the wall.





Fig. 2-24

Low Silhouette Ducted Type



2-Way, 4-Way Cassette Type




Fig. 2-25

1-Way Cassette Type





Fig. 2-26

Wall Mounted Type



Front View

* S-45MK1E5/56MK1E5/73MK1E5/106MK1E5 : Min. 7.5 cm

Fig. 2-28

4. Installation Instructions

4-13. How to install the indoor unit

• 4-Way Cassette Type (U1 Type : S- ** MU1E51)

4-13-1. Preparation for Suspending

This unit uses a drain pump. Use a carpenter's level to check that the unit is level.

4-13-2. Suspending the Indoor Unit

- (1) Fix the suspension bolts securely in the ceiling using the method shown in the diagrams (Figs. 2-29 and 2-30), by attaching them to the ceiling support structure, or by any other method that ensures that the unit will be securely and safely suspended.
- (2) Follow Fig. 2-30 and Table 2-11 to make the holes in the ceiling.

Table 2-11 Unit: mm

Type \ Length	A	B	C	D
22, 28, 36, 45, 56, 60, 73, 90, 106, 140, 160	786	745	860 to 910	860 to 910

- (3) Determine the pitch of the suspension bolts using the supplied full-scale installation diagram. The diagram and table (Fig. 2-31 and Table 2-12) show the relationship between the positions of the suspension fitting, unit, and panel.

Use the nut (field supply) and washer (supplied) for upper and lower position of the suspension lug.

Table 2-12 Unit: mm

Type \ Length	A	B	C	D	E
22, 28, 36, 45, 56, 60, 73, 90	121	171	256	180	130
106, 140, 160	121	171	319	180	130

Note: For DC Fan Tap Change Procedure for 4-Way Cassette, see page 20.




Fig. 2-29




Fig. 2-30




Fig. 2-31

4. Installation Instructions

4-13-3. Placing the Unit Inside the Ceiling

This unit is equipped with the drain pump. Check a tape measure or carpenter's level.

Before installing the ceiling panel, complete the work of drain pipe and refrigerant pipe installation.

- (1) When placing the unit inside the ceiling, determine the pitch of the suspension bolts using the supplied full-scale installation diagram. (Fig. 2-32)
Tubing and wiring must be laid inside the ceiling when suspending the unit. If the ceiling is already constructed, lay the tubing and wiring into position for connection to the unit before placing the unit inside the ceiling.
- (2) The length of suspension bolts must be appropriate for a distance between the bottom of the bolt and the bottom of the unit of more than 18 mm as shown in Fig. 2-32.
- (3) Thread the 3 hexagonal nuts and 2 washers (field supply) onto each of the 4 suspension bolts as shown in Fig. 2-33. Use 1 nut and 1 washer for the upper side, and 2 nuts and 1 washer for the lower side, so that the unit will not fall off the suspension lugs.
- (4) Adjust so that the distance between the unit and the ceiling bottom is 12 to 17 mm. Tighten the nuts on the upper side and lower side of the suspension lug.
- (5) Remove the protective polyethylene used to protect the fan parts during transport.
- (6) Check with a tape measure or carpenter's level.




Fig. 2-33

4-13-4. How to Process Tubing

Refer to the section "5. HOW TO PROCESS TUBING".




Fig. 2-32

4. Installation Instructions

4-13-5. Installing the Drain Pipe


4-13-5-1. Before Performing the Installation Drain Piping

(1) Limitations of Raising the Drain Pipe Connection



CAUTION

- The drain pipe can be raised to a maximum height of 850 mm from the bottom surface of the ceiling. Do not attempt to raise it higher than 850 mm. Doing so will result in water leakage. (Fig. 2-34)



* Length of supplied drain pipe = 250 mm

Fig. 2-34

(2) Limitations of Drain Pipe Connection



CAUTION

- Do not install the drain pipe with an upward gradient from the drain port connection. This will cause the drain water to flow backward and leak when the unit is not operating. (Fig. 2-35)
- Do not install an air bleeder as this may cause water to spray from the drain pipe outlet. (Fig. 2-35)
- Do not provide U-trap or bell-shaped trap in the middle of the drain pipe. Doing so will cause abnormal sound. (Fig. 2-35)
- Make sure the drain pipe has a downward gradient (1/100 or more; downward from drain port connection). (Fig. 2-36)




Fig. 2-35




Fig. 2-36

(3) Limitations of Drain Hose Connection



CAUTION

- Do not bend the supplied drain hose 90° or more. Bend it less than 45°. (Fig. 2-37)
- Do not make a trap in the middle of the supplied drain hose. Doing so will cause abnormal sound. (Fig. 2-38)




Fig. 2-37




Fig. 2-38

4. Installation Instructions

4-13-5-2. Installing the Drain Pipe



CAUTION

- Do not apply force to the drain port when connecting the drain pipe. Install and fix it near the indoor unit as close as possible.
- Do not use adhesive when connecting the drain port pipe and the drain hose.

(1) How to Install the Drain Pipe

- First insert the supplied hose band into the drain port pipe. Then make sure the head of the screw is facing toward a technical engineer when placing the screw of the hose band at an upward angle.
- Insert the soft PVC socket of the supplied drain hose to the drain port pipe. Do not use adhesive when connecting the drain hose to the drain port pipe. Insert it until the tip of the drain hose contacts the circular projection rib of the drain port pipe.

- Move the hose band so that the center position of the hose band can be placed approx. 30 mm away from the external plate of the indoor unit. (Fig. 2-39)
- Screw the drain hose tightly facing the screw of the hose band upward. (Torque: 2.5 N·m - 3.4 N·m) (If the screw is tightened beneath the drain hose, the troubles will be generated.) Pay attention not to make hose band overlap the circular projection rib and the sealed circulation projection of the drain port pipe.
- Apply approx. 2 g of adhesive on both sides of the drain hose without connection of the hard PVC socket and the hard PVC joint (VP25) in the local supply.
- Connect the drain hose and the hard PVC joint so that the adhesive area of both sides can be overlapped. Wipe off the protrusion-adhesive with a soft cloth.




Fig. 2-39

4. Installation Instructions

4-13-5-3. Checking the Drainage


CAUTION

Be careful since the fan will start when you short the pin on the indoor control board.

After wiring and drain piping are completed, use the following procedure to check that the water will drain smoothly. For this, prepare a bucket and wiping cloth to catch and wipe up spilled water.

- (1) Connect power to the power terminal board (R, S terminals) inside the electrical component box.
- (2) Slowly pour about 1,200 cc of water into the drain pan to check drainage. (Fig. 2-40)
- (3) Short the check pin (CHK) on the indoor control board and operate the drain pump. Check the water flow through the transparent drain pipe and see if there is any leakage.
- (4) When the check of drainage is complete, open the check pin (CHK) and remount the tube cover.
- (5) Checkpoint after installation

After installation of indoor and outdoor units, panels and electrical wiring, check the following items.





Fig. 2-40

2


	Checkpoint	Symptom	Check	Remark
1	Make sure whether indoor and outdoor units are correctly installed.	Fall, vibration, noise		
2	Make sure whether gas leakage is tested.	No cooling, no heating		
3	Make sure whether insulation is completed. (Refrigerant piping and drain piping)	Water leakage		
4	Make sure whether drain water is running smoothly.	Water leakage		
5	Make sure whether the power voltage matches the nameplate.	Inoperative, burnout		
6	Make sure whether there is miswiring or incorrect connection.	Inoperative, burnout		
7	Make sure whether the ground construction is completed.	Ground leakage		
8	Make sure whether the wire gauge is followed by the recommended specifications.	Inoperative, burnout		
9	Make sure whether the air intake and air outlet of the indoor and outdoor units are sealed by obstacles.	No cooling, no heating		

4. Installation Instructions

4-13-6. Important Note for Wiring 4-Way Cassette Type



- (1) The power supply inlet is located at the lower area of the refrigerant tubing side of the unit. The electrical component box is located at the air intake of the bottom of the unit.
- (2) Before installing the ceiling panel, be sure to carry out the wiring connection.
- (3) Remove the lid located on the bottom of the indoor unit attaching the electrical component box by unscrewing the philip head tapping screws (×2).



- (4) Lead the wires from the power supply inlet to the unit.
Be sure to lead the wires through the power supply inlet.
Make sure that no wire is caught between the indoor unit and ceiling panel. Otherwise, the unit may cause a fire.
- (5) Connect the wires into the terminals through the power supply inlet for the electrical component box.
Fix the wires with a clamping clip.
- (6) Reinstall the lid of the electrical component box in its original position with paying attention not to have the wires caught in the lid.
Refer to "3. Electrical Wiring".

4. Installation Instructions

● 4-Way Cassette Type (U1 Type : S- ** MU1E5)

4-13-7. Preparation for Suspending

This unit uses a drain pump. Use a carpenter's level to check that the unit is level.

4-13-8. Suspending the Indoor Unit

- (1) Fix the suspension bolts securely in the ceiling using the method shown in the diagrams (Figs. 2-41 and 2-42), by attaching them to the ceiling support structure, or by any other method that ensures that the unit will be securely and safely suspended.
- (2) Follow Fig. 2-42 and Table 2-13 to make the holes in the ceiling.

Table 2-13

Unit: mm

Type \ Length	A	B	C	D
22, 28, 36, 45, 56, 73, 106, 140, 160	786	745	860 to 910	860 to 910

- (3) Determine the pitch of the suspension bolts using the supplied full-scale installation diagram. The diagram and table (Fig. 2-43 and Table 2-14) show the relationship between the positions of the suspension fitting, unit, and panel.

Use the nut (field supply) and washer (supplied) for upper and lower position of the suspension lug.

Table 2-14

Unit: mm

Type \ Length	A	B	C	D	E
22, 28, 36, 45, 56	121	171	256	180	130
73, 106, 140, 160	121	171	319	180	130




Fig. 2-41




Fig. 2-42




Fig. 2-43

4-13-9. Placing the Unit Inside the Ceiling

This unit is equipped with the drain pump. Check a tape measure or carpenter's level.

Before installing the ceiling panel, complete the work of drain pipe and refrigerant pipe installation.

- (1) When placing the unit inside the ceiling, determine the pitch of the suspension bolts using the supplied full-scale installation diagram. (Fig. 2-44)
Tubing and wiring must be laid inside the ceiling when suspending the unit. If the ceiling is already constructed, lay the tubing and wiring into position for connection to the unit before placing the unit inside the ceiling.




Fig. 2-44

4. Installation Instructions

- (2) The length of suspension bolts must be appropriate for a distance between the bottom of the bolt and the bottom of the unit of more than 18 mm as shown in Fig. 2-44.
- (3) Thread the 3 hexagonal nuts and 2 washers (field supply) onto each of the 4 suspension bolts as shown in Fig. 2-45. Use 1 nut and 1 washer for the upper side, and 2 nuts and 1 washer for the lower side, so that the unit will not fall off the suspension lugs.
- (4) Adjust so that the distance between the unit and the ceiling bottom is 12 to 17 mm. Tighten the nuts on the upper side and lower side of the suspension lug.
- (5) Remove the protective polyethylene used to protect the fan parts during transport.
- (6) Check with a tape measure or carpenter's level.




Fig. 2-45

4-13-10. How to Process Tubing

Refer to the section "5. HOW TO PROCESS TUBING".

4-13-11. Installing the Drain Pipe


4-13-11-1 Before Performing the Installation Drain Piping

- (1) Limitations of Raising the Drain Pipe Connection



CAUTION

- The drain pipe can be raised to a maximum height of 850 mm from the bottom surface of the ceiling. Do not attempt to raise it higher than 850 mm. Doing so will result in water leakage. (Fig. 2-46)



* Length of supplied drain pipe = 250 mm

Fig. 2-46

- (2) Limitations of Drain Pipe Connection



CAUTION

- Do not install the drain pipe with an upward gradient from the drain port connection. This will cause the drain water to flow backward and leak when the unit is not operating. (Fig. 2-47)
- Do not install an air bleeder as this may cause water to spray from the drain pipe outlet. (Fig. 2-47)
- Do not provide U-trap or bell-shaped trap in the middle of the drain pipe. Doing so will cause abnormal sound. (Fig. 2-47)
- Make sure the drain pipe has a downward gradient (1/100 or more; downward from drain port connection). (Fig. 2-48)




Fig. 2-47




Fig. 2-48

- (3) Limitations of Drain Hose Connection



CAUTION

- Do not bend the supplied drain hose 90° or more. Bend it less than 45°. (Fig. 2-49)
- Do not make a trap in the middle of the supplied drain hose. Doing so will cause abnormal sound. (Fig. 2-50)




Fig. 2-49




Fig. 2-50

4. Installation Instructions

4-13-11-2. Installing the Drain Pipe




CAUTION

- Do not apply force to the drain port when connecting the drain pipe. Install and fix it near the indoor unit as close as possible.
- Do not use adhesive when connecting the drain port pipe and the drain hose.

(1) How to Install the Drain Pipe

- 1) First insert the supplied hose band into the drain port pipe. Then make sure the head of the screw is facing toward a technical engineer when placing the screw of the hose band at an upward angle.
- 2) Insert the soft PVC socket of the supplied drain hose to the drain port pipe. Do not use adhesive when connecting the drain hose to the drain port pipe. Insert it until the tip of the drain hose contacts the circular projection rib of the drain port pipe.

- 3) Move the hose band so that the center position of the hose band can be placed approx. 30 mm away from the external plate of the indoor unit. (Fig. 2-51)
- 4) Screw the drain hose tightly facing the screw of the hose band upward. (Torque: 2.5 N·m - 3.4 N·m) (If the screw is tightened beneath the drain hose, the troubles will be generated.) Pay attention not to make hose band overlap the circular projection rib and the sealed circulation projection of the drain port pipe.
- 5) Apply approx. 2 g of adhesive on both sides of the drain hose without connection of the hard PVC socket and the hard PVC joint (VP25) in the local supply.
- 6) Connect the drain hose and the hard PVC joint so that the adhesive area of both sides can be overlapped. Wipe off the protrusion-adhesive with a soft cloth.



- * After checking the drainage, wrap the supplied packing and drain pipe insulator around the pipe.

Fig. 2-51

4. Installation Instructions

4-13-11-3. Checking the Drainage



CAUTION

Be careful since the fan will start when you short the pin on the indoor control board.

After wiring and drain piping are completed, use the following procedure to check that the water will drain smoothly. For this, prepare a bucket and wiping cloth to catch and wipe up spilled water.

- (1) Connect power to the power terminal board (R, S terminals) inside the electrical component box.
- (2) Slowly pour about 1,200 cc of water into the drain pan to check drainage. (Fig. 2-52)
- (3) Short the check pin (CHK) on the indoor control board and operate the drain pump. Check the water flow through the transparent drain pipe and see if there is any leakage.
- (4) When the check of drainage is complete, open the check pin (CHK) and remount the tube cover.
- (5) Checkpoint after installation

After installation of indoor and outdoor units, panels and electrical wiring, check the following items.





Fig. 2-52

2


	Checkpoint	Symptom	Check	Remark
1	Make sure whether indoor and outdoor units are correctly installed.	Fall, vibration, noise		
2	Make sure whether gas leakage is tested.	No cooling, no heating		
3	Make sure whether insulation is completed. (Refrigerant piping and drain piping)	Water leakage		
4	Make sure whether drain water is running smoothly.	Water leakage		
5	Make sure whether the power voltage matches the nameplate.	Inoperative, burnout		
6	Make sure whether there is miswiring or incorrect connection.	Inoperative, burnout		
7	Make sure whether the ground construction is completed.	Ground leakage		
8	Make sure whether the wire gauge is followed by the recommended specifications.	Inoperative, burnout		
9	Make sure whether the air intake and air outlet of the indoor and outdoor units are sealed by obstacles.	No cooling, no heating		

4. Installation Instructions

4-13-12. Important Note for Wiring 4-Way Cassette Type



- (1) The power supply inlet is located at the lower area of the refrigerant tubing side of the unit.
The electrical component box is located at the air intake of the bottom of the unit.
- (2) Before installing the ceiling panel, be sure to carry out the wiring connection.
- (3) Remove the lid located on the bottom of the indoor unit attaching the electrical component box by unscrewing the philip head tapping screws (x2).



- (4) Lead the wires from the power supply inlet to the unit. Be sure to lead the wires through the power supply inlet.
Make sure that no wire is caught between the indoor unit and ceiling panel. Otherwise, the unit may cause a fire.
- (5) Connect the wires into the terminals through the power supply inlet for the electrical component box.
Fix the wires with a clamping clip.
- (6) Reinstall the lid of the electrical component box in its original position with paying attention not to have the wires caught in the lid. Refer to "3. Electrical Wiring".

4. Installation Instructions

● 4-Way Cassette 60x60 Type (Y1 Type)

4-13-13. Preparation for Ceiling Suspension

This unit uses a drain pump. Use a carpenter's level to check that the unit is level.

4-13-14. Mounting the Suspension Bolts

- (1) Fix the suspension bolts securely to the ceiling using the method shown in the diagrams (Figs. 2-53 and 2-54), by attaching them to the ceiling support structure, or by any other method that ensures that the unit will be securely and safely suspended.
- (2) Follow the diagram to make the holes in the ceiling. (Refer to Fig. 2-54)





Fig. 2-53



Unit: mm

Fig. 2-54

- (3) Determine the pitch of the suspension bolts using the supplied full-scale installation diagram. The diagram shows the relationship between the positions of the suspension fitting, the unit, and the panel.




Fig. 2-55

4-13-15. Placing the Unit Inside the Ceiling

- (1) When placing the unit inside the ceiling, determine the pitch of the suspension bolts using the supplied full-scale installation diagram. (Fig. 2-56)
Tubing and wiring must be laid inside the ceiling when suspending the unit. If the ceiling is already constructed, lay the tubing and wiring into position for connection to the unit before placing the unit inside the ceiling.
- (2) The length of suspension bolts must be appropriate for a distance between the bottom of the bolt and the bottom of the unit of more than 15 mm. (Fig. 2-56)




Fig. 2-56

4. Installation Instructions

- (3) Thread the 3 hexagonal nuts and 2 washers (field supply) onto each of the 4 suspension bolts (Fig. 2-57). Use 1 nut and 1 washer for the upper side, and 2 nuts and 1 washer for the lower side, so that the unit will not fall off the suspension lugs.




Fig. 2-57


- (4) Adjust so that the distance between the unit and the ceiling bottom is 13 to 18 mm. Tighten the nuts on the upper side and lower side of the suspension lug.
- (5) Remove the protective polyethylene used to protect the fan parts during transport.

2

4-13-16. Installing the Drain Pipe

- (1) Prepare a standard hard PVC pipe (O.D. 26 mm) for the drain and use the supplied drain hose and hose band to prevent water leaks. The PVC pipe must be purchased separately. The unit's transparent drain port allows you to check drainage.
- (2) Installing the drain hose

- **To install the drain hose, first place 1 of the 2 hose bands over the unit drain port and the other hose band over the hard PVC pipe (not supplied). Then connect both ends of the supplied drain hose. (Fig. 2-58)**



Unit: mm

Fig. 2-58

- **On the unit drain side, grasp the hose band with pliers and insert the drain hose all the way to the base.**
- **If other commercially available hose bands are used, the drain hose may become pinched or wrinkled and there is danger of water leakage. Therefore be sure to use the supplied hose bands. When sliding the hose bands, be careful to avoid scratching the drain hose.**
- **Do not use adhesive when connecting the supplied drain hose to the drain port (either on the main unit or the PVC pipe).**

Reasons: 1. It may cause water to leak from the connection.

Since the connection is slippery just after the adhesive has been applied, the pipe easily slips off.

2. The pipe cannot be removed when maintenance is needed.

4. Installation Instructions

- Wrap the hose with the supplied drain hose insulation and use the 4 twist ties so that the hose is insulated with no gaps.
- Do not bend the supplied drain hose 90° or more. The hose may slip off.

CAUTION

- Attach so that the hose band fastener is on the side of the drain port.
- Attach the hose bands so that each is approximately 5 to 25 mm from the end of the supplied drain hose.

NOTE

Make sure the drain pipe has a downward gradient (1/100 or more) and that there are no water traps.

CAUTION

- Do not install an air bleeder as this may cause water to spray from the drain pipe outlet. (Fig. 2-59)




Fig. 2-59

- In cases where it is necessary to raise the height of the drain piping, the drain piping can be raised to a maximum height of 850 mm above the bottom surface of the ceiling. Under no conditions attempt to raise it higher than 850 mm above the bottom surface of the ceiling. Doing so will result in water leakage. (Fig. 2-60)




Fig. 2-60

- Do not use natural drainage.
- Do not install the pipe with an upward gradient from the connection port. This will cause the drain water to flow backward and leak when the unit is not operating. (Fig. 2-61)
- Do not apply force to the piping on the unit side when connecting the drain pipe. The pipe should not be allowed to hang unsupported from its connection to the unit. Fasten the pipe to a wall, frame, or other support as close to the unit as possible. (Fig. 2-62)
- Provide insulation for any pipes that are run indoors.




Fig. 2-61




Fig. 2-62

4-13-17. Checking the Drainage

After wiring and drain piping are completed, use the following procedure to check that the water will drain smoothly. For this, prepare a bucket and wiping cloth to catch and wipe up spilled water.

- (1) Connect power to the power terminal board (R, S terminals) inside the electrical component box.
- (2) Slowly pour about 500 cc of water into the drain pan to check drainage. (Fig. 2-63)
- (3) Short the check pin (CHK) on the indoor control board and operate the drain pump. Check the water flow through the transparent drain pipe and see if there is any leakage.
- (4) When the check of drainage is complete, open the check pin (CHK) and remount the tube cover.

CAUTION

Be careful since the fan will start when you short the pin on the indoor control board.




Fig. 2-63

4. Installation Instructions

● Ceiling Type (T1 Type)

4-13-18. Required Minimum Space for Installation and Service

(1) Dimensions of suspension bolt pitch and unit

Type \ Length	A	B	C
36, 45, 56	855	910	210
73	1125	1180	210
106, 140	1540	1595	210

Unit: mm




Fig. 2-64

(2) Refrigerant tubing • drain hose position





Fig. 2-65

(3) Unit opening position (Refrigerant tubing • drain hose • power inlet port • remote controller wiring inlet port)



*1 Use a compass saw, jig saw or similar tool and cut along the indented portion of the side panel.



*2 If the optional drain up kit is installed, this becomes the upper tubing outlet port. For details, refer to the manual for the optional part.

*3 If the remote controller wiring inlet port is changed to the left side or the left top side, relocate the rubber grommet to the left side. Use aluminum tape or similar material to seal the unused inlet port on the right side.

Fig. 2-66

4. Installation Instructions

(4) Wall and ceiling side opening position



Unit: mm

* If the optional drain up kit is installed, create a ø100 hole along the dotted line (part marked with * in figure).

Fig. 2-67

4-13-19. Suspending the Indoor Unit

- (1) Place the full-scale diagram (supplied) on the ceiling at the location where you want to install the indoor unit. Use a pencil to mark the drill holes (Fig. 2-68).




Fig. 2-68

- (2) Drill holes at the 4 points indicated on the full-scale diagram.
- (3) Depending on the ceiling type:
 - a) Insert suspension bolts (Fig. 2-69).
or
 - b) Use existing ceiling supports or construct a suitable support (Fig. 2-70).

WARNING

It is important that you use extreme care in supporting the indoor unit from the ceiling. Ensure that the ceiling is strong enough to support the weight of the unit. Before hanging the ceiling unit, test the strength of each attached suspension bolt.

- (4) Screw in the suspension bolts, allowing them to protrude from the ceiling (Figs. 2-69 and 2-70). The distance of each exposed bolt must be of equal length within 50 mm. (Fig. 2-71)
- (5) Before suspending the indoor unit, remove the 2 or 3 screws on the latch of the air-intake grilles, open the grilles, and remove them by pushing the claws of the hinges (Fig. 2-72). Then remove both side panels sliding them along the unit toward the front after removing the 2 attachment screws. (Fig. 2-73)

Pull out the air-intake grille pushing claws of the hinges




Fig. 2-72




Fig. 2-69




Fig. 2-70




Fig. 2-71




Fig. 2-73

4. Installation Instructions

- (6) Carry out the preparation for suspending the indoor unit.
The suspension method varies depending on whether there is a suspended ceiling or not. (Figs. 2-74 and 2-75)
- (7) Suspend the indoor unit as follows:
a) Mount 1 washer and 2 hexagonal nuts on each suspension bolt (Fig. 2-76).




Fig. 2-75




Fig. 2-74




Fig. 2-76

- b) Lift the indoor unit, and place it on the washers through the notches, in order to fix it in place. (Fig. 2-77)
- c) Tighten the 2 hexagonal nuts on each suspension bolt to suspend the indoor unit as shown in Fig. 2-78.




Fig. 2-77




Fig. 2-78

NOTE

The ceiling surface is not always level. Confirm that the indoor unit is evenly suspended.
For the installation to be correct, leave a clearance of about 10 mm between the ceiling panel and the ceiling surface and fill the gap with an appropriate insulation or filler material.

- (8) If the tubing and wiring are to go towards the rear of the unit, make holes in the wall. (Fig. 2-79)
- (9) Measure the thickness of the wall from the inside to the outside and cut PVC pipe at a slight angle to fit. Insert the PVC pipe in the wall. (Fig. 2-80)

NOTE

The hole should be made at a slight downward slant to the outside.




Fig. 2-79





Fig. 2-80

4. Installation Instructions

4-13-20. Duct for Fresh Air

There is a duct connection port (knock-out hole) at the right-rear of the top panel of the indoor unit for drawing in fresh air. If it is necessary to draw in fresh air, remove the cover by opening the hole and connecting the duct to the indoor unit through the connection port. (Fig. 2-81)



Unit: mm

Fig. 2-81

4-13-21. Shaping the Tubing

- The positions of the refrigerant tubing connections are shown in the figure below. (The tubing can be routed in 3 directions.) (Fig. 2-82)
- * When routing the tubing out through the top or right sides, knock out the appropriate parts in the top panel and cut notches in the side panel (Fig. 2-81).
- * When routing the tubing out through the top, the optional L-shape tubing kit is required.

If the tubing is to be routed out together, use a box cutter or similar tool to cut out the part of the rear cover indicated by the marked area (Fig. 2-83), to match the positions of the tubes. Then draw out the tubing.




Fig. 2-82




Fig. 2-83

4-13-22. Installing the Drain Pipe

- Prepare standard PVC pipe for the drain and connect it to the indoor unit drain pipe with the supplied hose clamps to prevent water leaks.

(1) Drain hose connection

- The drain hose is connected below the refrigerant tubing.

(2) Installing the drain hose

- To install the drain hose, first place 1 of the 2 hose bands over the unit drain port and the other hose band over the hard PVC pipe (not supplied). Then connect both ends of the supplied drain hose.
- On the unit drain side, grasp the hose band with pliers and insert the drain hose all the way to the base.



- Attach so that the hose band fastener is on the side of the drain port. (Fig. 2-85)
- Attach the hose bands so that each is approximately 5 to 25 mm from the end of the supplied drain hose.
- If other commercially available hose bands are used, the drain hose may become pinched or wrinkled and there is danger of water leakage. Therefore be sure to use the supplied hose bands. When sliding the hose bands, be careful to avoid scratching the drain hose.
- Do not use adhesive tape when connecting the supplied drain hose to the drain port (either on the main unit or the PVC pipe).
- Wrap the hose with the supplied drain hose insulation and use the 4 twist ties so that the hose is insulated with no gaps.
- Connect the drain pipe so that it slopes downward from the unit to the outside. (Fig. 2-84)





Fig. 2-84

4. Installation Instructions

- Never allow water traps to occur in the course of the piping.
- Insulate any piping inside the room to prevent dripping.
- After the drain piping, pour water into the drain pan to check that the water drains smoothly.
- If the drain hose is to be raised, use the optional drain up kit. The drain hose can be raised 60 cm above the top of the main unit.
(For details, refer to the manual for the optional part.)

- * If the drain hose is routed through the left side, refer to Fig. 2-82, and follow the procedure above to install the hose. Reattach the rubber stopper removed earlier onto the right side.

The rubber stopper can be inserted easily by using a screwdriver or similar tool to press the stopper into the drain port on the main unit. Press the stopper into the main unit drain port as far as it will go.



Check local electrical codes and regulations before wiring. Also, check any specified instruction or limitations.




Fig. 2-85

How to carry out power supply wiring

(1) Wiring connection ports

The power inlet ports are located at the rear and top.
The remote controller wiring inlet ports are located at the rear and top (for use with the wired remote controller).
For details, refer to Fig. 2-81. For the method used to insert the wiring, refer to Fig. 2-86.

Attach the supplied eyelet to the power wiring inlet port with adhesive material (field supply).
(Refer to Fig. 2-86)

Remote controller wiring and inter-unit control wiring inlet port

- * Insert the remote controller wiring and inter-unit control wiring into the electrical component box from the inlet port as shown in the figure.
This is done regardless of whether the wiring was inserted from the top, rear, or left side of the main unit.




Fig. 2-86



When removing the fastening bracket from the cover of the electrical component box, use caution to avoid dropping the bracket.

(2) How to carry out wiring

- Open the knock-out hole on the rear or top of the main unit.
Attach the supplied rubber grommet and pull the power wiring into the main unit.
- Feed the wiring into the wiring inlet port on the electrical component box.
Connect the wiring to the terminal plate and fasten in place with the supplied clamp.
- Perform electrical and grounding work in accordance with the package A/C power specifications, and following local electrical codes and regulations.

4. Installation Instructions

● Low Silhouette Ducted Type (F1 Type)

4-13-23. Required Minimum Space for Installation and Service

- This air conditioner is usually installed above the ceiling so that the indoor unit and ducts are not visible. Only the air intake and air outlet ports are visible from the unit bottom.
- The minimum space for installation and service is shown in Fig. 2-87 and Table 2-15.

Table 2-15

Unit: mm

Type	22, 28, 36, 45, 56	73, 90	106, 140, 160
A (Length)	780	1,080	1,560

- It is recommended that space be provided (450 × 450 mm) for checking and servicing the electrical system.
- The detailed dimensions of the indoor unit is shown in Fig. 2-88 and Table 2-16.

Table 2-16

Unit: mm

Dimension Type	A	B	C	D	No. of holes		G	H	I	G	K
					E	F					
22, 28, 36, 45, 56	646	500 (100 × 5)	700	780	18	12	73	96	300 (100 × 3)	492	161
73, 90	946	900 (100 × 9)	1,000	1,080	26	20	23	41	700 (100 × 7)	782	171
106, 140, 160	1,426	1,300 (100 × 13)	1,480	1,560	26	28	63	81	1,100 (100 × 11)	1,262	182

Power, inter-unit wiring

- ① Refrigerant tubing joint (liquid tube)
- ② Refrigerant tubing joint (gas tube)
- ③ Upper drain port VP25 (O.D. 32 mm)
- ④ Bottom drain port VP25 (O.D. 32 mm)
- ⑤ Suspension lug (4 – 12 × 37 mm)
- ⑥ Power supply outlet (2 – ø30 mm)
- ⑦ Fresh air intake port (ø150 mm)
- ⑧ Flange for flexible air outlet duct
- ⑨ Tube cover
- ⑩ Electrical component box
- ⑪ Wind pressure endurance
- ⑫ Flange for air intake duct
- ⑬ Filter

Unit: mm




Fig. 2-88

4. Installation Instructions

4-13-24. Suspending the Indoor Unit

Depending on the ceiling type:

- Insert suspension bolts (Fig. 2-89)
or
- Use existing ceiling supports or construct a suitable support (Fig. 2-90).




Fig. 2-89




Fig. 2-90

⚠ WARNING

It is important that you use extreme care in supporting the indoor unit inside the ceiling. Ensure that the ceiling is strong enough to support the weight of the unit. Before hanging the unit, test the strength of each attached suspension bolt.

- (1) When placing the unit inside the ceiling, determine the pitch of the suspension bolts referring to the dimensional data as shown in Fig. 2-87 and Table 2-16. Tubing must be laid and connected inside the ceiling when suspending the unit. If the ceiling is already constructed, lay the tubing into position for connection to the unit before placing the unit inside the ceiling.
- (2) Screw in the suspension bolts allowing them to protrude from the ceiling (Fig. 2-89).
(Cut the ceiling material, if necessary.)
- (3) Thread the 3 hexagonal nuts and 2 washers (field supply) onto each of the 4 suspension bolts (Figs. 2-91 and 2-92). Use 1 nut and 1 washer for the upper part, and 2 nuts and 1 washer for the lower part, so that the unit will not fall off the suspension lugs.




Fig. 2-91




Fig. 2-92

● This shows an example of installation.




Fig. 2-93

4. Installation Instructions

4-13-25. Installing the Drain Pipe

- (1) Prepare standard hard PVC pipe (O.D. 32 mm) for the drain and use the supplied hose band to prevent water leaks.
The PVC pipe must be purchased separately.
The transparent drain part on the unit allows you to check drainage. (Fig. 2-94)

CAUTION

- Do not use adhesive tape at the drain connection port on the indoor unit.
- Insert the drain pipe until it contacts the socket, and then secure it tightly with the hose band.
- Do not use the supplied drain hose bent at a 90° angle. (The maximum permissible bend is 45°.)
- Tighten the hose clamps so their locking nuts face upward. (Fig. 2-94)

- (2) After connecting the drain pipe securely, wrap the supplied packing and drain pipe insulator around the pipe, then secure it with the vinyl clamps. (Fig. 2-95)

NOTE

Make sure the drain pipe has a downward gradient (1/100 or more) and that there are no water traps.

CAUTION

- Do not install an air bleeder as this may cause water to spray from the drain pipe outlet. (Fig. 2-96)
- If it is necessary to increase the height of the drain pipe, the section directly after the connection port can be raised a maximum of 500 mm. Do not raise it any higher than 500 mm, as this could result in water leaks. (Fig. 2-97)
- Do not install the pipe with an upward gradient from the connection port. This will cause the drain water to flow backward and leak when the unit is not operating. (Fig. 2-98)
- Do not apply force to the piping on the unit side when connecting the drain pipe. The pipe should not be allowed to hang unsupported from its connection to the unit. Fasten the pipe to a wall, frame, or other support as close to the unit as possible. (Fig. 2-99)




Fig. 2-94




Fig. 2-95




Fig. 2-96




Fig. 2-97




Fig. 2-98




Fig. 2-99

4. Installation Instructions

4-13-26. Checking the Drainage

After wiring and drain piping are completed, use the following procedure to check that the water will drain smoothly. For this, prepare a bucket and wiping cloth to catch and wipe up spilled water.

- (1) Connect power to the power terminal board (R, S terminals) inside the electrical component box.
- (2) Remove the tube cover and slowly pour about 1,200 cc of water through the opening into the drain pan to check drainage.
- (3) Short-circuit the check pin (CHK) on the indoor control circuit board and operate the drain pump.
Check the water flow through the transparent drain port and see if there is any leakage.



Be careful since the fan will start when you short the pin on the indoor control board.

- (4) When the drainage check is complete, open the check pin (CHK) and remount the insulator and drain cap onto the drain inspection port.




Fig. 2-100

4-13-27. Installing the Air-intake Filter

- (1) Standard installation
Install the filter onto the intake port. (Fig. 2-101)




Fig. 2-101

- (2) If a duct is connected to the intake port:
First remove the bottom cover, then install the filter inside the unit. (Fig. 2-102)




Fig. 2-102

- (3) If the intake is on the bottom:
Remove the intake port chamber from the side, then reattach the chamber onto the bottom of the unit. (Fig. 2-103)




Fig. 2-103

4. Installation Instructions

4-13-28. Increasing the Fan Speed

If external static pressure is too great (due to long extension of ducts, for example), the air flow volume may drop too low at each air outlet. This problem may be solved by increasing the fan speed using the following procedure:

- (1) Remove 4 screws on the electrical component box and remove the cover plate.
- (2) Disconnect the fan motor sockets in the box.
- (3) Take out the booster cable (sockets at both ends) clamped in the box.
- (4) Securely connect the booster cable sockets between the disconnected fan motor sockets in step 2 (Fig. 2-104).





Fig. 2-104


- (5) Place the cable neatly in the box and reinstall the cover plate.

Indoor Fan Performance


22, 28, 36 Type




45, 56 Type




73, 90 Type



106 Type



140, 160 Type



NOTE HT: Using the booster cable

H: At shipment



Fig. 2-105

How to read the diagram

The vertical axis is the external static pressure (Pa) while the horizontal axis represents the air flow (m^3/minute). The characteristic curves for "HT", "H", "M" and "L" fan speed control are shown. The nameplate values are shown based on the "H" air flow. For the 73 type, the air flow is $18 \text{ m}^3/\text{minute}$, while the external static pressure is 49 Pa at "H" position. If external static pressure is too great (due to long extension of ducts, for example), the air flow volume may drop too low at each air outlet. This problem may be solved by increasing the fan speed as explained above.

4. Installation Instructions

● Low Silhouette Ducted Type (F2 Type)

4-13-29. Required Minimum Space for Installation and Service

- This air conditioner is usually installed above the ceiling so that the indoor unit and ducts are not visible. Only the air intake and air outlet ports are visible from the unit bottom.
- The minimum space for installation and service is shown in Fig. 2-106 and Table 2-17.

Table 2-17

Unit: mm

Type	22, 28, 36, 45, 56	60, 73, 90	106, 140, 160
A (Length)	867	1,067	1,467

- It is recommended that space be provided (450 × 450 mm) for checking and servicing the electrical system.
- The detailed dimensions of the indoor unit is shown in Fig. 2-107 and Table 2-18.

Table 2-18

Unit: mm

Type	A	B	C	D	E	F
22, 28, 36, 45, 56	867	800	450 (Pitch 150 × 3)	71	592	12
60, 73, 90	1,067	1,000	750 (Pitch 150 × 5)	21	792	16
106, 140, 160	1,467	1,400	1,050 (Pitch 150 × 7)	71	1,192	20






Fig. 2-106



- a) Refrigerant tubing joint (liquid tube)
- b) Refrigerant tubing joint (gas tube)
- c) Upper drain port VP25 (O.D. 32 mm)
 φ 200 flexible hose supplied
- d) Bottom drain port VP25 (O.D. 32 mm)
- e) Suspension lug (4 – 12 × 30 mm)
- f) Power supply outlet
- g) Fresh air intake port (φ150 mm)
- h) Flange for flexible air outlet duct
- i) Electrical component box
- j) Filter



Unit: mm

Fig. 2-107

4. Installation Instructions

4-13-30. Suspending the Indoor Unit

Depending on the ceiling type:

- Insert suspension bolts (Fig. 2-108)
or
- Use existing ceiling supports or construct a suitable support (Fig. 2-109).




Fig. 2-108




Fig. 2-109



WARNING

It is important that you use extreme care in supporting the indoor unit inside the ceiling. Ensure that the ceiling is strong enough to support the weight of the unit. Before hanging the unit, test the strength of each attached suspension bolt.

- (1) When placing the unit inside the ceiling, determine the pitch of the suspension bolts referring to the dimensional data as shown in Fig. 2-106 and Table 2-18. Tubing must be laid and connected inside the ceiling when suspending the unit. If the ceiling is already constructed, lay the tubing into position for connection to the unit before placing the unit inside the ceiling.
- (2) Screw in the suspension bolts allowing them to protrude from the ceiling (Fig. 2-108). (Cut the ceiling material, if necessary.)
- (3) Thread the 3 hexagonal nuts and 2 washers (field supply) onto each of the 4 suspension bolts (Figs. 2-110 and 2-111). Use 1 nut and 1 washer for the upper part, and 2 nuts and 1 washer for the lower part, so that the unit will not fall off the suspension lugs.




Fig. 2-110




Fig. 2-111

- This shows an example of installation.




Fig. 2-112

4. Installation Instructions

4-13-31. Installing the Drain Pipe

- Prepare standard hard PVC pipe (O.D. 32 mm) for the drain and use the supplied hose band to prevent water leaks. The PVC pipe must be purchased separately. The transparent drain part on the unit allows you to check drainage. (Fig. 2-113)

CAUTION

- Do not use adhesive tape at the drain connection port on the indoor unit.
- Insert the drain pipe until it contacts the socket, and then secure it tightly with the hose band.
- Do not use the supplied drain hose bent at a 90° angle. (The maximum permissible bend is 45°.)
- Tighten the hose clamps so their locking nuts face upward. (Fig. 2-113)

Align the wire of hose band without separating from the drain hose and tighten so that it does not contact the bead.




Fig. 2-113

- After connecting the drain pipe securely, wrap the supplied packing and drain pipe insulator around the pipe, then secure it with the vinyl clamps. (Fig. 2-114)




Fig. 2-114

NOTE

Make sure the drain pipe has a downward gradient (1/100 or more) and that there are no water traps.

CAUTION

- Do not install an air bleeder as this may cause water to spray from the drain pipe outlet. (Fig. 2-115)




Fig. 2-115

- If it is necessary to increase the height of the drain pipe, the section directly after the connection port can be raised a maximum of 500 mm. Do not raise it any higher than 500 mm, as this could result in water leaks. (Fig. 2-116)




Fig. 2-116

- Do not install the pipe with an upward gradient from the connection port. This will cause the drain water to flow backward and leak when the unit is not operating. (Fig. 2-117)




Fig. 2-117

- Do not apply force to the piping on the unit side when connecting the drain pipe. The pipe should not be allowed to hang unsupported from its connection to the unit. Fasten the pipe to a wall, frame, or other support as close to the unit as possible. (Fig. 2-118)




Fig. 2-118

4-13-32. Checking the Drainage

After wiring and drain piping are completed, use the following procedure to check that the water will drain smoothly. For this, prepare a bucket and wiping cloth to catch and wipe up spilled water.

- Connect power to the power terminal board (R, S terminals) inside the electrical component box.
- Remove the tube cover and slowly pour about 1,200 cc of water through the opening into the drain pan to check drainage.
- Short-circuit the check pin (CHK) on the indoor control circuit board and operate the drain pump. Check the water flow through the transparent drain port and see if there is any leakage.

CAUTION

Be careful since the fan will start when you short the pin on the indoor control board.

- When the drainage check is complete, open the check pin (CHK) and remount the insulator and drain cap onto the drain inspection port.




Fig. 2-119

4. Installation Instructions

4-13-33. Connecting Duct to Air Intake Port Side

- (1) First pull out a filter in the direction of the electrical equipment box in the unit. (Fig. 2-120)
The pre-installed filter will not be used any more.
- (2) Then remove the seal packing, bracket and filter attached to the side of the air intake port. (Fig. 2-120)
- (3) Install the duct (field supply).
See the figure for the dimension of the installation hole.
Use M5 self-tapping screws for installation. (Fig. 2-121)

NOTE

- Select an air-intake grille with a filter at a local shop.
- To get clean air and to extend the service life of the air conditioner, an air filter must be installed in the air intake.
For installation and cleaning the air filter, consult your dealer or service center.





Fig. 2-120



Type	G	H	J	K
22, 28, 36, 45, 56	600 (Pitch 150 × 4)	25	113	14
60, 73, 90	900 (Pitch 150 × 6)	25	13	18
106, 140, 160	1,350 (Pitch 150 × 9)	0	13	24

Fig. 2-121


4. Installation Instructions

4-13-34. External Static Pressure Setting

Choose one of the following methods from “a”, “b”, “c” or “d” as shown in the flow chart (within the dotted lines) and then make the setting accordingly.

- a. No setting modification..... : Use-as-is at shipment (there are cases in which the setting may differ from the shipment setting when reset after once setting the external static pressure.)
- b. Manual setting (set with the PC board)..... : For high static pressure. Switching method with the short-circuit connector.
- c. Manual setting (set with the wired remote controller) : Low static pressure ~ high static pressure
- d. Auto airflow volume setting (set on the wired remote controller) : Air outlet volume is automatically adjusted to the rated airflow volume with the auto airflow control drive.

Flow of External Static Pressure



NOTE

- (1) Check the following items before performing the setting-check operations or auto airflow volume operations.
 - 1) Check to make sure that the electrical wiring and ducting have been completed. Activate the stand-by mode. In particular, make sure that the closed damper located in the middle of the duct is open, if installed. Also, make sure that air filters have been installed inside the air inlet duct.
Check to make sure air is not leaking from the joints.
 - 2) If multiple air outlets and air inlets are included, adjust the airflow volume ratio of all of them until they meet the design airflow ratio.
 - 3) Make sure the address setting has been completed.
- (2) The operation check will be completed in approximately three minutes if the settings have been made correctly. The settings will be modified if they are out of the range of use (max. 30 mins.). If this is not completed within 31 minutes, check whether the air speed is set to "H" or not.

4. Installation Instructions

- (3) Refer to Table 2-20-1 and Fig. 2-123 for details on the relationship between the value of item code “b0” and the external static pressure.
- (4) When set in group control (connecting multiple indoor units with one wired remote controller), set each indoor unit to item code “b0”. When amending the setting after selecting [b. Manual setting] (due to airflow path changes, etc.), it is necessary to cancel [b. Manual setting] (disconnect short-circuit connector). When [b. Manual setting] has not been cancelled, [c. Manual setting] and [d. Auto airflow volume setting] will be activated if selected, but [b Manual setting] takes precedence when the power is switched back on after power outages, etc.
- (5) If this is not completed within 8 minutes, check the drive mode, air speed and air inlet temperature.
- (6) When set in group control (connecting multiple indoor units with one wired remote controller), the test run operations display will disappear once the external static pressure setting check or auto airflow volume control operation check have been completed for the main unit. Decisions on sub-unit complete are not possible. The test run operation display will disappear after one hour even if the external status pressure setting check or auto airflow volume control operation check have not been completed.

⚠ CAUTION

- Be sure to check that the external static pressure is within the range for use and then make the setting. Failure to observe this may result in insufficient airflow or water leakages. Refer to Fig. 2-123 for the external static pressure setting range.
- There are cases in which automatic variable dampers and other mounted items may trigger the P12 alarm on systems that modify the static pressure of outdoor units when the auto airflow volume control operations or setting check operations are carried out if high static pressure in the outdoor unit is lowered. In this event, lower the dampers, etc., so that the static pressure in the outdoor unit reaches its lowest level, and then carry out the auto airflow volume control operations or setting check operations.
- Be sure to set the [External Static Pressure Setting] once again after amending the airflow path for the duct or air outlet after setting the external static pressure.
- Set the air inlet temperature within the range for use. The auto airflow volume control will not function if the air inlet temperature is over 45°C or not in the fan mode.

4-13-34-1. How to Set on PC Board

1. Turn off the power breaker to halt the supply of electricity to the PC board.
2. Open the lid of electrical equipment box and check where the short-circuit pin on the indoor unit control PC board is located (Fig. 2-122)
3. Short circuit the applicable short-circuit pin in accordance with the selected short-circuit pin connected (Fig. 2-123).
 150 Pa : TP3 (2P: yellow) short-circuit
 140 Pa : TP1 (2P: red) short-circuit
 * Use the short-circuit connector (2P: yellow) supplied.

Table 2-19 Selection of connected short-circuit pins

External static pressure at the time of rated airflow volume	Short-circuit pin
Unusable	TP6 (2P: white)
150 Pa	TP3 (2P: yellow)
140 Pa	TP1 (2P: red)




Fig. 2-122

4. Installation Instructions

4-13-34-2. Operating the Timer Remote Controller (CZ-RTC2)

4-13-34-2-1. Setting Item Code “b0”

- Press and hold down the , and buttons simultaneously for 4 or more seconds.
(, the Unit No., Item Code and Detailed Data will blink on the remote controller's LCD display.)
- The indoor unit numbers in the group control will be sequentially displayed whenever the Unit Select button is pressed .
Only the fan motor for the selected indoor unit will operate during this.
- Specify the “b0” item code by pressing the / buttons for the temperature setting buttons and confirm the values.
(“-001” set at shipment)
- Press the / buttons for the time to amend the values for the set data.
Refer to table 2-20-1 and Fig. 2-123 and select a value between “0001” and “0015”.
Select “-002” if the auto airflow volume setting is activated.
- Press the button.
The display will stop blinking and remain illuminated.
- Press the button. The fan motor will stop operating and the LCD display will return to the normal stop mode.

4-13-34-2-2. Auto Airflow Volume Control Operations and External Static Pressure Setting-Check Operation

- Press and hold down the button for 4 or more seconds. “TEST” will be displayed on the remote controller's LCD display.
- Press the button to commence the test run.
[Test Run] will be displayed on the remote controller's LCD display.
- Select the fan mode and set it to “H” by pressing the button.


CAUTION

Auto airflow volume control operations and external static pressure setting-check operations will not be performed unless [H] has been selected for the fan mode.


- The fan motor will be activated and auto airflow volume control operations or external static pressure setting-check operations will commence.
The power of the airflow will change while these operations are in progress.
The external static pressure setting-check operations and auto airflow volume control operations will be completed in about 3 to 30 minutes.
The “TEST” display will be extinguished from the remote controller's LCD display.
- Press the button to halt the test run.

Table 2-20-1 Setting the external static pressure

Indoor unit		Item code
22, 28, 36, 45, 56, 60, 73, 90	106, 140, 160	b0
External static pressure of the rated air flow volume (Pa)		
150	150	00 15
140	140	00 14
130	130	00 13
120	120	00 12
100	110	00 11
70	100	00 08
60	70	00 06
50	50	00 05
30	30	00 03
10	10	00 01
No auto airflow volume setting		-001
Auto airflow volume setting		-002



* Failure to set this parameter may result in decreased airflow and condensation.




4. Installation Instructions


Indoor Fan Performance

		Item code " b0 "															
		00 15	00 14	00 13	00 12	00 11	00 08	00 06	00 05	00 03	00 01						
		Cooling	Heating	Cooling	Heating	Cooling	Heating	Cooling	Heating	Cooling	Heating	Cooling	Heating	Cooling	Heating	Cooling	Heating
Tap	15	H	H							Setting at shipment							
	14			H	H												
	13	M	M			H	H										
	12						H	H									
	11				M				H		H						
	8			M			M	M	M			H	H				
	6	L	L			M					M	M		H	H		
	5										M	M			H	H	
	3				L		L	L	L	L			M	M	M	H	H
	1			L		L					L	L	L	L		M	M
1-2														L	L	L	M
1-3																L	L


90 type




22, 28, 36, 45 types




106 type




56 type




140 type



60, 73 types



160 type




2

4. Installation Instructions

● Slim Low Static Ducted Type (M1 Type)

4-13-35. Required Minimum Space for Installation and Service

- This air conditioner is usually installed above the ceiling so that the indoor unit and ducts are not visible. Only the air intake and air outlet ports are visible from below.
- The minimum space for installation and service is shown in the diagram. (Fig. 2-124)
- *H dimension means the minimum height of the unit.
- Select the *H dimension such that a downward slope of at least 1/100 is ensured as indicated in “4-13-40. Installing the Drain Pipe”.



Unit: mm






Fig. 2-124



Frang for air inlet duct



1	Refrigerant tubing joint (narrow tube)
2	Refrigerant tubing joint (wide tube)
3	Upper and bottom drain port (O.D. 26mm)
4	Suspension lug
5	Power supply outlet (ø17)
6	Frang for air inlet duct
7	PI cover
8	Electrical component box
9	Filter
10	Inter-unit control wiring and control wiring for group control outlet (ø15)
11	Remote control wiring outlet (ø15)

unit : mm

Fig. 2-125

4. Installation Instructions

4-13-36. Preparations Before Installation

- (1) Confirm the positional relationship between the unit and suspension bolts. (Fig. 2-126)
- Install the inspection opening on the control box side where maintenance and inspection of the control box and drain pump are easy. Install the inspection opening also in the lower part of the unit.




Fig. 2-126

- (2) Make sure the range of the unit's external static pressure is not exceeded.
(See the technical documentation for the range of the external static pressure setting.)
- (3) Open the installation hole. (Pre-set ceilings)
- Once the installation hole is opened in the ceiling where the unit is to be installed, pass refrigerant piping, drain piping, transmission wiring, and remote controller wiring (It is not necessary if using a wireless remote controller) to the unit's piping and wiring holes. See " 5. HOW TO PROCESS TUBING ", " 4-13-40. Installing the Drain Pipe " and " 3. Electrical Wiring ".
- After opening the ceiling hole, make sure ceiling is level if needed. It might be necessary to reinforce the ceiling frame to prevent shaking. Consult an architect or carpenter for details.

4-13-37. For Bottom Intake

For bottom intake, replace the chamber lid and protection net in the procedure shown in the diagram.

- (1) Remove the frame filter assy.
Remove the chamber lid. (Fig. 2-127)
- (2) Refer to the diagram to attach the chamber lid and frame filter assy in the direction of the arrow. (Fig. 2-128)
Note: Attach the lid with the dummy holes downward.
- (3) Attach the frame filter assy (supplied) in the manner shown in the diagram. (Fig. 2-129)




Fig. 2-127




Fig. 2-128




Fig. 2-129

4. Installation Instructions

4-13-38. Installing the Duct

Connect the duct supplied in the field as shown in Fig. 2-130.

Air inlet side

- Attach the duct and intake-side flange (field supply).
- Connect the flange to the main unit with 10 - $\phi 3.1$ (Hole) screws.
- Wrap the intake-side flange and duct connection area with aluminum tape or something similar to prevent air escaping.



When attaching a duct to the intake-side, be sure to attach an air filter inside the air passage on the intake-side. (Use an air filter whose dust collecting efficiency is at least 50% in a gravimetric technique.)
The included filter is not used when the intake duct is attached.

Air outlet side

- Connect the duct according to the air outside of the outlet-side flange.
- Wrap the outlet-side flange and the duct connection area with aluminum tape or something similar to prevent air escaping.



- Be sure to insulate the duct to prevent condensation from forming. (Material: glass wool or polyethylene foam, 25 mm thick)
- Use electric insulation between the duct and the wall when using metal ducts to pass metal laths of the net or fence shape or metal plating into wooden buildings.
- Be sure to explain about the way of maintaining and cleaning local procurements (air filter, grille [both air outlet and suction grille], etc.) to your customer.




Fig. 2-130

4-13-39. Suspending the Indoor Unit

Depending on the ceiling type:

- Insert suspension bolts as shown in the diagram. (Fig. 2-131) or
- Use existing ceiling supports or construct a suitable support as shown in the diagram. (Fig. 2-132)



It is important that you use extreme care in supporting the indoor unit inside the ceiling. Ensure that the ceiling is strong enough to support the weight of the unit.
Before hanging the unit, test the strength of each attached suspension bolt.

- (1) When placing the unit inside the ceiling, determine the pitch of the suspension bolts referring to the dimensional data as shown in Fig. 2-124.

Tubing must be laid and connected inside the ceiling when suspending the unit. If the ceiling is already constructed, lay the tubing into position for connection to the unit before placing the unit inside the ceiling.

- (2) Screw in the suspension bolts allowing them to protrude from the ceiling as shown in Fig. 2-131. (Cut the ceiling material, if necessary.)
- (3) Thread the 3 hexagonal nuts and 2 washers (field supply) onto each of the 4 suspension bolts as shown in Fig. 2-133 and 2-134. Use 1 nut and 1 washer for the upper part, and 2 nuts and 1 washer for the lower part, so that the unit will not fall off the suspension lugs.




Fig. 2-131




Fig. 2-132




Fig. 2-133




Fig. 2-134

4. Installation Instructions

- (4) Adjust the height of the unit.
- (5) Check the unit is horizontally level.

CAUTION

- Make sure the unit is installed level using a level or a vinyl hose filled with water. In using a vinyl hose instead of a level, adjust the top surface of the unit to the surface of the water at both ends of the vinyl hose and adjust the unit horizontally. (One thing to watch out for in particular is if the unit is installed so that the slope is not in the direction of the drain piping, this might cause leaking.) (Fig. 2-135)

- (6) Tighten the upper nut.

4-13-40. Installing the Drain Pipe

- (1) Prepare standard hard PVC pipe (O.D. 26 mm) for the drain and use the supplied hose band to prevent water leaks. (Fig. 2-136)

The PVC pipe must be purchased separately.

The transparent drain part on the unit allows you to check drainage.

CAUTION

- Attach so that the hose band fastener is on the side of the drain port. (Fig. 2-136)
- Attach the hose bands so that each is approximately 5 to 25 mm from the end of the supplied drain hose. (Fig. 2-136)
- **Do not use adhesive at the drain connection port on the indoor unit.**
- Insert the drain pipe until it contacts the socket, as shown in the figure above, then secure it tightly with the hose band.
- **Do not use the supplied drain hose bent at a 90° angle. (The maximum permissible bend is 45°.)**
- Tighten the hose clamps so their locking nuts face in the horizontal direction.
- Make sure that the drain port is not a downward gradient from the joint section (may lead to abnormal noise).

NOTE

Make sure the drain pipe has a downward gradient (1/100 or more) and that there are no water traps.

CAUTION

- Do not install an air bleeder as this may cause water to spray from the drain pipe outlet. (Fig. 2-137)
- If it is necessary to increase the height of the drain pipe, the section directly after the connection port can be raised a maximum of 500 mm. Do not raise it any higher than 500 mm, as this could result in water leaks. (Fig. 2-138)
- Do not install the pipe with an upward gradient from the connection port. This will cause the drain water to flow backward and leak when the unit is not operating. (Fig. 2-139)





Fig. 2-135



Unit:mm
Fig. 2-136




Fig. 2-137




Fig. 2-138




Fig. 2-139

4. Installation Instructions

- Do not apply force to the piping on the unit side when connecting the drain pipe. The pipe should not be allowed to hang unsupported from its connection to the unit. Fasten the pipe to a wall, frame, or other support as close to the unit as possible. (Fig. 2-140)




Fig. 2-140

4-13-41. Checking the Drainage

After wiring and drain piping are completed, use the following procedure to check that the water will drain smoothly. For this, prepare a bucket and wiping cloth to catch and wipe up spilled water.

- (1) Connect power to the power terminal board (R, S terminals) inside the electrical component box.
- (2) Remove the eyelet cap and through the opening, slowly pour about 500 cc of water into the drain pan to check drainage.
- (3) Short the check pin (CHK) on the indoor control board and operate the drain pump. Check the water flow through the transparent drain port and see if there is any leakage.




Fig. 2-141



Be careful since the fan will start when you short the pin on the indoor control board.

- (4) When the check of drainage is complete, open the check pin (CHK) and remount the insulator and drain cap onto the drain inspection port.

4. Installation Instructions

4-13-42. Increasing the Fan Speed

■ For Short Circuit Connection

- The standard (before shipment) external static pressure is shown in the table below.
- When using with a higher static pressure, it is necessary to change to the high static pressure mode.


External static pressure

Type	22	28	36/45/56
Standard (Pa)	10	15	15
High static pressure (Pa)	30	30	40

When using with high static pressure mode, set the indoor unit control board as shown in Fig. 2-142.

Follow the below procedure while the unit is turned off.

- (1) Open the cover of the electrical box and confirm that it is the indoor unit control board.
 - (2) Connect the short circuit connector to the short circuit pin TP3 (2P: Yellow) of the indoor unit control board.
- In case of wired remote control setting, do not use the short circuit connector.



Indoor control board

Fig. 2-142










Fig. 2-143

4. Installation Instructions

4-13-44. Required Minimum Space for Installation and Service (224, 280 Types)

- This air conditioner is usually installed above the ceiling so that the indoor unit and ducts are not visible. Only the air intake and air outlet ports are visible from below.
- The minimum space for installation and service is shown in Fig. 2-146.
- It is recommended that space be provided (600 × 600 mm) for checking and servicing the electrical system.
- Fig. 2-147 shows the detailed dimensions of the indoor unit.


Unit: mm



Unit: mm

Fig. 2-146

2



Unit: mm

Fig. 2-147

4. Installation Instructions

4-13-45. Suspending the Indoor Unit

Depending on the ceiling type:

- Insert suspension bolts as shown in Fig. 2-148




Fig. 2-148

- Use existing ceiling supports or construct a suitable support as shown in Fig. 2-149.




Fig. 2-149



WARNING

It is important that you use extreme care in supporting the indoor unit inside the ceiling.

Ensure that the ceiling is strong enough to support the weight of the unit. Before hanging the unit, test the strength of each attached suspension bolt.

- (1) When placing the unit inside the ceiling, determine the pitch of the suspension bolts referring to the dimensional data given previously. (Figs. 2-144 and 2-145)

Tubing must be laid and connected inside the ceiling when suspending the unit. If the ceiling is already constructed, lay the tubing into position for connection to the unit before placing the unit inside the ceiling.

- (2) Screw in the suspension bolts allowing them to protrude from the ceiling as shown in Fig. 2-148. (Cut the ceiling material, if necessary.)
- (3) Suspend and fix the indoor unit using the 2 hexagonal nuts (field supply) and special washers (supplied with the unit) as shown in Fig. 2-150.





Fig. 2-150

■ RAP Valve Kit (Refrigerant Accumulation Protector Valve Kit) (CZ-P160RVK2)

When installing a E1 type indoor unit (either the 8-hp 224 type or 10-hp 280 type), you must also install the RAP Valve Kit (CZ-P160RVK2).

- Connect 2 RAP valve kits in parallel for 224 or 280 type.
- Secure the RAP valve kit using suspension bolts, etc. within 30 meters from the indoor unit.
- Do not place the RAP valve kit directly on the ceiling.



Note: This figure shows the valve body with the suspension hook and strainer assemblies installed.

Fig. 2-151

4. Installation Instructions

4-13-46. Installing the Refrigerant Tubing

The size of the refrigerant tubing is as shown in the table below.

Table 2-21

	224 Type	280 Type
Gas tube	ø19.05 (Braze connection)	ø22.22 (Braze connection)
Liquid tube	ø9.52 (Flare connection)	ø9.52 (Flare connection)

- When brazing the gas tubing, cool the tubing with dampened shopcloths as you work, as shown in the figure below, to protect the unit's thermistor from the heat generated by brazing.
- Be sure to insulate both the gas tubing and liquid tubing. In addition, wrap the supplied insulation material around the tubing joints, and fasten in place with vinyl tape or other means. Failure to insulate the tubing may result in water leakage from condensation.
- Plug all gaps at tube through-holes in the unit with insulation or a similar substance to prevent air leakage.
- When connecting an embedded ceiling type unit (like this one) to a refrigerant system where individual operation is possible, install 2 RAP valve kits (CZ-P160RVK2) in parallel.

(For details on connecting the RAP valve kit, refer to the manual that came with the kit.)




Fig. 2-152




Fig. 2-153

4-13-47. Installing the Drain Piping

- (1) Prepare standard hard PVC pipe (O.D. 32 mm) for the drain and use the supplied drain socket to prevent water leaks. The PVC pipe must be purchased separately. When doing this, apply adhesive for the PVC pipe at the connection point.
- (2) If connecting a drain joint (supplied) to the threaded drain port, first wrap the drain port threads with sealing tape, then connect the joint. (Fig. 2-154)
- (3) After connecting the drain pipe securely, wrap insulator (field supply) around the pipe.
- (4) Ensure the drain pipe has a downward gradient (1/100 or more) and prepare traps as indicated in Fig. 2-155.




Fig. 2-154




Fig. 2-155

4. Installation Instructions

- (5) Also, in another part of the pipe arrangement, prepare traps with an inspection plug to clean dust or debris that may cause leaking of water. (Fig. 2-156)
- (6) After connecting the drain piping, slowly pour water into the drain pan to check that the water drains smoothly.




Fig. 2-156

4-13-48. Caution for Ducting Work

- This unit has high static pressure (applicable external static pressure Max. 167 to 216 Pa (17–22 mm Aq). In the case of small pressure resistance (for instance, a short duct), install a damper for adjusting air flow volume as air flow volume / air flow noise increases.
- If the air conditioner is to be installed in a room such as an office or meeting room which needs a low sound level, provide a supply and return noise absorption chamber with an acoustic liner.
- Include an air filter (field supply) at the return duct.




Fig. 2-157

Indoor Fan Performance

How to Read the Diagram

The vertical axis is the External Static Pressure (Pa) while the horizontal axis represents the Air Flow (m^3/minute). The characteristic curve for the “H,” “Med,” and “Lo” fan speed control. The nameplate values are shown based on the “H” air flow. Therefore in the case of 73 Type, the flow is $23 \text{ m}^3/\text{minute}$, while the External Static Pressure is 190 Pa at “H” position. If the external static pressure is too great (due to long extension of duct, for example), the air flow volume may drop too low at each air outlet.

4-13-49. Increasing the Fan Speed (280 Type Only)

If external static pressure is too great (due to long extension of ducts, for example), the air flow volume may drop too low at each air outlet. This problem may be solved by increasing the fan speed using the following procedure:

- (1) Remove 4 screws on the electrical component box and remove the cover plate.
- (2) Disconnect the fan motor sockets in the box.
- (3) Take out 2 booster cables from option carton box (sockets at both ends).
- (4) Securely connect the booster cable's 2 sockets between the disconnected fan motor sockets in step 2 as shown in Fig. 2-158.
- (5) Place the cable neatly in the box and reinstall the cover plate.




Fig. 2-158




Fig. 2-159

4. Installation Instructions

- **1-Way Cassette Type (D1 Type)**

4-13-50. Preparation for Suspending

This unit uses a drain pump. Use a carpenter's level to check that the unit is level.

4-13-51. Suspending the Indoor Unit

- (1) The measurements of the ceiling hole and suspension bolt positions should be as shown in Fig. 2-160. The length of the suspension bolts should extend a minimum of 15 mm beyond the bottom of the unit suspension bracket. Refer to Fig. 2-165.
- (2) Use the full-scale installation diagram (printed on the package) to determine the suspension bolt pitch. The positional relationships between the suspension brackets and the unit, and between the brackets and the ceiling panel, should be as shown in Figs. 2-160 & 2-161.

- (3) Depending on the ceiling type:
- Insert suspension bolts as shown in Fig. 2-162




Fig. 2-162

or

- Use existing ceiling supports or construct a suitable support as shown in Fig. 2-163.



It is important that you use extreme care in supporting the indoor unit from the ceiling. Ensure that the ceiling is strong enough to support the weight of the unit. Before hanging the unit, test the strength of each attached suspension bolt.

- (4) Cut the ceiling material, if necessary. (Figs. 2-160 and 2-161)
- (5) If the system requires fresh air to be drawn into the unit, cut and remove the insulation (both externally and internally) at the location shown as (A) in Fig. 2-164.




Fig. 2-164




Fig. 2-160




Fig. 2-161




Fig. 2-163



4. Installation Instructions

4-13-52. Placing the Unit Inside the Ceiling

- (1) When suspending the unit, attach gauges A and B (with packaging pad) to the indoor unit suspension brackets using the supplied M5 screws (2 for each bracket) to create the ceiling opening dimensions.
- CAUTION**
- Tubing and wiring work will be necessary inside the ceiling after the unit has been suspended. Therefore, if the ceiling is already installed, perform tubing and wiring up to the connection position before suspending the unit.
- (2) Attach the special washers (supplied) and nuts (field supply) to the suspension bolts (4 locations).

- CAUTION**
- Use 3/8" or M10 nuts.
- The length of the suspension bolts should be such that there is clearance of at least 15 mm below the bottom of the bracket, as shown in Fig. 2-166. If the suspension bolts are too long, they will contact the ceiling panel and louver motor cover, making installation impossible.
- (3) Thread the 3 hexagonal nuts and 2 washers (field supply) onto each of the the 4 suspension bolts as shown in Fig. 2-166. Use 1 nut and 1 washer for the upper side, and 2 nuts and 1 washer for the lower side, so that the unit will not fall off the suspension lugs.
- (4) The indoor unit should be suspended from the suspension bolts (Fig. 2-166) so that the distance between the bottom of the suspension lug and the bottom surface of the ceiling is 17 to 22 mm. (Fig. 2-165) Clearance between the indoor unit and the bottom surface of the ceiling is adjustable after the ceiling panel is attached to the unit. Use gauges A and B to adjust the height of the indoor unit as shown below.

Supplied with the unit

Installation gauge (Use the packaging side pad.)		1	Gauge A (Install on tubing side.)
		1	Gauge B (Install on opposite side of tubing.)

- (5) The unit should be adjusted using water level or as shown in Fig. 2-167 so that the drain pipe side is slanted 5 mm lower than the opposite side.
- (6) After completing the adjustment of the clearance, fasten all upper and lower suspension nuts tightly.




Fig. 2-165




Fig. 2-166




Fig. 2-167

4. Installation Instructions

4-13-53. Installing the Drain Piping

- (1) Prepare standard hard PVC pipe (O.D. 32 mm) for the drain and use the supplied drain hose and hose band to prevent water leaks. The PVC pipe must be purchased separately. The unit's transparent drain port allows you to check drainage. (Fig. 2-168)

CAUTION

- Do not use adhesive at the drain connection port on the indoor unit.
- Insert the drain pipe until it contacts the socket, as shown in Fig. 2-168, then secure it tightly with the hose band.
- Tighten the hose clamps so their locking nuts face upward. (Fig. 2-168)
- Do not use the supplied drain hose bent at a 90° angle. (The maximum permissible bend is 45°.)

- (2) After checking the drainage, wrap the supplied packing and drain pipe insulator around the pipe, then secure it with the clamps. (Fig. 2-169)

NOTE

- Make sure the drain pipe has a downward gradient (1/100 or more) and that there are no water traps. (Fig. 2-170)

CAUTION

Do not install an air bleeder as this may cause water to spray from the drain pipe outlet. (Fig. 2-170)

- If it is necessary to increase the height of the drain pipe, the pipe can be raised a maximum of 590 mm from the bottom of the ceiling. Do not raise it any higher than 590 mm, as this could result in water leaks. (Fig. 2-171)
- Do not install the pipe with an upward gradient from the connection port. This will cause the drain water to flow backward and leak when the unit is not operating. (Fig. 2-172)
- Do not apply force to the piping on the unit side when connecting the drain pipe. The pipe should not be allowed to hang unsupported from its connection to the unit. Fasten the pipe to a wall, frame, or other support as close to the unit as possible. (Fig. 2-173)
- Provide insulation for any pipes that are run indoors.




Fig. 2-168




Fig. 2-169




Fig. 2-170




Fig. 2-171




Fig. 2-172




Fig. 2-173

4. Installation Instructions

4-13-54. Checking the Drainage

After wiring and drain piping are completed, use the following procedure to check that the water will drain smoothly. For this, prepare a bucket and wiping cloth to catch and wipe up spilled water.

- (1) Connect power to the power terminal board (R, S terminals) inside the electrical component box.
- (2) Short the check pin (CHK) on the indoor control board and operate the drain pump.



Be careful since the fan will start when you short the pin on the indoor control board.

- (3) Pour about 1,200 cc of water into the drain pan using a siphon pump through the air outlet grille. (Fig. 2-174)
Check the water flow through the transparent drain pipe and see if there is any leakage.
- (4) When the check of drainage is complete, open the check pin (CHK) and remount the insulator.




Fig. 2-174



Use 4 × 8 tapping screws to fasten the drainage cover. If the screws used are longer than 8 mm, it may make a hole in the drain pan and cause leakage.

Removing the side panel

- (1) Push the tab on both sides of the side panel inward (a) to disengage the tab (first stage) and move the panel horizontally (b).
- (2) Push the area in the vicinity of the tab (second stage) inward while holding both sides of the side panel to remove the side panel.




Fig. 2-175

● 2-Way Cassette Type (L1 Type)

4-13-55. Preparation for Suspending

This unit uses a drain pump. Use a carpenter's level to check that the unit is level.

4-13-56. Suspending the Indoor Unit

- (1) Follow the diagrams to make the holes in the ceiling.
- (2) Depending on the ceiling type:
 - Insert suspension bolts as shown in Fig. 2-176




Fig. 2-176




Fig. 2-177

or

- Use existing ceiling supports or construct a suitable support as shown in Fig. 2-177.



It is important that you use extreme care in supporting the indoor unit from the ceiling. Ensure that the ceiling is strong enough to support the weight of the unit. Before hanging the unit, test the strength of each attached suspension bolt.

4. Installation Instructions

- (3) Cut the ceiling material, if necessary.
(Refer to Figs. 2-178 and 2-179, and Table 2-22.)





Fig. 2-178



Adjust so that the distance between the indoor unit and the bottom surface of the ceiling is 60 to 65 mm.

Fig. 2-179

Table 2-22

Unit: mm

	A	B	C	D	E
22, 28, 36, 45, 56	1,020	920	840	440	480
73	1,320	1,220	1,140	550	590

- (4) If the system requires fresh air to be drawn into the unit, cut and remove the insulation (both externally and internally) at the location shown as (A) in Fig. 2-180.



When making the cuts to the insulation, be careful not to damage the drain pan.




Fig. 2-180

4-13-57. Placing the Unit Inside the Ceiling

- When placing the unit inside the ceiling, determine the pitch of the suspension bolts.
Tubing must be laid and connected inside the ceiling when suspending the unit. If the ceiling is already constructed, lay the tubing into position for connection to the unit before placing the unit inside the ceiling.
- Thread the 3 hexagonal nuts and 2 washers (field supply) onto each of the 4 suspension bolts as shown in Fig. 2-182. Use 1 nut and 1 washer for the upper side, and 2 nuts and 1 washer for the lower side, so that the unit will not fall off the suspension lugs.
- The distance between the unit and the opening in the ceiling and the distance between the bottom surface of the ceiling and the bottom surface of the flange of the unit should follow the dimensions given in Fig. 2-181. Use the supplied installation gauge to check.




Fig. 2-181




Fig. 2-182

4. Installation Instructions

4-13-58. Installing the Drain Piping

- (1) Prepare a standard hard PVC pipe (O.D. 32 mm) for the drain and use the supplied drain hose and hose band to prevent water leaks. The PVC pipe must be purchased separately.

When doing this, leave a gap between the drain socket and the PVC pipe to allow the drainage to be checked.

The unit's transparent drain port allows you to check the drainage. (Fig. 2-183)




Fig. 2-183

CAUTION

- Do not use adhesive at the drain connection port on the indoor unit.
- Insert the drain pipe until it contacts the socket, as shown in Fig. 2-183, then secure it tightly with the hose band.
- Tighten the hose clamps so their locking nuts face upward. (Fig. 2-183)
- Do not use the supplied drain hose bent at a 90° angle. (The maximum permissible bend is 45°.)

- (2) After checking the drainage, wrap the supplied packing and drain pipe insulator around the pipe, then secure it with the supplied clamps. (Fig. 2-184)

NOTE

Make sure the drain pipe has a downward gradient (1/100 or more) and that there are no water traps.




Fig. 2-184

CAUTION

- Do not install an air bleeder as this may cause water to spray from the drain pipe outlet. (Fig. 2-185)
- If it is necessary to increase the height of the drain pipe, the section directly after the connection port can be raised a maximum of 500 mm. Do not raise it any higher than 500 mm, as this could result in water leaks. (Fig. 2-186)
- Do not install the pipe with an upward gradient from the connection port. This will cause the drain water to flow backward and leak when the unit is not operating. (Fig. 2-187)
- Do not apply force to the piping on the unit side when connecting the drain pipe. The pipe should not be allowed to hang unsupported from its connection to the unit. Fasten the pipe to a wall, frame, or other support as close to the unit as possible. (Fig. 2-188)
- Provide insulation for any pipes that are run indoors.




Fig. 2-185




Fig. 2-186




Fig. 2-187




Fig. 2-188

4. Installation Instructions

4-13-59. Checking the Drainage

After wiring and drain piping are completed, use the following procedure to check that the water will drain smoothly. For this, prepare a bucket and wiping cloth to catch and wipe up spilled water.

- (1) Connect power to the power terminal board (R, S terminals) inside the electrical component box.
- (2) Remove the tube cover and through the opening, slowly pour about 1,200 cc of water into the drain pan to check the drainage.
- (3) Short the check pin (CHK) on the indoor control board and operate the drain pump. Check the water flow through the transparent drain port and see if there is any leakage.



CAUTION

Be careful since the fan will start when you short the pin on the indoor control board.

- (4) When the check of drainage is complete, open the check pin (CHK) and remount the tube cover. (Fig. 2-189)



CAUTION

To mount the tube cover, use 4 × 8 tapping screws.(Fig. 2-189) Do not use long screws as they may puncture the drain pan and cause water leakage.





Fig. 2-189

● Wall Mounted Type (K1 Type) 22, 28, 36 types

4-13-60. Remove the Rear Panel from the Unit

- (1) Remove and discard the set screw on the rear panel. (Fig. 2-190)
- (2) Press the 2 △ marks on the frame cover and disengage the stationary tabs from the frame. (Fig. 2-191)
- (3) Remove the rear panel.




Set screw only for transportation

Fig. 2-190

NOTE

Tubing can be extended in 5 directions as shown in Fig. 2-192. Select the direction you need providing the shortest run to the outside unit.

- When left tubing is to be done, switch the drain hose and drain cap. (For details, refer to "Switching drain hose and drain cap".)



△ marks
Fig. 2-191




Fig. 2-192

4. Installation Instructions

4-13-61. Make a Hole

- (1) Place the rear panel from the indoor unit on the wall at the location selected. Make sure the panel is horizontal, using a carpenter's level or tape measure to measure down from the ceiling. Wait until after cutting the hole before attaching the rear panel to the wall.
- (2) Determine which side of the unit you should make the hole for tubing and wiring. (Fig. 2-193)

NOTE

In the case of left-rear tubing, use the measurement points from the edge of the rear panel for precise placement of the hose outlet. (Fig. 2-193)

- (3) Before making the hole, check carefully that no studs or pipes are directly run behind the spot to be cut.

CAUTION

Also avoid areas where electrical wiring or conduits are located.

The above precautions are also applicable if tubing goes through the wall in any other location.

- (4) Using a sabre saw, key hole saw or hole-cutting drill attachment, cut a hole in the wall. (Fig. 2-194)

NOTE

Hole should be made at a slight downward slant to the outdoor side.

Table 2-23

Hole Dia. (mm)
S-22MK1E5 / S-28MK1E5 / S-36MK1E5
65

- (5) Measure the thickness of the wall from the inside edge to the outside edge and cut PVC pipe at a slight angle 6 mm shorter than the thickness of the wall. (Fig. 2-195)
- (6) Place the plastic cover over the end of the pipe (for indoor side only) and insert the pipe in the wall. (Fig. 2-196)




Fig. 2-193




Fig. 2-194

PVC pipe (Locally purchased)




Fig. 2-195




Fig. 2-196

4. Installation Instructions

4-13-62. Install the Rear Panel on the Wall

Be sure to confirm that the wall is strong enough to suspend the unit.

NOTE

Be sure to install the unit within the range of the wall.

If Wooden Wall

- (1) Attach the rear panel to the wall with the 8 screws provided. (Fig. 2-197)

If you are not able to line up the holes in the rear panel with the beam locations marked on the wall, use rawl plugs or toggle bolts to go through the holes on the panel or drill 5 mm dia. holes in the panel over the stud locations and then mount the rear panel.




Fig. 2-197




Fig. 2-198

- (2) Double check with a carpenter's level or tape measure that the panel is level. This is important to install the unit properly. (Fig. 2-198)
- (3) Make sure the panel is flush against the wall. Any space between the wall and unit will cause noise and vibration.

4-13-63. Remove the Grille to Install the Indoor Unit

Basically, these models can be installed and wired without removing the grille. If access to any internal part is needed, follow the steps as given below.

How to remove the grille

- (1) Grasp both ends of the air intake grille, and remove it by opening towards the front and pulling towards you. (Fig. 2-199)
- (2) Remove the 2 screws. (Fig. 2-200)
- (3) Press the 3 tabs at the top of the grille and the 3 tabs on the front face to separate the grille from the frame. (Fig. 2-201)
- (4) Pull the grille toward you to remove it.




Fig. 2-199




Fig. 2-200




Fig. 2-201

How to replace the grille

- (1) When installing the grille, place the bottom of the grille into the frame first. (Fig. 2-202)
Then insert the tabs on the top of the grille and on the front face into the frame.
- (2) Make sure that the grille and frame are firmly fitted together by engaging the tabs.
- (3) Affix the grille with the 2 previously removed screws. (Fig. 2-200)
- (4) Install the air intake grille.
 - (a) Allow the edge of the air intake grille to slide into the top of the indoor unit, and then insert it all the way inside. (Fig. 2-203)




Fig. 2-202




Fig. 2-203

4. Installation Instructions

- (b) Press the bottom right and left corners and center of the air intake grille to attach it to the indoor unit. (Fig. 2-204)

NOTE

Attach so that the round pins at the top right and left corners of the air intake grille are inserted into the grooves at the top right and left of the indoor unit.

4-13-64. Shape the Indoor Side Tubing

- (1) Arrangement of tubing by directions
 - a) Right or left tubing
Cut out the corner of the right/left frame with a hacksaw or the like. (Figs. 2-205 and 2-206)
 - b) Right-rear or left-rear tubing
In this case, the corner of the frame need not be cut.
- (2) To mount the indoor unit on the rear panel:
Hang the 2 mounting slots of the unit on the upper tabs of the rear panel. (Fig. 2-207)




Fig. 2-204




Fig. 2-205

Fig. 2-206




Fig. 2-207




Fig. 2-208




Fig. 2-209

Use this screw when connecting to ground the shield for the Inter-unit control wiring.

Protective ground screw (External Solenoid Valve Kit for 3WAY)




Fig. 2-210

4-13-65. Wiring Instructions

General precautions on wiring

- (1) Before wiring, confirm the rated voltage of the unit as shown on its nameplate, then carry out the wiring closely following the wiring diagram.
- (2) Provide a power outlet to be used exclusively for each unit, with a power supply disconnect and circuit breaker for overcurrent protection provided in the exclusive line.
- (3) To prevent possible hazard due to insulation failure, the unit must be grounded.
- (4) Each wiring connection must be done tightly and in accordance with the wiring system diagram. Wrong wiring may cause the unit to misoperate or become damaged.
- (5) Do not allow wiring to touch the refrigerant tubing, compressor, or any moving parts of the fan.
- (6) Unauthorized changes in the internal wiring can be very dangerous. The manufacturer will accept no responsibility for any damage or misoperation that occurs as a result of such unauthorized changes.

4-13-66. Wiring Instructions for Inter-unit Connections

- (1) Grasp both ends of the air intake grille, and remove it by opening toward the front and pulling it toward you.
- (2) Remove the screw on the right side cover plate and open the cover. (Fig. 2-208)
- (3) Insert the inter-unit wiring into the through-the-wall PVC pipe. Lead the power wiring into the room allowing approx. 25 cm to extend from the wall face. (Fig. 2-209)
- (4) Route the inter-unit wiring from the back of the indoor unit and pull it toward the front for connection. (Fig. 2-210)
- (5) Connect the inter-unit wiring to the corresponding terminals on the terminal plate (Fig. 2-210) while referring to the wiring diagram.

4. Installation Instructions

- (6) Be sure to secure the wiring with the provided clamp.

NOTE

When closing the air intake grille, press the bottom right and left corners and center. (Fig. 2-211)

WARNING

Loose wiring may cause the terminal to overheat or result in unit malfunction. A fire hazard may also exist.

Therefore, be sure all wiring is tightly connected.

When connecting each power wire to the corresponding terminal, follow the instructions "How to connect wiring to the terminal" and fasten the wire securely tight with the fixing screw of the terminal plate.

How to connect wiring to the terminal

a) For Indoor Unit

- (1) Cut the wire end with a cutting pliers, then strip the insulation to expose the wire about 8 mm.
See the label (Fig. 2-212) near the terminal plate.
- (2) Using a screwdriver, loosen the terminal screw on the terminal plate.
- (3) Insert the wire and tighten the terminal screw completely using a screwdriver.

b) For Outdoor Unit

■ For solid core wiring (or F-cable)

- (1) Cut the wire end with a cutting pliers, then strip the insulation to expose the solid wire about 25 mm. (Fig. 2-213)
- (2) Using a screwdriver, remove the terminal screw(s) on the terminal plate.
- (3) Using the pliers, bend the solid wire to form a loop suitable for the terminal screw.
- (4) Shape the loop wire properly, place it on the terminal plate and fix it securely with the removed terminal screw using a screwdriver.

■ For stranded wiring

- (1) Cut the wire end with a cutting pliers, then strip the insulation to expose the stranded wiring about 10 mm and tightly twist the wire ends. (Figs. 2-214 and 2-215)
- (2) Using a screwdriver, remove the terminal screw(s) on the terminal plate.
- (3) Using a ring connector fastener or pliers, securely clamp each stripped wire end with a ring connector. (Fig. 2-214)
- (4) Place the ring connector wire, and replace and tighten the removed terminal screw using a screwdriver. (Fig. 2-216)

4-13-67. Mounting

- (1) To install the indoor unit, mount the indoor unit onto the 2 tabs on the upper part of the rear plate.
- (2) Hold down the air discharge outlet and press the lower part of the indoor unit until it clicks to securely fasten to the 2 tabs on the lower part of the rear plate. (Fig. 2-217)




Fig. 2-211

Please refer to "How to replace the grille" for installing the air intake grille.

For indoor unit




Fig. 2-212

For outdoor unit




Fig. 2-213




Fig. 2-214

Fig. 2-215




Fig. 2-216




Fig. 2-217

4. Installation Instructions

NOTE

For tubing, choose either the right or left tubing direction and follow the steps below. This work can be made easier by placing padding material (such as styrofoam) at the rear right side of the indoor unit. (Fig. 2-218)

■ Right-side tubing

- (1) Shape the refrigerant tubing so that it can easily go into the wall hole. (Fig. 2-219)
- (2) Push the wiring, refrigerant tubing, and drain hose through the hole in the wall. Adjust the indoor unit so it is securely seated on the rear panel. (Fig. 2-220)
- (3) Carefully bend the tubing (if necessary) to run along the wall in the direction of the outdoor unit and then tape as far as the fittings. The drain hose should come straight down the wall to a point where water runoff won't stain the wall.
- (4) Connect the refrigerant tubing to the outdoor unit. (After performing a leak test on the connecting part, insulate it with the tubing insulation.) (Fig. 2-221)
- (5) Assemble the refrigerant tubing, drain hose, and inter-unit wiring as shown in Fig. 2-221.




Fig. 2-218

Fig. 2-219




Fig. 2-220




Fig. 2-221

■ Left-side tubing

- (1) Lead the tubing and drain hose through the wall, allowing sufficient length for connection. Then bend the tubing using a tube bender to make the attachment. (Fig. 2-222)
- (2) Switch the drain hose and drain cap.

Switching drain hose and drain cap

- (a) Locate the drain hose and the drain cap. (Fig. 2-223)
- (b) Remove the screws fastening the drain hose on the right side, and pull out the drain hose to remove it. (Fig. 2-223)
- (c) Apply moderate force to pull off the drain cap on the left side. (If you cannot pull it off by hand, use a long-nose pliers.)
- (d) Reattach the drain hose to the left side and the drain cap to the right side. (Fig. 2-224)




Fig. 2-222




Fig. 2-223




Fig. 2-224

4. Installation Instructions

Drain hose

Slide the drain hose fully onto the drain pan outlet until the drain hose edge is pushed into the insulation. Check that the screw holes in the drain bracket and the drain pan outlet are aligned and securely in contact, then fasten them with the screw. (After attaching the drain hose, check that it is attached securely.) (Fig. 2-225)

Drain cap

Use a Phillips screwdriver to push the drain cap in firmly. (If it is difficult to push in, wet the cap with water first.)

- (3) Install the indoor unit on the rear panel.
- (4) Connect the tubing and wiring led inside from outdoors.
- (5) After completing a leak test, bundle the tubing together with armoring tape and store it inside the tubing storage area at the back of the indoor unit and hold it with clamps. (Fig. 2-226)

To unmount indoor unit

Press the 2 \triangle marks on the lower part of the indoor unit and unlatch the tabs. Then lift the indoor unit and unmount. (Fig. 2-227)

4-13-68. Drain Hose

- a) The drain hose should be slanted downward to the outdoors. (Fig. 2-228)
- b) Never allow a trap to form in the course of the hose.
- c) If the drain hose will run in the room, insulate the hose with insulation* so that chilled condensation will not damage furniture or floors. (Fig. 2-229)

* Foamed polyethylene or its equivalent is recommended.



WARNING

Do not supply power to the unit or operate it until all tubing and wiring to the outside unit are completed.



Risk of Electric Shock




Fig. 2-225




Fig. 2-226




Fig. 2-227




Fig. 2-228




Fig. 2-229

4. Installation Instructions

● Wall Mounted Type (K1 Type) 45, 56, 73, 106 types

4-13-69. Remove the Rear Panel from the Unit

- (1) Remove and discard the set screw on the rear panel.
(Fig. 2-230)
- (2) Press the 2 Δ marks on the frame cover and disengage the stationary tabs from the frame. (Fig. 2-231)
- (3) Remove the rear panel by grasping the sections shown in Fig. 2-232 and pulling it in the direction shown by the arrow.

NOTE

Tubing can be extended in 6 directions as shown in Fig. 2-234. Select the direction you need providing the shortest run to the outside unit.

- When left tubing is to be done, switch the drain hose and drain cap. (For details, refer to "Switching drain hose and drain cap".)

4-13-70. Make a Hole

- (1) Place the rear panel from the indoor unit on the wall at the location selected. Make sure the panel is horizontal, using a carpenter's level or tape measure to measure down from the ceiling. Wait until after cutting the hole before attaching the rear panel to the wall.
- (2) Determine which side of the unit you should make the hole for tubing and wiring. (Fig. 2-235)

NOTE

In the case of left-rear tubing, use the measurement points 158 mm from the marked position on the rear panel for precise placement of the hose outlet. (Fig. 2-235)


- (3) Before making the hole, check carefully that no studs or pipes are directly run behind the spot to be cut.



CAUTION

Also avoid areas where electrical wiring or conduits are located.

The above precautions are also applicable if tubing goes through the wall in any other location.



Set screw only for transportation

Fig. 2-230




Fig. 2-231




Fig. 2-232




Fig. 2-233





Fig. 2-234



Unit: mm

Fig. 2-235

4. Installation Instructions

- (4) Using a sabre saw, key hole saw or hole-cutting drill attachment, cut a hole in the wall. See Table 2-24 and Fig. 2-236.

Table 2-24

Hole Dia.
80 mm

- (5) Measure the thickness of the wall from the inside edge to the outside edge and cut PVC pipe at a slight angle 6 mm shorter than the thickness of the wall. (Fig. 2-237)
- (6) Place the plastic cover over the end of the pipe (for indoor side only) and insert the pipe in the wall. (Fig. 2-238)

4-13-71. Install the Rear Panel on the Wall

Be sure to confirm that the wall is strong enough to suspend the unit.

There are a number of screw holes on the rear panel. Using the 8 screw holes with ⇐ mark is recommended to attach the rear panel securely to the wall.

NOTE

Be sure to install the unit within the range of the wall.

If Wooden Wall

- (1) Attach the rear panel to the wall with the 8 screws provided. (Fig. 2-239)
If you are not able to line up the holes in the rear panel with the beam locations marked on the wall, use rawl plugs or toggle bolts to go through the holes on the panel or drill 5 mm dia. holes in the panel over the stud locations and then mount the rear panel.
- (2) Double check with a carpenter’s level or tape measure that the panel is level. This is important to install the unit properly. (Fig. 2-240)
- (3) Make sure the panel is flush against the wall. Any space between the wall and unit will cause noise and vibration.

NOTE

Hole should be made at a slight downward slant to the outdoor side.





Fig. 2-236

PVC pipe (Locally purchased)



Cut at slight angle

Fig. 2-237




Fig. 2-238




Fig. 2-239




Fig. 2-240

4. Installation Instructions

4-13-72. Removing and Installing the Grille

Basically, these models can be installed and wired without removing the grille. If access to any internal part is needed, follow the steps as given below.

How to remove the grille

- (1) Open the front panel until it is nearly horizontal, grasp the sections near the front panel arms on both sides, and then remove the panel by pushing the arms towards the outside while pulling the panel towards you.
- If the front panel is difficult to remove, grasp both ends of it and lift it up slightly. Move it to the left and disengage the left arm, then move it to the right and disengage the right arm. (Fig. 2-241)
- (2) Lift the anti-mold filter up slightly to disengage it from the protrusions on the unit, and then pull downward to remove the filter from the unit. (Fig. 2-241)
- (3) Remove the 3 screws from the front of the unit and remove the screw covers on the bottom surface. Then remove the 2 screws. (Fig. 2-242)
- (4) Remove the screw on the right side cover plate and remove the cover. (Fig. 2-242)
- (5) Remove the lower flap by disengaging 4 pins of the lower flap in order. (Figs. 2-243 and 2-244)
- (The flap is so flexible that it can be easily removed.)
- (6) Lift up the grille in the direction shown by the arrow and pull the grille towards you to remove it. (Fig. 2-245)

How to replace the grille

- (1) While aligning the top edge of the grille with the frame, move the grille horizontally and insert the top and bottom into the frame.
- (2) Press the grille firmly with your hand to ensure no gap exists between the frame and grille.
- (3) Tighten the 6 screws. And fix the removed covers in place.
- (4) Grasp the sections near the front panel arms on both sides, and hold the front panel so that it is nearly horizontal. Push the arm shafts towards the outside so that they come into contact with the top of the indentations on the right and left sides of the air conditioner. Then push firmly until the arm shafts click into place. (Fig. 2-246)
- (5) Remount the lower flap.
- (In remounting the flap, it cannot be turned end for end because the right and left pins of the flap differ in form. (Fig. 2-244))
- (6) Insert the top of the anti-mold filter, and then secure the bottom of the filter with the protrusions on the unit.
- (7) When closing the front panel, push the central part of the front panel first and then press the bottom right and left corners in place until you feel a click. (Fig. 2-247)




Fig. 2-241




Fig. 2-242




Fig. 2-243




Fig. 2-244




Fig. 2-245




Fig. 2-246




Fig. 2-247

NOTE

Check that no gap exists between the frame and the grille.

4. Installation Instructions

4-13-73. Shape the Indoor Side Tubing

- (1) Arrangement of tubing by direction
 - a) Right or left tubing
Cut out the corner of the right/left frame with a hacksaw or the like. (Figs. 2-248 and 2-249)
 - b) Right-rear or left-rear tubing
In this case, the corner of the frame need not be cut.
- (2) To mount the indoor unit on the rear panel:
Hang the 3 mounting slots of the unit on the upper tabs of the rear panel. (Fig. 2-250)




Fig. 2-248




Fig. 2-249




Fig. 2-250

4-13-74. Wiring Instructions

General precautions on wiring

- (1) Before wiring, confirm the rated voltage of the unit as shown on its nameplate, then carry out the wiring closely following the wiring diagram.
- (2) Provide a power outlet to be used exclusively for each unit, with a power supply disconnect and circuit breaker for overcurrent protection provided in the exclusive line.
- (3) To prevent possible hazards due to insulation failure, the unit must be grounded.
- (4) Each wiring connection must be done tightly and in accordance with the wiring system diagram. Wrong wiring may cause the unit to misoperate or become damaged.
- (5) Do not allow wiring to touch the refrigerant tubing, compressor, or any moving parts of the fan.
- (6) Unauthorized changes in the internal wiring can be very dangerous. The manufacturer will accept no responsibility for any damage or misoperation that occurs as a result of such unauthorized changes.

4-13-75. Mounting

- (1) To install the indoor unit, mount the indoor unit onto the 3 tabs on the upper part of the rear plate.
- (2) Hold down the air discharge outlet and press the lower part of the indoor unit until it clicks to securely fasten to the 2 tabs on the lower part of the rear plate. (Fig. 2-251)




Fig. 2-251




Fig. 2-252

NOTE

For tubing, choose either the right or left tubing direction and follow the steps below. Also, extend the support on the back of the indoor unit as a stand to make your work easier. (Fig. 2-252)

4. Installation Instructions

■ Right-side tubing

- (1) Shape the refrigerant tubing so that it can easily go into the wall hole. (Fig. 2-253)
- (2) Push the wiring, refrigerant tubing, and drain hose through the hole in the wall. Adjust the indoor unit so it is securely seated on the rear panel. (Fig. 2-254)
- (3) Carefully bend the tubing (if necessary) to run along the wall in the direction of the outdoor unit and then tape as far as the fittings. The drain hose should come straight down the wall to a point where water runoff won't stain the wall.
- (4) Connect the refrigerant tubing to the outdoor unit. (After performing a leak test on the connecting part, insulate it with the tubing insulation. (Fig. 2-255)).
- (5) Assemble the refrigerant tubing, drain hose, and conduit (including inter-unit wiring) as shown in Fig. 2-256.




Fig. 2-253




Fig. 2-254




Fig. 2-255




Fig. 2-256

■ Left-side tubing

- (1) Lead the tubing and drain hose through the wall, allowing sufficient length for connection. Then bend the tubing using a tube bender to make the attachment. (Fig. 2-257)
- (2) Switch the drain hose and drain cap.

Switching drain hose and drain cap

- (a) Locate the drain hose and the drain cap. (Fig. 2-258)
- (b) Remove the screw fastening the drain hose on the right side, and pull out the drain hose to remove it. (Fig. 2-258)
- (c) Apply moderate force to pull off the drain cap on the left side. (If you cannot pull it off by hand, use a long-nose pliers.)
- (d) Reattach the drain hose to the left side and the drain cap to the right side. (Fig. 2-259)

Drain hose

Slide the drain hose fully onto the drain pan outlet. (It will be easy to slide when water is added.) Check that the screw holes in the drain bracket and the drain pan outlet are aligned and securely in contact, then fasten them with the screw. (After attaching the drain hose, check that it is attached securely.) (Fig. 2-260)

Drain cap

Use a Phillips head screwdriver to push the drain cap in firmly. (If it is difficult to push in, wet the cap with water first.)

- (3) Install the indoor unit on the rear panel.
- (4) Connect the tubing and wiring led inside from outdoors.
- (5) After completing a leak test, bundle the tubing together with armoring tape and store it inside the tubing storage area at the back of the indoor unit and hold it with clamps. (Figs. 2-259 and 2-261)




Fig. 2-257




Fig. 2-258




Fig. 2-259




Fig. 2-260




Fig. 2-261

4. Installation Instructions

To unmount indoor unit

- (1) Remove the screw cover on the bottom surface.
(Fig. 2-263)
- (2) Fasten the frame to the rear panel using the 2 supplied tapping screws 4 x 10 mm. (Fig. 2-263)
- (3) Press the 2 Δ marks on the lower part of the indoor unit and unlatch the tabs. Then lift the indoor unit and unmount.
(Fig. 2-262)


NOTE

Under normal conditions, the installation design calls for a less than 2 mm gap between the air conditioner unit and the wall.
Confirm that the gap is appropriate (less than 2 mm).

4-13-76. Drain Hose


- a) The drain hose should be slanted downward to the outdoors. (Fig. 2-264)
- b) Never form a trap in the course of the hose.
- c) If the drain hose will run in the room, insulate the hose with insulation* so that chilled condensation will not damage furniture or floors. (Fig. 2-265)

*Foamed polyethylene or its equivalent is recommended.



WARNING

Do not supply power to the unit or operate it until all tubing and wiring to the outside unit are completed.



Risk of Electric Shock




Fig. 2-262




Fig. 2-263




Fig. 2-264




Fig. 2-265

4. Installation Instructions

● Floor Standing Type (P1 Type) Concealed Floor Standing Type (R1 Type)

4-13-77. Required Minimum Space for Installation and Service

Install the unit where cooled or heated air from the unit can circulate well in the room. Do not put obstacles which may obstruct the air flow in front of the air intake and outlet grilles.




Fig. 2-266

NOTE

Ensure there is adequate space for maintenance of the electrical component box, air filter, and refrigerant tubes.


4-13-78. Dimensions and Part Names Floor Standing Type (P1 Type)

- ① 4- ϕ 12 holes (for fastening the indoor unit to the floor with screws)
- ② Air filter
- ③ Refrigerant connection outlet (liquid tube)
- ④ Refrigerant connection outlet (gas tube)
- ⑤ Level adjusting bolt
- ⑥ Drain outlet (20 A)
- ⑦ Power cord outlet (downward, rear)
- ⑧ Refrigerant tubing outlet (downward, rear)
- ⑨ Location for mounting the remote controller (remote controller can be attached within the room)

Table 2-25

Unit: mm

Length Type	A	B	C	Liquid tube	Gas tube
22, 28, 36	1065	665	632	ϕ 6.35	ϕ 12.7
45, 56	1380	980	947	ϕ 9.52	ϕ 15.88
73					



Unit: mm

Fig. 2-267


4. Installation Instructions

Concealed Floor Standing Type (R1 Type)

- ① 4-ø12 holes (for fastening the indoor unit to the floor with screws)
- ② Air filter
- ③ Refrigerant connection outlet (liquid tube)
- ④ Refrigerant connection outlet (gas tube)
- ⑤ Level adjusting bolt
- ⑥ Drain outlet (20A)
- ⑦ Flange for air-outlet duct

Table 2-26 Unit: mm

Length Type	A	B	C	D	E	F	Liquid tube	Gas tube
22, 28, 36	904	692	672	665	500	86	ø6.35	ø12.7
45, 56	1219	1007	1002	980	900	51	ø9.52	ø15.88
73								



Unit: mm

Fig. 2-268

NOTE

Make an opening in the housing of the unit so that maintenance service can be performed on the electrical component box, air filter, refrigerant tubing connection, and drain pipe.

4. Installation Instructions

4-13-79. Removing and Attaching the Front Panel (Floor Standing Type)

NOTE

A dew-prevention heater is secured behind the front panel. When removing or attaching the panel, take care not to damage the lead wire to the heater.

How to remove the front panel

- (1) Remove the 2 screws at the lower part of the front panel.
- (2) Holding **A** at the upper right of the unit, push up **B** at the lower right of the panel. The right side of the front panel is removed. Then remove the left side of the front panel following the same procedure.
- (3) Disengage the lead wire connector (2P red) for the dew-prevention heater.
- (4) Remove the string connecting the front panel of the unit by unhooking it from the fixture attached to the panel.

How to attach the front panel

- (1) Hook the string to the fixture of the front panel.
- (2) Connect the lead wire connector.
- (3) Align the slots at the lower part of the front panel to the tabs at the lower part of the indoor unit and put the upper trim tab of the front panel on the groove of the unit. Then press down the panel.
- (4) Insert the 2 screws at the lower part of the front panel.

4-13-80. Installing the Refrigerant Tubing

- (1) When connecting the gas tube use the supplied tubing.
- (2) Tubes can be extended in 2 directions: downward and at rear.

For Floor Standing type

- When a rear tube is required, it can run through the rear-tube outlet of the rear panel.
- When a downward tube is required, refer to the opening dimensions shown in Fig. 2-271.



CAUTION

Insulate both gas and liquid tubes.

- To insulate tubes
- (1) Wrap the flare nuts with the supplied white insulating tape.
 - (2) Wrap the flare nuts with the supplied flare insulator.
 - (3) Fill the clearance between the union insulator and flare insulator with black insulating tape. Fasten both ends of the flare insulator with the supplied vinyl clamps.




Fig. 2-269




Fig. 2-270




Fig. 2-271




Fig. 2-272




Fig. 2-273

4. Installation Instructions

4-13-81. Installing the Drain Piping



CAUTION

Water leaks may occur if the drain pipes are connected inadequately.

- (1) When rear-side drain piping is required bend the drain hose attached to the indoor unit by 90°. Connect a drain pipe (field supply) to the drain hose through the rear tubing outlet in the rear panel. Use a hard PVC pipe (O.D. 25 mm) for the drain piping.
- (2) Ensure that the drain pipe has a downward gradient of 1/100 or more and that there are no water traps.
- (3) Provide insulation for the drain pipe.
- (4) After the drain piping is completed, pour water into the drain pan to check that the water drains smoothly.
- (5) Remove any dust or debris in the drain pan so that the pipe is not clogged.




Fig. 2-274

4-13-82. Installing the Remote Controller

A remote controller (optional wired remote controller) can be mounted in the indoor unit (Floor Standing type).

- (1) Remove the cover of the optional wired remote controller. (Fig. 2-275)
- (2) Remove the front panel. Remove the screws and fixture. (Fig. 2-276)
- (3) Place the remote controller into the space in the unit as shown in Fig. 2-276. Assemble the lead wires of the remote controller to its rear side center and route them to the lead wire guide.
- (4) Secure the fixture using the supplied screws.




Fig. 2-275

To remove the cover from the remote controller, insert a screwdriver between the cover and the controller as shown in the figure above, and pry off the cover.




Fig. 2-276

5. HOW TO PROCESS TUBING

The liquid tubing side is connected by a flare nut, and the gas tubing side is connected by brazing.

5-1. Connecting the Refrigerant Tubing

Use of the Flaring Method

Many of conventional split system air conditioners employ the flaring method to connect refrigerant tubes which run between indoor and outdoor units. In this method, the copper tubes are flared at each end and connected with flare nuts.

Flaring Procedure with a Flare Tool

- (1) Cut the copper tube to the required length with a tube cutter. It is recommended to cut approx. 30 – 50 cm longer than the tubing length you estimate.
- (2) Remove burrs at each end of the copper tubing with a tube reamer or file. This process is important and should be done carefully to make a good flare. Be sure to keep any contaminants (moisture, dirt, metal filings, etc.) from entering the tubing. (Figs. 2-277 and 2-278)

NOTE

When reaming, hold the tube end downward and be sure that no copper scraps fall into the tube. (Fig. 2-278)

- (3) Remove the flare nut from the unit and be sure to mount it on the copper tube.
- (4) Make a flare at the end of copper tube with a flare tool. (Fig. 2-279)

NOTE

A good flare should have the following characteristics:

- Inside surface is glossy and smooth
- Edge is smooth
- Tapered sides are of uniform length

Caution Before Connecting Tubes Tightly

- (1) Apply a sealing cap or water-proof tape to prevent dust or water from entering the tubes before they are used.
 - (2) Be sure to apply refrigerant lubricant (ether oil) to the inside of the flare nut before making piping connections. This is effective for reducing gas leaks. (Fig. 2-280)
 - (3) For proper connection, align the union tube and flare tube straight with each other, then screw in the flare nut lightly at first to obtain a smooth match. (Fig. 2-281)
- Adjust the shape of the liquid tube using a tube bender at the installation site and connect it to the liquid tubing side valve using a flare.

Cautions During Brazing

- Replace air inside the tube with nitrogen gas to prevent copper oxide film from forming during the brazing process. (Oxygen, carbon dioxide and Freon are not acceptable.)
- Do not allow the tubing to get too hot during brazing. The nitrogen gas inside the tubing may overheat, causing refrigerant system valves to become damaged. Therefore allow the tubing to cool when brazing.
- Use a reducing valve for the nitrogen cylinder.
- Do not use agents intended to prevent the formation of oxide film. These agents adversely affect the refrigerant and refrigerant oil, and may cause damage or malfunctions.




Fig. 2-277




Fig. 2-278




Fig. 2-279




Fig. 2-280




Fig. 2-281

5. HOW TO PROCESS TUBING

5-2. Connecting Tubing Between Indoor and Outdoor Units

- (1) Tightly connect the indoor-side refrigerant tubing extended from the wall with the outdoor-side tubing.
- (2) To fasten the flare nuts, apply specified torque as at right:

- When removing the flare nuts from the tubing connections, or when tightening them after connecting the tubing, be sure to use 2 adjustable wrenches or spanners as shown. (Fig. 2-282)

If the flare nuts are over-tightened, the flare may be damaged, which could result refrigerant leakage and cause injury or asphyxiation to room occupants.

- For the flare nuts at tubing connections, be sure to use the flare nuts that were supplied with the unit, or else flare nuts for R410A (type 2).
The refrigerant tubing that is used must be of the correct wall thickness as shown in the table at right.
- In order to prevent damage to the flare caused by over-tightening of the flare nuts, use the table above as a guide when tightening.
- When tightening the flare nut on the liquid tube, use an adjustable wrench with a nominal handle length of 200 mm.




Fig. 2-282

Tube diameter	Tightening torque, approximate	Tube thickness
ø6.35 (1/4")	14 – 18 N · m (140 – 180 kgf · cm)	0.8 mm
ø9.52 (3/8")	34 – 42 N · m (340 – 420 kgf · cm)	0.8 mm
ø12.7 (1/2")	49 – 61 N · m (490 – 610 kgf · cm)	0.8 mm
ø15.88 (5/8")	68 – 82 N · m (680 – 820 kgf · cm)	1.0 mm
ø19.05 (3/4")	100 – 120 N · m (1000 – 1200 kgf · cm)	1.2 mm


Because the pressure is approximately 1.6 times higher than conventional refrigerant pressure, the use of ordinary flare nuts (type 1) or thin-walled tubes may result in tube rupture, injury, or asphyxiation caused by refrigerant leakage.

5-3. Insulating the Refrigerant Tubing

Tubing Insulation

- Standard Selection of Insulation Material
Under the environment of the high temperature and high humidity, the surface of the insulation material is easy to become condensation. This will result in leakage and dew drop. Refer to the chart shown below when selecting the insulation material.
In case that the ambient temperature and relative humidity are placed above the line of the insulation thickness, the condensation may occasionally make a dew drop on the surface of the insulation material. In this case, select the better insulation efficiency.
- * However, since the condition will be different due to the sort of the insulator material and the environmental condition of the installation place, see the chart shown below as a reference when making a selection.

Two tubes arranged together



Three tubes arranged together





Fig. 2-283

Standard Selection of Tubing Insulation

Calculating condition	
Sort of insulation material	Polyethylene heat resisting material
Thermal conductivity of insulation material	Based on JIS A9501
Calculating formula used when calculating thickness	Based on JIS A9501
Refrigerant temperature	2°C

5. HOW TO PROCESS TUBING

2



5. HOW TO PROCESS TUBING



CAUTION

If the exterior of the outdoor unit valves has been finished with a square duct covering, make sure you allow sufficient space to use the valves and to allow the panels to be attached and removed.

Taping the flare nuts

Wind the white insulation tape around the flare nuts at the gas tube connections. Then cover up the tubing connections with the flare insulator, and fill the gap at the union with the supplied black insulation tape. Finally, fasten the insulator at both ends with the supplied vinyl clamps. (Fig. 2-284)

Insulation material

The material used for insulation must have good insulation characteristics, be easy to use, be age resistant, and must not easily absorb moisture.



CAUTION

After a tube has been insulated, never try to bend it into a narrow curve because it can cause the tube to break or crack.

Never grasp the drain or refrigerant connecting outlets when moving the unit.

5-4. Taping the Tubes

- (1) At this time, the refrigerant tubes (and electrical wiring if local codes permit) should be taped together with armoring tape in 1 bundle. To prevent the condensation from overflowing the drain pan, keep the drain hose separate from the refrigerant tubing.
- (2) Wrap the armoring tape from the bottom of the outdoor unit to the top of the tubing where it enters the wall. As you wrap the tubing, overlap half of each previous tape turn.
- (3) Clamp the tubing bundle to the wall, using 1 clamp approx. each meter. (Fig. 2-286)

NOTE

Do not wind the armoring tape too tightly since this will decrease the heat insulation effect. Also ensure that the condensation drain hose splits away from the bundle and drips clear of the unit and the tubing.

5-5. Finishing the Installation

After finishing insulating and taping over the tubing, use sealing putty to seal off the hole in the wall to prevent rain and draft from entering. (Fig. 2-287)




Fig. 2-284




Fig. 2-285




Fig. 2-286




Fig. 2-287

6. AIR PURGING

Air and moisture in the refrigerant system may have undesirable effects as indicated below.

- pressure in the system rises
- operating current rises
- cooling (or heating) efficiency drops
- moisture in the refrigerant circuit may freeze and block capillary tubing
- water may lead to corrosion of parts in the refrigerant system

Therefore, the indoor unit and tubing between the indoor and outdoor unit must be leak tested and evacuated to remove any noncondensables and moisture from the system.

■ Air Purging with a Vacuum Pump (for Test Run) Preparation

Check that each tube (both liquid and gas tubes) between the indoor and outdoor units have been properly connected and all wiring for the test run has been completed. Remove the valve caps from both the gas and liquid service valves on the outdoor unit. Note that both liquid and gas tube service valves on the outdoor unit are kept closed at this stage.

2

Leak test

- (1) With the service valves on the outdoor unit closed, remove the 1/4 in. flare nut and its bonnet on the gas tube service valve. (Save for reuse.)
- (2) Attach a manifold valve (with pressure gauges) and dry nitrogen gas cylinder to this service port with charge hoses.



CAUTION

Use a manifold valve for air purging. If it is not available, use a stop valve for this purpose. The “Hi” knob of the manifold valve must always be kept closed.

- (3) Pressurize the system to no more than 3.8 MPa with dry nitrogen gas and close the cylinder valve when the gauge reading reaches 3.8 MPa. Then, test for leaks with liquid soap.



CAUTION

To avoid nitrogen entering the refrigerant system in a liquid state, the top of the cylinder must be higher than the bottom when you pressurize the system. Usually, the cylinder is used in a vertical standing position.

Manifold gauge




Fig. 2-288

Vacuum pump




Fig. 2-289




Fig. 2-290

6. AIR PURGING

- (4) Do a leak test of all joints of the tubing (both indoor and outdoor) and both gas and liquid service valves. Bubbles indicate a leak. Wipe off the soap with a clean cloth after a leak test.
- (5) After the system is found to be free of leaks, relieve the nitrogen pressure by loosening the charge hose connector at the nitrogen cylinder. When the system pressure is reduced to normal, disconnect the hose from the cylinder.

Evacuation

- (1) Attach the charge hose end described in the preceding steps to the vacuum pump to evacuate the tubing and indoor unit. Confirm that the "Lo" knob of the manifold valve is open. Then, run the vacuum pump. The operation time for evacuation varies with the tubing length and capacity of the pump. The following table shows the amount of time for evacuation:

Required time for evacuation when 30 gal/h vacuum pump is used	
If tubing length is less than 15 m	If tubing length is longer than 15 m
45 min. or more	90 min. or more

NOTE

The required time in the above table is calculated based on the assumption that the ideal (or target) vacuum condition is less than -101 kPa (-755 mmHg, 5 Torr).

- (2) When the desired vacuum is reached, close the "Lo" knob of the manifold valve and turn off the vacuum pump. Please confirm that the gauge pressure is under -101 kPa (-755 mmHg, 5 Torr) after 4 to 5 minutes of vacuum pump operation.



CAUTION

Use a cylinder designed for use with R410A respectively.




Fig. 2-291

6. AIR PURGING

Charging additional refrigerant

- Charging additional refrigerant (calculated from the liquid tube length as shown in Section “1-8. Additional Refrigerant Charge”) using the liquid tube service valve. (Fig. 2-292)
- Use a balance to measure the refrigerant accurately.
- If the additional refrigerant charge amount cannot be charged at once, charge the remaining refrigerant in liquid form by using the gas tube service valve with the system in cooling operation mode at the time of test run. (Fig. 2-293)

Finishing the job

- (1) With a hex wrench, turn the liquid tube service valve stem counter-clockwise to fully open the valve.
- (2) Turn the gas tube service valve stem counter-clockwise to fully open the valve.

2

**CAUTION**

To avoid gas from leaking when removing the charge hose, make sure the stem of the gas tube is turned all the way out (“BACK SEAT” position).

- (3) Loosen the charge hose connected to the gas tube service port (1/4 in.) slightly to release the pressure, then remove the hose.
- (4) Replace the 1/4 in. flare nut and its bonnet on the gas tube service port and fasten the flare nut securely with an adjustable wrench or box wrench. This process is very important to prevent gas from leaking from the system.
- (5) Replace the valve caps at both gas and liquid service valves and fasten them securely.

This completes air purging with a vacuum pump.
The airconditioner is now ready for a test run.




Fig. 2-292




Fig. 2-293

7. Optional Parts

7-1. Distribution Joint Kits


■ CZ-P160BK2 (for R410A)

How to Attach Distribution Joint

1. Accompanying Parts

Check the contents of your distribution joint kit.

2. Distribution Joint Kits (with insulation)



- Size of connection point on each part (Shown are inside diameters of tubing)

Size	mm	Inch
Part A	ø19.05	3/4
Part B	ø15.88	5/8
Part C	ø12.7	1/2
Part D	ø9.52	3/8
Part E	ø6.35	1/4

3. Making Branch Connections

- For branching tubes, install 150mm or larger (including reducer) straight tubing up to the point where the tube branches (or after the point where the tubes join together). (Fig. 2-294)
- Using a tube cutter, cut the joints at the diameter required to match the outside diameter of the tubing you are connecting. (This is usually done at the installation site.)

The tube diameter depends on the total capacity of the indoor unit. Note that you do not have to cut the joints if it already matches the tubing end size. For size selection of the tube diameter, refer to the installation instructions provided with the outdoor unit.

NOTE

Avoid forceful cutting that may harm the shape of the joints or tubing. (Inserting the tubing will not be possible if the tube shape is not proper.)

- Cut off as far away from stopper as possible. (Fig. 2-295)
- After cutting the joints, be sure to remove burrs on the inside of the joints. (If the joints have been squashed or dented badly, reshaped them using a tube spreader.)
- Make sure there is no dirt or other foreign substances inside the distribution joint.
- The distribution joint can be either horizontal or vertical. (Fig. 2-296)
In the case of horizontal, the L-shaped tubing must be slanted slightly upward (15° to 30°).
- When brazing a pipe E to the reducer of which middle pipe inner dimension is D as shown above chart, cut the middle pipe as long as possible so that the pipe E can be inserted.
- When brazing, replace air inside the tube with nitrogen gas to prevent copper oxide from forming.
- To insulate the distribution joint, use the supplied tubing insulation. (If using insulation other than that supplied, make sure that its heat resistance is 120 °C or higher.)
- For additional details, refer to the installation instructions provided with the outdoor unit.




Fig. 2-294






Fig. 2-295



In case of horizontal position



In case of vertical position
(directed upward)

Fig. 2-296

7. Optional Parts


■ CZ-P680BK2 (for R410A)

How to Attach Distribution Joint

1. Accompanying Parts

Check the contents of your distribution joint kit.

2. Distribution Joint Kits (with insulation)



- Size of connection point on each part (Shown are inside diameters of tubing)

Size	mm	Inch
Part A	ø28.58	1-1/8
Part B	ø25.4	1
Part C	ø22.22	7/8
Part D	ø19.05	3/4
Part E	ø15.88	5/8
Part F	ø12.7	1/2
Part G	ø9.52	3/8
Part H	ø6.35	1/4

3. Making Branch Connections

- For branching tubes, install 150mm or larger (including reducer) straight tubing up to the point where the tube branches (or after the point where the tubes join together). (Fig. 2-297)
- Using a tube cutter, cut the joints at the diameter required to match the outside diameter of the tubing you are connecting. (This is usually done at the installation site.)

The tube diameter depends on the total capacity of the indoor unit. Note that you do not have to cut the joints if it already matches the tubing end size. For size selection of the tube diameter, refer to the installation instructions provided with the outdoor unit.

NOTE

Avoid forceful cutting that may harm the shape of the joints or tubing. (Inserting the tubing will not be possible if the tube shape is not proper.)

- Cut off as far away from stopper as possible. (Fig. 2-298)
- After cutting the joints, be sure to remove burrs on the inside of the joints. (If the joints have been squashed or dented badly, reshaped them using a tube spreader.)
- Make sure there is no dirt or other foreign substances inside the distribution joint.
- The distribution joint can be either horizontal or vertical. (Fig. 2-299) In the case of horizontal, the L-shaped tubing must be slanted slightly upward (15° to 30°).
- When brazing, replace air inside the tube with nitrogen gas to prevent copper oxide from forming.
- To insulate the distribution joint, use the supplied tubing insulation. (If using insulation other than that supplied, make sure that its heat resistance is 120 °C or higher.)
- For additional details, refer to the installation instructions provided with the outdoor unit.




Fig. 2-297






Fig. 2-298



In case of horizontal position



In case of vertical position
(directed upward or downward)

Fig. 2-299

7. Optional Parts


■ CZ-P1350BK2 (for R410A)

How to Attach Distribution Joint

1. Accompanying Parts

Check the contents of your distribution joint kit.

2. Distribution Joint Kits (with insulation)



- Size of connection point on each part (Shown are inside diameters of tubing)

Size	mm	Inch
Part A	ø38.1	1-1/2
Part B	ø31.75	1-1/4
Part C	ø28.58	1-1/8
Part D	ø25.4	1
Part E	ø22.22	7/8
Part F	ø19.05	3/4
Part G	ø15.88	5/8
Part H	ø12.7	1/2
Part I	ø9.52	3/8
Part J	ø6.35	1/4

3. Making Branch Connections

- For branching tubes, install 150mm or larger (including reducer) straight tubing up to the point where the tube branches (or after the point where the tubes join together). (Fig. 2-300)
- Using a tube cutter, cut the joints at the diameter required to match the outside diameter of the tubing you are connecting. (This is usually done at the installation site.)

The tube diameter depends on the total capacity of the indoor unit. Note that you do not have to cut the joints if it already matches the tubing end size. For size selection of the tube diameter, refer to the installation instructions provided with the outdoor unit.

NOTE

Avoid forceful cutting that may harm the shape of the joints or tubing. (Inserting the tubing will not be possible if the tube shape is not proper.)

- Cut off as far away from stopper as possible. (Fig. 2-301)
- After cutting the joints, be sure to remove burrs on the inside of the joints. (If the joints have been squashed or dented badly, reshaped them using a tube spreader.)
- Make sure there is no dirt or other foreign substances inside the distribution joint.
- When brazing, replace air inside the tube with nitrogen gas to prevent copper oxide from forming.
- To insulate the distribution joint, use the supplied tubing insulation. (If using insulation other than that supplied, make sure that its heat resistance is 120 °C or higher.)
- For additional details, refer to the installation instructions provided with the outdoor unit.




Fig. 2-300




Fig. 2-301

7. Optional Parts


■ CZ-P680PJ2, CZ-P1350PJ2 (for R410A)

How to Attach Distribution Joint

1. Accompanying Parts

Check the contents of your distribution joint kit.

2. Distribution Joint Kits (with insulation)



- Size of connection point on each part (Shown are inside diameters of tubing)

Size	Part A	Part B	Part C	Part D	Part E	Part F	Part G	Part H	Part I	Part J
mm	ø38.1	ø31.75	ø28.58	ø25.4	ø22.22	ø19.05	ø15.88	ø12.7	ø9.52	ø6.35
Inch	1-1/2	1-1/4	1-1/8	1	7/8	3/4	5/8	1/2	3/8	1/4

3. Making Branch Connections

- For branching tubes, install 150mm or larger (including reducer) straight tubing up to the point where the tube branches (or after the point where the tubes join together). (Fig. 2-302)
- Using a tube cutter, cut the joints at the diameter required to match the outside diameter of the tubing you are connecting. (This is usually done at the installation site.)

The tube diameter depends on the total capacity of the indoor unit. Note that you do not have to cut the joints if it already matches the tubing end size. For size selection of the tube diameter, refer to the installation instructions provided with the outdoor unit.

NOTE

Avoid forceful cutting that may harm the shape of the joints or tubing. (Inserting the tubing will not be possible if the tube shape is not proper.)

- Cut off as far away from stopper as possible. (Fig. 2-303)
- After cutting the joints, be sure to remove burrs on the inside of the joints. (If the joints have been squashed or dented badly, reshaped them using a tube spreader.)
- Make sure there is no dirt or other foreign substances inside the distribution joint.
- The distribution joint can be either horizontal or vertical. (Fig. 2-304)
In the case of horizontal, the L-shaped tubing must be slanted slightly upward (15° to 90°).
- When brazing, replace air inside the tube with nitrogen gas to prevent copper oxide from forming.
- To insulate the distribution joint, use the supplied tubing insulation. (If using insulation other than that supplied, make sure that its heat resistance is 120 °C or higher.)
- For additional details, refer to the installation instructions provided with the outdoor unit.




Fig. 2-302




Fig. 2-303




Fig. 2-304

Direction of Distribution Joint










Fig. 2-305

7. Optional Parts

■ CZ-P4HPC2, CZ-P4HP2C2, CZ-P4HP1C2 (for R410A)

Header Tube Installation





Tube size



NOTE

* The values and alphabets given in the parenthesis indicate the size of CZ-P4HPC2, P4HP1C2.

Unit : mm



- Size of connection joint on each part (shown are inside diameter of tubing)

Size	mm	Inch
Part A	ø38.1	1-1/2
Part B	ø31.75	1-1/4
Part C	ø28.58	1-1/8
Part D	ø25.4	1
Part E	ø22.22	7/8
Part F	ø19.05	3/4
Part G	ø15.88	5/8
Part H	ø12.7	1/2
Part I	ø9.52	3/8
Part J	ø6.35	1/4

Check!

Confirm the parts supplied in the header tube set. The content shows as shown in the table below.

	Content
Part No.1	Header tube to gas side
Part No.2	Header tube to liquid side
Part No.3	Insulator for part No.1
Part No.4	Insulator for part No.2
Part No.5	Reducer(attached to P4HP2C2)
Part No.6	Reducer(attached to P4HP2C2)
Part No.7	Reducer(attached to P4HPC2)
Part No.8	Reducer(attached to P4HPC2)
Part No.9	Reducer(attached to P4HP2C2)
Part No.10	Reducer(attached to P4HP1C2)
Part No.11	Reducer(attached to P4HP1C2)


Installation

- Be sure to handle the header tube in the correct direction as shown below.


<Horizontal use>

- Be sure to use the tube in the 15-degree to 30-degree tilt position. Regarding the branch tube of the indoor unit side, raise the tube correctly as shown in "Horizontal sideways use" and joint the tube sideways.

Horizontal sideways use




Horizontal upward use



7. Optional Parts

<Vertical use>



- Cut off the header tube by the pipe cutter according to meet the demand of the local tube size selected in consideration of the total amount of indoor units.
(It is not necessary to cut off the tube if it is identical to the tip of the size.)


NOTE

Do not forcibly cut off the tube to escape deformation. (If doing so, connection tube cannot be inserted.)
When selecting the size, refer to "Installation Instructions" supplied with the outdoor unit.

- When using with 3 indoor units, cut off the tube and joint in the position fitted to the refrigerant tubing size at the side of 3 indoor units. When not to use some of the header tubes, leave as-is.
- When using with 5 to 8 indoor units, joint two header tubes as shown below.

In case of using header tube :

Tube cutting portion :



- After cutting off the tubing, carefully remove burrs from the cut cross section of the tube and make a smooth finish.
(If there is any hollow on the tube, enlarge the opening port by a mechanical pipe expander.)
- Use the supplied reducer according to the tube size from the side of outdoor unit. In this case, braze it in the local field.
- Check that there is no foreign substance inside the branch tube.
- Use the supplied insulator for the insulation of the branch tube.
(When using other than that, be sure to insulate it to tolerate the temperature of more than 120°C.)
- For the details, refer to "Installation Instructions".

Request for Replacement of Nitrogen When Brazing

If the replacement of nitrogen was not carried out when brazing the refrigerant tube of the outdoor unit and indoor unit, oxidized scale occurs and the motor valve and strainer become clogged.











This will cause malfunction. It is necessary to replace the air in the tube with the nitrogen gas when brazing the tube and prevent the trouble caused by the oxidized scale.

7. Optional Parts

7-2. RAP Valve Kit (Refrigerant Accumulation Protector Valve Kit)

■ CZ-P160RVK2 (for R410A)

1. Accessories

Part name	Figure	Q'ty	Remarks
Strainer assembly for gas tube		2	For gas tube NOTE Two pieces were joined at the time of shipment from the factory. Separate them for use.
Flare insulator		2	For gas tube
		2	For liquid tube
Insulating tape		4	For flare nut sections of gas and liquid tube
Vinyl clamp		14	For both ends of insulator
Washer		2	For suspension bolt
Suspension hook		1	Used to suspend RAP valve kit
M4 screw		4	Used to suspend RAP valve kit
Connecting tube		2	For $\phi 12.7$ gas tube connection
		2	For $\phi 9.52$ liquid tube connection

2. Valve Kit Dimensions and Components

The maximum capacity of the indoor unit that can be connected is 14 kW (5 hp).

For 22.4 kW (8 hp) and 28 kW (10 hp) units, use 2 RAP valve kits connected in parallel. (Refer to Fig. 2-312)

Dimensions and Components




Fig. 2-306

NOTE

This figure shows the valve body with the suspension hook and strainer assemblies installed.

7. Optional Parts

Connecting Tube Shape (For $\phi 9.52$ liquid tube connection)




Fig. 2-307

Connecting Tube Shape (For $\phi 12.7$ gas tube connection)




Fig. 2-308

3. Air-tightness Test

Nitrogen is sealed inside the main unit. Before loosening the flare section, perform the following air-tightness check. Use pliers or a similar tool to bend the end of the indoor unit hermetically sealed tubing so that a crack is formed. Verify that a "pffft" sound occurs.

Air-tightness Test




Fig. 2-309

4. Installation

(1) Preparation

- Fit the supplied suspension hook to the valve body with 4 screws.
- Next, fit the strainer assemblies to the gas tube inlet and outlet and tighten the flare nut.
- In doing this, **be sure to use 2 spanners** together and tighten the flare nut with the tightening torque shown in Table 2-27.
- Since the RAP Valve Kit contains nitrogen, be careful when removing the flare nut.
- The diameter of the indoor unit tubing may be different from the diameter of the tubing for this unit.

If this is the case, refer to Figs. 2-307 and 2-308 (for the liquid tube and gas tube, respectively) and follow the instructions there.

For 22.4 kW (8hp) and 28 kW (10hp) indoor units, connect 2 RAP Valve Kits in parallel.

Assembly Drawing




Fig. 2-310

Service Space




Fig. 2-311

Example of RAP Valve Kit Installation




Fig. 2-312

7. Optional Parts

(2) Notes on Installation

- **For the direction for connecting the indoor and outdoor unit and RAP Valve Kit, be sure to follow the instructions on the label of the valve body.**

- Be sure to secure the valve body by using its structure with the suspension bolt, etc.
- Install the valve body within **a distance of 30 m from the indoor unit** as shown in Fig. 2-312.
- Be sure to install the valve body **with its upper surface facing upward**.
- When installing the valve, ensure a service space of 200 mm or more (Fig. 2-311).
- Secure the valve body by using the upper or side holes of the suspension hook.
- Do not place the valve body directly on the ceiling surface. Also, do not install near conference rooms or other rooms where extremely quiet operation is required.
- **Never do drilling or welding** on the sheet metal of the valve body.
- Place the valve body so that it does not hinder draining.

If using the optional tubing kit, refer to the installation manual for the kit.

Connection




Fig. 2-313

5. Wiring, Tubing, and Insulation

(1) Wiring

- Put the 6P connector from the RAP Valve Kit through the power inlet and connect it to the 6P connector (yellow). (See Fig. 2-313)
- Secure the supplied cable with the binding band inside the unit.
- Do not run the supplied cable through the same wiring conduit together with the remote control line and inter-unit control line.

(2) Refrigerant Tubing

- **Be sure to use 2 spanners** together for removing the flare nut at the tubing connection or when tightening the flare nut during tubing connection.
- To prevent destruction in the flared portion due to over-tightening the flare nut, tighten the nut using the table at the right as a standard torque.




Table 2-27. Tightening Torque

Tubing size	Tightening torque	
	(N•m)	(kgf•cm)
ø6.35 (1/4")	16±2	Approx. 140 – 180
ø9.52 (3/8")	38±4	Approx. 340 – 420
ø12.7 (1/2")	55±6	Approx. 490 – 610
ø15.88 (5/8")	75±7	Approx. 680 – 820
ø19.05 (3/4")	110±10	Approx. 1,000 – 1,200

(3) Insulation

Be sure to provide insulation after finishing leak inspection.

- Be sure to provide insulation to the tubing.
- Use insulation with a thickness of 10 mm or more, with heat resistance of 120°C or more for gas tubes and 80°C or more for liquid tubes. If the ambient conditions exceed DB 30°C and RH 70%, increase the thickness of the thermal insulation by one step.
- Put the supplied insulating tape, 2 pieces of each, around the flare nut portion of the liquid tube.
- Next, put the supplied flare insulator around the flare nut portion and secure both ends with the vinyl clamps.
- Failure to provide insulation may cause water leakage due to condensation.
- Thermal insulation is not supplied with the connecting tube (for connecting to the ø12.7 gas tube).
If this tube is used, obtain insulation (field supply) separately.

Insulation




Fig. 2-314

7. Optional Parts

7-3. External Electronic Expansion Valve Kit for Indoor Unit

■ CZ-P56SVK2, CZ-P160SVK2 (for R410A)

Precautions in this manual are given in the form of "Warnings" or "Cautions."

Both types of precautions contain important information related to your safety, the safety of users, and the correct operation, installation, or maintenance of the air conditioning system. Be sure to carefully observe all relevant precautions.


WARNING

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.


CAUTION







This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

- This external electronic expansion valve is compatible with the refrigerants listed below.

R410A, R407C, R22

• Checking Parts

Please check these parts below that came in the box.

	Description	Shape	Q'ty
1	External electronic expansion valve (Extension cord 8 m)		1
2	Flare insulator		2
3	Clamp (Large: 350 mm, Small: 200 mm)		Large: 2 Small: 4
4	Connector-converter cable		1
5	Installation manual		1
6	Insulating tape	 White (heat resisting)	2

Installation Procedure

1. Positioning for Installation

- The valve should be connected to the liquid tube. Determine the position for installation referring to the diagram of outer dimensions. (Fig. 2-315) Refrigerant-flow noise may occur from the external electronic expansion valve. As a guide, the distance from the indoor unit should be a minimum of 5 m, but less than 8 m. (Install away from locations where strictly quiet operation is required.) If this distance is unavailable, install inside the ceiling or in another location where noise insulation is possible. This is a functional component, and therefore may require inspection and replacement. Consider this when deciding the installation location. (For example, place near an inspection port, or provide one.)
- This valve is for indoor use. Do not install the valve outdoors.




Fig. 2-315 Diagram of outer dimensions

7. Optional Parts

2. Cutting and Flaring of Liquid Tube


After determining the position for installation, cut the liquid tube and flare the connecting portion.
(Pay attention to the notes below when flaring the tubes.)

NOTE

- After cutting the tube, deburr and finish the end face smoothly and correctly.
 - Do not damage tubes while flaring.
 - Take care not to allow dirt and deburred chips into the tube.
 - Use the flare nut which came with External Electronic Expansion Valve Kit.
 - The flaring dimensions for R410A are different from the conventional dimensions for R407C and R22. For R410A, the specially created flaring tool is recommended.
- However a conventional tool can be used by adjusting the amount of copper tube projection as shown in the table below.

Unit: mm

Rigid (clutch type)		
R410A		R407C, R22
If special R410A tool is used	If conventional tool is used	If conventional tool is used
B=0~0.5	1.0~1.5	0~0.5



Copper tube projection for flaring: B (mm)


Fig. 2-316

3. Connection of External Electronic Expansion Valve with Tubing

In connection with tubing, take care to fit the external electronic expansion valve in the right direction. Be sure to install with the mark on the label pointing upwards. Also when connecting the flare, use the arrow marks on the label to check the directions of the indoor unit side and outdoor unit side.

(The wiring outlet side faces the indoor unit.)

(Refer to Fig. 2-317.)



Attached label on the unit




Fig. 2-317

- Tightening flare nuts




CAUTION

Be sure to use 2 spanners together when removing or tightening the flare nuts. After connection with the tubing, tighten the flare nuts by the correct torque. Failure to tighten the nuts correctly can cause loosening and damage on the flared portion, resulting in accidents by oxygen deficiency due to refrigerant leaks.

Tubing size	Tightening torque
ø6.35 (1/4")	14~ 18 N · m (140~180 kgf · cm)
ø9.52 (3/8")	34~ 42 N · m (340~ 420 kgf · cm)

4. Flare Insulation of Tubing

After completing a leakage test, apply heat insulation. (Fig. 2-318)



Be careful not to allow a gap to occur between the thermal insulation of the tubing and the thermal insulation of the main unit.

* Use the flare insulator provided with the product.

Fig. 2-318

7. Optional Parts

5. Securing the External Electronic Expansion Valve After Connection with Tubing

After connection with tubing, secure the external electronic expansion valve using the supplied clamps (large) to hold it against the gas tube. (Fig. 2-319)

NOTE

Be careful not to tighten the clamps with excessive force, in order to avoid deforming the tubing or other parts.




Fig. 2-319

Wiring Procedure



WARNING

Be sure to turn the power off at the mains before removing or connecting connectors to avoid electric shock hazard.

● Connection of External Electronic Expansion Valve with Extension Cord

- (1) Turn the power off.
- (2) Turn the power on. (This step is unnecessary if the model does not have an electronic expansion valve.)
- (3) Wait 1 minute after the power is on and then turn the power off again at the mains.
(This step is unnecessary if the model does not have an electronic expansion valve.)
- * The electronic expansion valve becomes full-open in the 1 minute.
Do not give instructions for operation through the remote control during this time.
- (4) Open the electrical component box. From the control PCB, disconnect the connector to the indoor unit internal electronic expansion valve. (This step is unnecessary if the model does not have an electronic expansion valve.)
- (5) Connect the external electronic expansion valve. (Fig. 2-320)

Connect the external electronic expansion valve connector to the indoor unit control PCB (PMV or T6).
After completing the wiring process, close the cover of the electrical component box.

* With some models that do not include an electronic expansion valve, a relay connector is included. Connect this relay connector.

- (6) Turn the mains power breaker back on.
This procedure is now completed.




Fig. 2-320

Wiring Procedure (Using the Attached Cable)

Depending on the model of indoor unit that is connected, this product may require the use of a supplied connector-converter cable. Refer to the below for the corresponding units and the method of use.

● If the indoor unit control PCB has a 5P plug, use the supplied connector-converter cable.

● Using the connector-converter cable

The connector-converter cable is used by connecting it to the extension cable (8 m) that runs from the electronic expansion valve unit. (Refer to Fig. 2-321.)

After connecting the connector-converter cable, follow the above wiring procedure and connect the cable to the indoor unit control PCB.

* Depending on the model, a relay connector may be connected on the indoor unit control PCB. If this supplied cable is used, disconnect the relay connector and connect the supplied cable directly to the indoor unit control PCB.




Fig. 2-321

7. Optional Parts





7-4. Filter Chamber for Indoor Unit

■ CZ-FDU2

Installation Instructions

1. Accessories

- Check that the following parts are in the box when unpacking.

Supplied parts	Q'ty	Remarks	Supplied parts	Q'ty	Remarks
Installation screws (5x40) 	4	Fixture for filter chamber	Short-circuit connector 	1	
Washer 	4	Fixture for filter chamber	Instructions 	Each	Installation Instructions, Fan tap

2. Installation

NOTE

1. Be careful handling the unit when installing it inside the ceiling. Use particular care to avoid allowing any impact to strike the side of the filter chamber, as this can result in damage.
2. Remove the cardboard inserted in the air outlet (4 locations) before installation.

(1) Installing Filter Chamber (Fig. 2-322)

- Align the black sealing material on the filter chamber with the indoor unit.
(The filter chamber must be installed in a specific direction, therefore align the shape of the filter chamber with the shape of the indoor unit.)
- Fasten with the supplied installation screws (x4).

(2) Installing Indoor Unit

- Install the indoor unit (attached to the filter chamber) in the ceiling.
(Install the indoor unit according to instructions supplied with the indoor unit.)

(3) Installing Ceiling Panel (Fig. 2-323)

- Install the ceiling panel to the chamber.
(Install the ceiling panel according to instructions supplied with the ceiling panel.)
- First cut off the bundled clumper and insert the ceiling panel 22P (white) connector into the through-hole of the chamber.
Then connect it to the 22P connector in the electric component box.






Fig. 2-322




Fig. 2-323

7. Optional Parts

7-5. Air Intake Kit for Chamber







■ CZ-ATU2

Duct connection box

Installation Instructions

1. Accessories

- Check that the following parts are in the box when unpacking.

Supplied parts	Q'ty	Remarks
Duct connection box 	1	
Duct connection box installation bracket 	1	
Installation flange (ø100) 	1	Duct flange
Instruction screw 	14	
Thermal insulation for installation screws A 	2	Polyethylene foam T2
Thermal insulation for installation screws B 	2	Polyethylene foam T5


2. Installation

NOTE

Install the duct connection box after installing the indoor unit. Also, because the duct connection box is attached to the air-intake plenum, use sufficient care when handling it. Especially avoid any impacts on the side of the air-intake plenum, as this can result in damage.

- Follow the instructions in the air-intake plenum installation instructions and install the air-intake plenum on the indoor unit.

- (1) Remove the sealing plate from the air-intake plenum.
- (2) Fit the duct connection flange and installation bracket into the duct connection box. Fasten with the supplied 8 installation screws.
- (3) Fasten the duct connection box to the air-intake plenum with the 6 installation screws.
- (4) Apply the supplied thermal insulation A and B to the installation screws.









7. Optional Parts

7-6. Air Intake Kit for Unit

■ CZ-BCU2

Installation Instructions

1. Accessories

Supplied parts	Q'ty	Supplied parts	Q'ty	Supplied parts	Q'ty
Connecting box for main unit 	1	Instructions 	1	Installation screw (4 x 10) 	4
Sealing insulation "A" 	2	Sealing insulation "B" 	2	Duct connection flange (φ100, for fresh air intake) 	1

2. Installation

- (1) Cut and remove the sheet-metal together with an insulation (styrofoam) with a nipper or a cutter knife paying attention to the incision as a marker on the indoor unit. (Fig. 2-324)

NOTE

When cutting out the styrofoam, do not insert the blade more than 30mm depth. (If the inside of the drain pan is damaged, this will result in water leakage.)
Also, be careful not to let the chips invade the unit.

- (2) Peel off the insulation of the shaded portion and insert the connecting box for the main unit from the air outlet of the main unit. (Fig. 2-325)

- (3) If there is a space between the styrofoam and the sheet-metal, this will result in condensation forming.
First seal the supplied insulation "A" to meet the hole of the screw and then seal that of "B". (Fig. 2-326)

- (4) Fasten the flange to the indoor unit supplied with the installation screws (x4). (Fig. 2-327)




Fig. 2-324




Fig. 2-325




Fig. 2-326




Fig. 2-327

7. Optional Parts

7-7. Air Cut Insulation

■ CZ-CFU2

Installation Instructions

Use this part to close air flow when setting 3-way or 2-way air discharge, or connecting the duct connection flange ($\phi 150$) according to the situation of the unit installation.





NOTE

When using an optional high-performance filter, a filter grille or a natural evaporation type humidifier, it is impossible to shift the 3-way or 2-way air discharge or make a connection of duct connection flange ($\phi 150$).

1. Applicable Model & Use

Model	Use
CZ-CFU2	<ul style="list-style-type: none"> ● Close off in case of 3-Way or 2-Way Air Discharge ● Close off in case of connecting the duct connection flange ($\phi 150$)

2. List of Parts

Model	Supplied parts	Dimensions	Shape	Q'ty
CZ-CFU2	Part to close air flow	490 × 70 × T40		2
	Packing	650 × 100 × T2		2
	Short-circuit connector			1
	Instructions		Instructions & Change Procedures of DC Fan Tap 	2

3. Installation

When using the part to close air flow, follow the change procedures of DC Fan Tap and change the fan tap. If not changed, air discharge temperature in the cooling mode drops due to the reduction in airflow. This may result in condensation forming.

(1) Indoor Unit Installation

- Install the indoor unit in the ceiling. (Install the indoor unit according to instructions supplied with the indoor unit.)

(2) Cut off the part to close air flow and the packing according to the installation dimensions as shown in the right table.

Be careful as the dimensions are different due to the installation location.


Be careful they should be no shorter than the installation dimensions. The excessive cut may result in condensation forming.

(3) Part to close air flow Installation

- Insert the part to close air flow into the air outlet (styrofoam) of the indoor unit and apply the packing and close. (See Fig. 2-328 and Fig. 2-329.)
- Paste the packing to cover the internal styrofoam in the unit more than 15mm. (If not covered over 15mm, this may result in condensation forming.)

Installation location	Name	Installation dimension
①	Part to close air flow	450×70
	Packing	490×100
②	Part to close air flow	490×70
	Packing	610×100
③	Part to close air flow	490×70
	Packing	650×100
④	Part to close air flow	400×70
	Packing	620×100

7. Optional Parts




(Fig. 2-328)

Cut off the packing on a slant not to be subjected to the drain wiring.

The portion where the packing protrudes outward must be folded to the side of the lateral plate and paste it.

The packing should not be subjected to the corner metal.




(Fig. 2-329)

(4) Block Pattern of Air Outlet (seen from the unit bottom)

- In case of 3-way or 2-way air discharge and connecting the duct connection flange ($\phi 150$), block the air outlet according to the block pattern of air outlet as shown on the next page. Also, select the appropriate piping position referring to the following table. (See Fig. 2-330 to correctly understand the illustration.)

NOTE

Be careful not to cause condensation, cool wind leak and insulation shortage when installing the duct connection flange ($\phi 150$).



(Fig. 2-330)

7. Optional Parts

- Do not apply any other block pattern of air outlet as listed below.

3-way air discharge Capable of blocking 1 direction				
2-way air discharge Capable of blocking 2 directions				
3-way air discharge + connecting air outlet duct connection flange ($\phi 150$) Block one of the air outlet and connect the duct connection flange. Then the air is discharged from the air discharge duct connection flange.				
2-way air discharge + connecting air outlet duct connection flange ($\phi 150$) Block two (2) air outlet and connect either of the duct connection flanges. Then the air is discharged from the air discharge duct connection flange. There is, however, only capable of discharging the air from one set of air outlet duct connection flange.				

(5) Setting Changes of DC Fan Tap

- Make settings of the wired remote control, timer remote control or indoor unit control P.C. board (using supplied short-circuit connector) according to separate instructions.
- Make settings of 3-way air discharge and 2-way air discharge according to separate instructions.

8. How to select of AHU system

AHU system selection guideline


● System lineup

Capacity	Outdoor combination			Connectable AHU-kit combination		
28 kW	U-10ME1E81	—	—	CZ-280MAH1	—	—
56 kW	U-20ME1E81	—	—	CZ-560MAH1	—	—
84 kW	U-16ME1E81	U-14ME1E81	—	CZ-560MAH1	CZ-280MAH1	—
112 kW	U-20ME1E81	U-20ME1E81	—	CZ-560MAH1	CZ-560MAH1	—
140 kW	U-18ME1E81	U-16ME1E81	U-16ME1E81	CZ-560MAH1	CZ-560MAH1	CZ-280MAH1
168 kW	U-20ME1E81	U-20ME1E81	U-20ME1E81	CZ-560MAH1	CZ-560MAH1	CZ-560MAH1

*Mix connection with standard indoor units is not allowed.

*Applicable system is only above. (2way VRF system, ME1E81 series)

● System Overview



* In case of 84kW or more capacity system, system requires 2 or 3 AHU kits and heat exchangers. Connection and setting of multiple AHU kits and heat exchanger are same as normal indoor unit.
 ex) There are 3 AHU kits and heat exchanger. Main piping should be distributed to 3 paths. PCB setting "No. of indoor unit" of outdoor unit (master) should be set to "3".

● Piping design regulation

- Connecting pipe dimension to heat exchanger of AHU


Capacity	Model name	Liquid pipe	Gas pipe
28kW	CZ-280MAH1	Ø9.52mm	Ø22.22mm
56kW	CZ-560MAH1	Ø15.88mm	Ø28.58mm

- Main piping diameter

System size	Liquid pipe	Gas pipe
28 kW	Ø 9.52mm	Ø 22.22mm
56 kW	Ø 15.88mm	Ø 28.58mm
84 kW	Ø 19.05mm	Ø 31.75mm
112 kW	Ø 19.05mm	Ø 38.10mm
140 kW	Ø 19.05mm	Ø 38.10mm
168 kW	Ø 19.05mm	Ø 38.10mm

8. How to select of AHU system


- System piping length
 Max. piping length: 100m (actual) / 120m (equivalent)
 Difference between longest and shortest piping from first branch: 10m
 Max. length of branch tubing: 12m
 * Other conditions to be referred the standard piping design regulations.
- Installation
 - Expansion Valve
 If there are multiple heat exchanges in one system, each heat exchanger requires expansion valve that is in the AHU kit.




For 10HP AHU, piping to outdoor unit is $\varnothing 9.52$. Reduce the piping size in field.

- Thermistor for Gas and Liquid Pipe
 If there are multiple heat exchanges in one system, each heat exchanger requires these thermistors that is in the AHU kit.


Gas thermistor




Attach the gas thermistor to the gas pipe of collecting gas pipe in heat exchanger.



Cover the thermistor and pipe with aluminum tape




Cover the aluminum tape with thermal insulation




Thermal insulation and wiring are fixed in two bands


Liquid thermistor




Attach the liquid thermistor to the liquid pipe located in the lowest position after distributor in heat exchanger



Cover the thermistor and pipe with aluminum tape




Cover the aluminum tape with thermal insulation



Thermal insulation and wiring are fixed in two bands

8. How to select of AHU system

- Blower operation signal and protection signal



● Limitation of AHU

When the AHU is selected, there are some limitations.

- The limitation of temperature range is below.

		Cooling	Heating
Outdoor temperature	Min.	-10 °C(DB)	-20 °C(WB)
	Max.	43 °C(DB)	15 °C(WB)
Inlet air temperature (to the heat exchanger)	Min.	18 °C(DB)	0 °C(DB)
	Max.	32 °C(DB) / 23°C(WB)	30 °C(DB)

- The limitation of heat exchanger volume and air volume is shown in below table 1 & 2.

Table 1: Inside volume of heat exchanger

Capacity (Cooling)	kW	28.0	56.0	84.0	112.0	140.0	168.0
Max. volume of Hex	dm ³	5.4	10.7	16.1	21.4	26.8	32.1
Min. volume of Hex	dm ³	2.8	5.6	8.4	11.2	14.0	16.8

Table 2: Air volume of AHU

Capacity (Cooling)	kW	28.0	56.0	84.0	112.0	140.0	168.0
Max. air volume	m ³ /h	3500	7000	10500	14000	17500	21000
Min. air volume	m ³ /h	5000	10000	15000	20000	25000	30000

But in addition, system requires other complex limitation like pressure loss, sufficient pressure of refrigerant, etc. An appropriate AHU can be easily selected by using software named "AHU for VRF.exe".

8. How to select of AHU system

● How to use the software "AHU for VRF"

1. Execute the software "AHU for VRF.exe"

2. Input the specification of heat exchanger, air volume, capacity and temperature at heating.

- ① Input inside diameter of tube not outside diameter.
All the tubes of a heat exchanger must be the same inside diameter.
- ② ③ ④ ⑤ Input distance between tube sheets, No. of paths and steps and rows.
From above information, software calculates the inside volume and pressure loss of heat exchanger.
Inside volume of heat exchanger must be between table 1 values.
- ⑥ Input air volume of AHU
Air volume must be in the range shown at table 2.
- ⑦ Select the system capacity
Check the system size from 10HP to 60HP listed in the box.
- ⑧ Input the temperature condition.
It is for confirming the abnormal situation in heating.
In case of low temperature condition, it may not be possible for heating operation.
- ⑨ Push the Calculation button.

3. Check the results

The results are shown in three places.

- ① Results of inside volume and pressure loss of heat exchanger
*Case "NG":
Inside volume of heat exchanger is out of range shown at table 1.
Change the value excluding No. of paths.
*Case "NG(Pressure loss is high)":
Pressure loss, especially in cooling operation, is high.
Change the value of "No. of paths".
- ② Results of air volume.
*Case "NG":
Air volume of AHU is out of range shown at table 2.
Change the value.

8. How to select of AHU system

③ Heating operation check.

*Case "NG":

This is the case which AHU system cannot perform suitable operation.

The main causes are the following three points.

- 1) Outdoor temperature is low
- 2) Indoor temperature is low
- 3) Air volume is high

Change the above value mainly.

*In case of some value displayed.

This is the performance in this condition. 8

10 Push the "Heating Capacity table" button.

It is able to confirm the capacity table in heating.

Data is saved as "temp heat.csv" at the same folder of the software.

	A	B	C	D	E	F	G	H	I
1	System capacity: 10 HP								
2	Inside diameter of HEX: 8.52 mm								
3	Distance between tube sheets: 1190 mm								
4	No of paths: 8								
5	No of steps: 20								
6	No of rows: 3								
7	Air volume: 5000 m3/h								
8									
9	Heating Capacity table(kW)								
10			Indoor temperature(DB)						
11			15	17	19	20	21	23	25
12	Outdoor	-20	NG	NG	NG	NG	22.6	21.1	19.5
13	temp(WB)	-15	NG	27.1	25.6	24.8	24	22.4	20.8
14		-10	30.2	29.1	27.5	26.7	25.9	24.2	22.5
15		-5	32.2	31.7	30.1	29.2	28.3	26.5	24.7
16		-2.5	33.5	32.9	31.7	30.8	29.9	28	25.7
17		0	34.9	34.2	32.7	31.5	30.3	28	25.7
18		2	35.9	35	32.7	31.5	30.3	28	25.7
19		5	37.3	35	32.7	31.5	30.3	28	25.7
20		6	37.3	35	32.7	31.5	30.3	28	25.7
21		7.5	37.3	35	32.7	31.5	30.3	28	25.7
22		10	37.3	35	32.7	31.5	30.3	28	25.7
23		15	37.3	35	32.7	31.5	30.3	28	25.7

If "NG" is displayed, the system cannot perform normal operation in heating mode on this condition.

– MEMO –